



MAIN(01) SECTIONS




SEC. 11 WHEELS




GROUP	EQUIP	TIRE SIZE	RIM
83.00	83.52	16.9 - 28 R4 - 10 PLY TITAN	W14L X 28Z
	83.64	16.9 - 24 R4 - 10R	W15L X 24
	83.65	17.5 - L24 R4 - 10PR	W16L X 24
	83.91	19.5 - L24 R4 - 10PR	W16L X 24
	83.92	18.4 - 26 R4 - 12PR	W16 X 26



GROUP	EQUIP	TIRE SIZE	RIM
82.00	82.75	14 -17.5NHS - 8PR	10.5 X 17.5
	82.76	12 -16.5 - 8PR	10.5 X 17.5
	82.78	10.5/80 -18I3 - 10PR	9 X 18
	82.79	12.5/80 -18I3 - 10PR	9 X 18
	82.80	12.5/80 -18I3 - 10PR	9 X 18
	82.86	340/80-R18-136A8	9 X 18







GROUP	EQUIP	TIRE SIZE	RIM
81.00	81.35	11L - 16F3 - 10PR	W8L X 16
	81.38	11L - 16SLF3 - 10PR	W8L X 16





GROUP	EQUIP	TIRE SIZE	RIM
85.00	85.64	16.9 - 24 R4 - 12PR	W14L X 24
	85.64	16.9 - 24 R4 - 12PR (I.S.G.)	W15L X 24
	85.65	16.9 - 28 R4 - 12PR	W15L X 28
	85.65	16.9 - 28 R4 12PLY GY (I.S.G.T)	W15L X 28
	85.66	440/80 R28 156A8 IT 530	W14L X 28
	85.67	440/80 R28 156A8 IT 520	W14L X 28














1.92.1(01) CAB & DOOR FRAMES



514(01) BACKHOE BOOM & RELATED PARTS






1.82.3(01) HYDRAULIC PUMP




● = 2
▲ = 3



0.40.0/ B(01) ALTERNATOR



1.98.0/ 1(03) CAB WARNING & INFORMATION DECALS



- BEFORE LEAVING THE OPERATOR'S SEAT TURN THE ENGINE OFF AND CONNECT THE **PARKING BRAKE**
- LAY THE EQUIPMENT TO THE GROUND
- REMOVE THE KEY FROM THE DASHBOARD BEFORE LEAVING THE OPERATOR'S SEAT
- TURN THE ENGINE OFF BEFORE ANY MAINTENANCE OPERATION

3

5



6

1

WATCH YOUR PROOF - METER HOURS

LUBRICATION AND MAINTENANCE
SERVICE INTERVALS

LUBRICATION AND MAINTENANCE ITEM	CHECK	CLEAN	LUBE	SERVIC INTERVAL
AIR CLEANER OUTER ELEMENT (1)	•	•		WHEN IN INDICATED
HYDRAULIC SYSTEM OIL FILTER	•	•		
HYDRAULIC OIL LEVEL	•			DAILY
ENGINE OIL LEVEL	•			
RADIATOR COOLANT LEVEL	•			
BACKHOE PIVOTS			•	EVERY 50 HOURS
LOADER PIVOTS			•	
SEAT RAILS			•	
FRONT AXLE AND STEERING PIVOTS			•	
DIFF LOCK PEDAL PIVOT			•	

1) NOTE: IMPROPER CLEANING CAN DAMAGE THE FILTER. REFER TO THE OPERATOR'S MANUAL FOR CORRECT CLEANING PROCEDURE. (LUBRICATION AND MAINTENANCE SECTION).

REFER TO YOUR OPERATOR'S MANUAL FOR EXTENDED SERVICE INTERVAL REQUIREMENTS OF OTHER MAJOR COMPONENTS.

ALWAYS USE GENUINE NEWHOLLAND PARTS AND LUBRICANTS

WARNING


- Before starting and operating:
Know the operating and safety instructions in the operators manual and on the tractor.
Clear the area of bystanders.
Locate and know operation of controls.
- Start engine only from operators seat with transmission in neutral, and hydraulic controls in lowered position.
- Do not permit anyone but the operator to ride on the tractor. There is no safe place for riders.
- Lock brakes together, use warning lights and SMV emblem when driving on roads.
- Lower equipment, place gear shift in neutral, stop engine and apply parking brake before leaving tractor seat.
- Loader bucket must be installed during machine operation for proper balance. Out of balance condition can result in overturn and personal injury.
- Do not enter platform from the rear. Operate backhoe from operator's seat only.
- Do not low start.
- When lowering place gear lever in fourth gear.

FAILURE TO FOLLOW ANY OF THE ABOVE INSTRUCTION CAN CAUSE SERIOUS INJURY TO THE OPERATOR OR OTHER PERSONS.

2

4

7







Caution

AIR CONDITIONING SYSTEM CONTAINS "HFC 134a". A NON OZONE DEPLETING REFRIGERANT AND PAG OIL. SERVICE, REPAIR OR RECHARGING MUST BE PERFORMED BY QUALIFIED PERSONNEL ONLY.

REFRIGERANT HFC 134a
CHARGE 1.65 LBS 10.750 Kg.



1.98.0/ 1(04) BACKHOE, LOADER & ENGINE WARNING DECALS



Ref	Part Number	Qty	Description
-----	-------------	-----	-------------




PREVIEW - YOUFIXTHIS.COM			
--------------------------	--	--	--



--	--	--	--

LB75.B BACKHOE LOADER UPGRADE 2000 (1/01-) - General

0.14.0/ 1(03) ENGINE, WATER SEPARATOR/FILTER ASSY.

Ref	Part Number	Qty	Description
1	87802172	1	FILTER, Water Separator
2	81825360	2	PLUG,
3	81825363	1	WASHER,
4	81833781	1	WASHER,
5	81811884	1	O-RING,
6	87802367	1	CAP, Head, Filter
7	83914036	2	GASKET,
8	83900080	1	O-RING,
9	81871478	1	FILTER, ELEMENT,
10	83916922	1	FILTER, ELEMENT,
11	81871481	1	STUD,
12	81871479	1	BOWL, Sediment
13	81813204	1	SEAL, Washer
14	81871482	1	BASE,
15	81833780	1	SCREW,





POWER SHIFT (PT)




LB75.B BACKHOE LOADER UPGRADE 2000 (1/01-) - General

1.88.11/ 1(01) LIFT CYLINDER

Ref	Part Number	Qty	Description
1	85800160	2	HYDRAULIC CYLINDER, Assy, Loader
2	85801049	1	PIN, 38 mm x 159 mm
3	87916S8	4	NIPPLE, LUBE, 1/8-27-90GR
4	N800272S36M	1	RING, SNAP,
5	85801050	1	PIN, 38 mm x 183 mm
6	87402742	2	PIN,
7	85800103	2	ROD, Includes 8
8	290620	4	BUSHING,
9	85800105	2	TUBE,
10	291550	4	BUSHING,
11	85802993	2	PIN,
12	85802992	2	RING,
13	47049094	4	CIRCLIP,
14	D9NNA273BA	2	SEAL,
15	85800082	2	WIPER, 50 mm rod
16	85800086	2	SEAL, 50 mm rod
17	85800090	2	SEAL, 50 mm rod
18	85800093	2	Ring, Wear, 50 mm rod
19	85800973	2	GLAND,
20	87079S95	2	O-RING, 5/8 x 0.097
21	85800981	2	PISTON, Includes 14, 22
22	85800960	2	RING,
23	85800003	2	BACK-UP RING,
24	E8NNA156FB	2	SCREW,
25	85819352		AR KIT, SEALS,

UP TO S/N 031053101

1.91.6(01) RADIO ANTENNA & SPEAKER COVER





LB75.B BACKHOE LOADER UPGRADE 2000 (1/01-) - General


1.94.2/ 1(02) HEATER WATER HOSES

Ref	Part Number	Qty	Description
1	85802320	1	HOSE, FLEXIBLE, 1950mm lg,
1	85802321	1	HOSE, FLEXIBLE, 2200mm lg,
2	85803344	1	CLAMP,
3	85803079	8	CLAMP, HOSE,
4	85803057	2	TEE,

S/ -031033370



215(01) FRONT COUNTERWEIGHT





1

2




LB75.B BACKHOE LOADER UPGRADE 2000 (1/01-) - General


474(01) 6X1 BUCKET (1 M3) WITH TEETH

Ref	Part Number	Qty	Description
1	85820032	1	BUCKET,
2	85820033	1	BUCKET,
3	85820018	4	SCREW, M10 x 90
4	85820035	4	NUT, M10 x 1.5
5	85820021	1	SCREW, M8 x 120
6	85820031	1	NUT, M8
7	85820034	12	SCREW, M6 x 30
8	85820026	2	PLATE,
9	85820028	12	CLAMP,
10	85820066	2	PIN,
11	85820063	2	SUPPORT,
11	85827785	2	SUPPORT,
12	85820014	8	NIPPLE, LUBE, M10 x 1,
13	85820062	2	FORK, BUCKET,
14	85820067	2	PIN,
15	85820068	2	PIN, LOCK, D=11
16	85820016	2	PIN, ROLL, M10 x 80
17	85820017	2	PIN,
18	85820005	2	CYLINDER,
19	85820013	4	BUSHING,
20	85820015	2	PIN,
21	85820007	8	SCREW, M14 x 35
22	85820009	8	WASHER, SEALING,
23	85820008	10	NUT, M14 x 2
24	85820006	1	EDGE, CUTTING,
25	85820025	4	CONNECTOR, HYD.,
26	85825177	2	PIN, LOCK, D=8
27	85824364	2	HOSE, FLEXIBLE,
28	85824363	2	HOSE, FLEXIBLE,
29	85820039	2	TUBE, HYD,
30	85820040	2	TEE,
31	85820038	2	TUBE, HYD,
32	85820064	2	PIN,
33	85820069	2	PLUG,
34	85820065	2	BRACKET,
34	85827786	2	BRACKET,
35	85820027	4	CLAMP,
36	85820019	2	PIN,
37	85820020	2	SCREW, M14 x 30
38	85820011	4	SCREW, M8 x 16
39	85820012	4	WASHER, SEALING,
40	85820010	2	GUARD,
41	85820030	2	SCREW, M8 x 45

525(01) 1MC LODER BUCKET FORKS



● = 14



LB75.B BACKHOE LOADER UPGRADE 2000 (1/01-) - General

641/ 1(09) HEATER COIL HOSES

Ref	Part Number	Qty	Description
1	85803079	4	CLAMP, HOSE,
2	85804974	2	HOSE, FLEXIBLE,
3	11193274	1	WASHER, SPRING, Belleville, M6.4,
4	85817303	1	HOSE, FLEXIBLE,
5	85817299	1	HOSE, FLEXIBLE,
6	85804980	1	VALVE,
7	85804051	1	TUBE,
8	85817294	1	THERMOSTAT,
9	85804975	2	CLIP,
10	85804989	1	SUPPORT,
11	85812217	1	CLAMP,
12	85817295	1	NUT,
13	10902424	2	BOLT, Hex, M6 x 20, 8.8, Full Thd,
14	86508568	1	BOLT, Hex, M6 x 16, 8.8,



LB75.B BACKHOE LOADER UPGRADE 2000 (1/01-) - General

855(01) AIR RIDE CLOTH SEAT & ATTACHING HARDWARE

Ref	Part Number	Qty	Description
1	85815544	1	SEAT, DRIVER, 2" Seat Belt
2	85815545	1	SEAT, DRIVER, 3" Seat Belt
3	120104	8	BOLT, Hex, M8 x 20, 8.8,
4	11198071	8	WASHER, SPRING, Belleville, M8.4,

PREVIEW - YOUFIXTHIS.COM

PREVIEW ONLY

You're viewing 25 of 915 pages

The full manual includes:

- All 915 pages, complete
 - Searchable PDF (find any keyword)
 - No watermarks
 - Instant download
 - Print-ready quality
-

GET FULL MANUAL NOW

**New Holland LB75.B, LB85, LB90, LB95, LB110, LB115, LB75.B
BACKHOE LOADER UPGRADE 2000, LB75.B Backhoe Loader,
UPGRADE 2000 (1/01-) Parts Catalog**



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual