## How To Use Figure Search

1). Locate the figure list index at the beginning of manual

examples:

01A01 FRONT WHEEL ASSEMBLY - 2100,2110,2120,2150,2300,2310,3055,3100,3120,3150,3190,3300,3310,3550,4140

01A01[C] FRONT WHEEL ASSEMBLY, W/16" WHEELS - 3400, 3500, 3550, 4400, 4500, 4410, 5100, 5200, 5190, 7100, 7200

01B01 STANDARD REAR WHEELS - 2000, 4100 & 3000 EXCEPT 3550

01B01[A] STANDARD REAR WHEELS - 3500, 3550, 5000, 7000, 4000 EXCEPT 4110

01B02 POWER ADJUSTABLE REAR WHEELS - 2000, 3000, 4140

Use the “search” feature in adobe to jump to the figure number.

Press **Ctrl** key, and letter **F** on the keyboard, at the same time. This will bring up the “search” feature in Adobe Acrobat. Then simply type in the figure number you wish to locate, and press enter.

Adobe takes you immediately to that page!

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TB110 4 CYL AG TRACTOR (12/02- )

01A01 FRONT WHEELS, 2WD

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | | 2 | W 6 x 16 |
| 1 | 82965788 | 2 | W 6 x 16 |
| 2 | 82980464 | 2 | RETAINER, |
| 3 | 67370 | 2 | BEARING, CONE, Inner |
| 3 | | 2 | Inner |
| 4 | C9NN1104D | 2 | HUB, , Previous |
| 4 | 82980396 | 2 | HUB, , Actual |
| 5 | 82971755 | 2 | BEARING, CONE, Inner |
| 6 | 81816580 | 12 | BOLT, , Previous |
| 6 | 82980463 | 12 | BOLT, , Actual |
| 7 | 82964608 | 2 | CUP, Outer |
| 7A | 83416242 | 2 | NIPPLE, LUBE, 1/8" |
| 8 | 82964614 | 2 | Outside |
| 9 | 81815739 | 12 | NUT, 1/2"-20 |
| 10 | C5NN1N195A | 2 | WASHER, |
| 11 | 387930S36 | 2 | NUT, 3/4"-16 |
| 12 | 86523851 | 2 | PIN,SPLIT (COTTER), 5/32" x 1-1/4" |
| 13 | C5NN1130A | 2 | COVER, CAP, |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

001 MAINFRAME, 716603006 - 32LA




PREVIEW YOUFIXTHIS.COM

When ordering either the bucket or lift cylinders check the 2 letter code on the cylinder before ordering.

Download full manual at youfixthis.com

004 HYDRAULICS - 716603006




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

11A01 ELECTRICAL WIRING HARNESS, MAIN FRONT, 4/6 CYL.




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

## Figure Search for TB110 4 CYL AG TRACTOR (12/02- )

11B01 ELECTRICAL WIRING HARNESS, FRONT LIGHTS, 4/6 CYL., NHNA/MEXICO
11C01 ELECTRICAL WIRING HARNESS, MAIN REAR, NHNA
11C02 ELECTRICAL WIRING HARNESS, MAIN REAR, MEXICO
11D01 ELECTRICAL WIRING HARNESS, REAR LIGHTS, 4/6CYL.
11E01 ELECTRICAL WIRING HARNESS, 4WD & DUAL POWER, 4/6 CYL., NHNA
11E02 ELECTRICAL WIRING HARNESS, 4WD & DUAL POWER, 4/6 CYL., MEXICO
11F01 HEADLAMP ASSEMBLY
11G01 ELECTRICAL, SWITCH & HORN
11G02 ELECTRICAL, SWITCHES
11H01 FLASHER LAMPS & SWITCHES, NHNA
11H02 FLASHER LAMPS & SWITCHES, MEXICO
11J01 BATTERY
11K01 STARTER MOTOR DRIVE & RELAY ASSEMBLY
11L01 ALTERNATOR ASSEMBLY
11M01 WORK LIGHT
12A01 PANELS, INSTRUMENTS
13A01 SEAT ASSEMBLY, COBO, DELUXE
13A02 SEAT ASSEMBLY, COBO, DELUXE
14A01 HOOD, SIDE LIGHTS AND PANEL ASSEMBLY
14A02 HOOD, FRONT GRILLE
14B01 HOOD, UPPER & REAR, RH & LH COVER
14C01 FENDER REAR, CROWN RH
14C02 PLATFORM
14C03 FENDER REAR, CROWN LH
14D01 FENDER REAR, FULL COVER, RH
14D02 BAFFLE, HEAT
14E01 HOOD, FENDER AND FRONT GRILLE
15A01 ROLLBAR ASSEMBLY & RELATED PARTS
16A01 DECALS, IDENTIFICATION
16B01 DECALS, CONTROL INSTRUCTION
16C01 DECALS, WARNING & SERVICE
16D01 DECALS, SERVICE, MEXICO
16D02 DECALS, SERVICE, NHNA
16E01 DECALS, TRANSMISSION SHIFT PATTERN
17A01 TOOL
17B01 INJECTOR OIL
17C01 PAINT
17D01 GREASE
17E01 OIL
17F01 SLOW MOVING VEHICLE SIGN

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TB110 4 CYL AG TRACTOR (12/02- )

05C01 LIFT CYLINDER

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | E9NN477AA | 1 | ACTUATOR, Cylinder & Valve Assy., Includes: Ref. 2 thru 20 |
| 1 | 82855327 | 1 | Cylinder & Valve Assy., Includes: Ref. 2 thru 20 |
| 2 | E0NN481HA | 1 | BUSHING, DRIVE, Blue/White |
| 2 | E0NN481JA | 1 | SPINDLE, White |
| 2 | E0NN481KA | 1 | RING, Blue |
| 2 | E0NN481LA | 1 | BUSHING, DRIVE, Yellow |
| 2 | E0NN481MA | 1 | BUSHING, Green |
| 2 | E0NN481NA | 1 | BUSHING, Orange |
| 2 | E0NN481PA | 1 | BUSHING, Green/White |
| 3 | F0NN488AA | 1 | VALVE, HYDRAULIC, White |
| 3 | F0NN488BA | 1 | VALVE, HYDRAULIC, Blue |
| 3 | F0NN488CA | 1 | VALVE, HYDRAULIC, Yellow |
| 3 | F0NN488DA | 1 | VALVE, HYDRAULIC, Green |
| 3 | F0NN488EA | 1 | VALVE, HYDRAULIC, Orange |
| 4 | E0NNB875BC | 1 | SLEEVE, |
| 5 | E4NN924BA | 1 | SPRING, |
| 6 | E0NN921CA | 1 | PLATE, |
| 7 | D5NN984A | 1 | VALVE, HYDRAULIC, |
| 8 | C5NNN917A | 1 | SEAL, |
| 9 | C5NNN855A | 1 | SPRING, |
| 10 | 82895237 | 1 | BALL, 1/4" |
| 11 | E0NNF947BA | 1 | PLUG, |
| 12 | 86512844 | 1 | O-RING, 90 Duro, .239" ID x .070" Thk |
| 13 | C5NNN858A | 1 | VALVE, HYDRAULIC, Blue/White |
| 13 | C5NNN858B | 1 | VALVE, HYDRAULIC, White |
| 13 | C5NNN858C | 1 | VALVE, HYDRAULIC, Blue |
| 13 | C5NNN858D | 1 | VALVE, HYDRAULIC, Yellow |
| 13 | C5NNN858E | 1 | VALVE, HYDRAULIC, Green |
| 14 | D3NN837A | 2 | RING, |
| 15 | E0NNR916AA | 1 | DIFFUSER, |
| 16 | F0NNR922AA | 1 | VALVE, HYDRAULIC, Includes: Ref. 17 thru 20 |
| 17 | 97608S | 1 | RING, |
| 18 | E0NNR940AA | 1 | SPACER, |
| 19 | 82001562 | 1 | PLUG, |
| 20 | E0NNF936AA | 1 | SPRING, |
| 21 | 83925618 | 1 | BOLT, 3/8"-16 x 3/4" |
| 22 | E1NNS864AB | 1 | FILTER, Filter, .361 |
| 23 | 9625178 | 1 | PLUG, |
| 24 | 9617873 | 1 | O-RING, 90 Duro, .468" ID x .078" Thk |
| 25 | D5NN530A | 1 | PISTON, |
| 26 | 83904858 | 1 | O-RING, |

PREVIEW.YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TB110 4 CYL AG TRACTOR (12/02- )

08B01 WATER PUMP AND RELATED PARTS

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | 87800122 | 1 | PUMP, WATER, With Threaded Pulley, Includes: Ref. 1A thru 12 |
| 1A | FAPN8A513HH | 1 | KIT, WATER PUMP REPAIR, With Threaded Single Pulley, Includes: Ref. 2 thru 8 |
| 2 | E8NN8512AA | 1 | IMPELLER, |
| 3 | 81870468 | 1 | GASKET, |
| 4 | 83943917 | 1 | BEARING, BALL, Single Pulley |
| 5 | NSS | 1 | NOT SERVICED SEPARATELY, Housing |
| 6 | 83959398 | 1 | GASKET, |
| 7 | E7NN8509AA | 1 | PULLEY, Single, w/Threads |
| 8 | E5NN8507AB | 1 | GASKET, |
| 9 | 81863678 | 1 | HOUSING, |
| 10 | 80681 | 4 | WASHER, LOCK, 5/16" |
| 11 | 88275 | 4 | SCREW, Cap, HH, G5, 5/16"-18 x 1-1/2" |
| 12 | 80781 | 1 | PLUG, Pipe, Sq Hd, 3/8"-18 |
| 13 | 12934 | 4 | SCREW, Cap, HH, G5, 7/16"-14 x 3" |
| 14 | 81547 | 4 | WASHER, LOCK, 7/16" |
| 15 | 82012728 | 2 | CLAMP, M50 - 70 |
| 16 | 83946457 | 1 | HOSE, FLEXIBLE, |
| 17 | 83957738 | 2 | BOLT, HH, 5/16"-18 x 2.88" |
| 18 | 87802272 | 1 | HOUSING, Thermostat |
| 19 | E9NN8255AA | 2 | GASKET, |
| 20 | 82016352 | 1 | SWITCH, THERMOSTATIC, |
| 21 | 83959426 | 1 | CONNECTOR, HYD., |
| 22 | 56521S36 | 2 | BOLT, Cap Flg Hd, G5, 5/16"-18 x 7/8" |
| 23 | 9712608 | 1 | SENDER UNIT, Water Temperature Indicator |
| 24 | FAPN8591DD | 1 | KIT, MISC, Repair, Single Pulley, Includes: Ref. 2 thru 4, 6 & 8 |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TB110 4 CYL AG TRACTOR (12/02- )

11M01 WORK LIGHT

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | 82985271 | 1 | LAMP, WORK, Work-Lamp Assy. |
| 2 | 82980476 | 1 | BRACKET, |
| 3 | E1ADKN16751 | 1 | GROMMET, |
| 4 | 280781 | 2 | SCREW, Cap, HH, G5, 1/4"-28 x 5/8" |
| 5 | 87361 | 2 | WASHER, SAE, 1/4" |
| 6 | 80682 | 2 | WASHER, LOCK, 1/4" |
| 7 | 86509309 | 2 | NUT, G5, 1/4"-28 |
| 8 | 88434 | 1 | SCREW, Cap, HH, G5, 3/8"-16 x 3/4" |
| 9 | 85700664 | 1 | WASHER, LOCK, 3/8" |
| 10 | | 1 | Ext T, 3/8" |
| 11 | 82936389 | 1 | NUT, 1/4" - 28 |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

33LA FARM LOADER (11/98- )

006 HYDRAULICS, MSL - 716604016

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | SML412333 | 2 | Hose, 3/8x74" |
| 2 | SML412334 | 2 | Hose, 3/8x52" |
| 3 | SML412335 | 2 | Hose, 3/8x18" |
| 4 | 86581674 | 2 | Hose, 3/8x30" |
| 5 | SML464873 | 4 | Hose, 3/8x80" |
| 6 | SML46690 | 1 | Tube, Oil Line (LCB) |
| 7 | SML46689 | 1 | Tube, Oil Line (LCR) |
| 8 | SML46688 | 1 | Tube, Oil Line (TCR) |
| 9 | SML46687 | 1 | Tube, Oil Line (TCB) |
| 10 | SML61376 | 4 | Fitting, Adapter, Coupling, Male |
| 11 | SML3485325 | 1 | Sleeve, Nylon, 68" |
| 12 | 86581682 | 1 | Band, Blue, 3/4" |
| 13 | 86581683 | 1 | Band, Red, 3/4" |
| 14 | 86581684 | 1 | Band, Yellow, 3/4" |
| 15 | 86581685 | 1 | Band, Green, 3/4" |
| 16 | 86581686 | 1 | Cap, Dust, Blue |
| 17 | 86581687 | 1 | Cap, Dust, Red |
| 18 | 86581688 | 1 | Cap, Dust, Yellow |
| 19 | 86581689 | 1 | Cap, Dust, Green |
| 20 | 86581690 | 1 | Band, Blue, 1" |
| 21 | 86581691 | 1 | Band, Red, 1" |
| 22 | 86581692 | 1 | Band, Yellow, 1" |
| 23 | 86581693 | 1 | Band, Green, 1" |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

46LB AG LOADER (11/02- )

008 HOSE KIT, THIRD FUNCTION

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | 86582398 | 1 | BULKHEAD, |
| 2 | 88946 | 2 | SCREW, SELF TAPPING, HH, 1/4" x 3/4" |
| 3 | 86582400 | 6 | STRAP, |
| 4 | SML474223 | 2 | 3/8" x 264" |
| 5 | 86582377 | 2 | ADAPTER, Bulkhead Union, O-Ring, 3/4"-16 |
| 6 | 86582402 | 1 | COUPLING, Female |
| 7 | 86582403 | 1 | COUPLING, Male |
| 8 | 248974 | 2 | ELBOW, 90°, 3/4"-16, Swivel Nut |
| 9 | 86582405 | 1 | DUST CAP, 1-1/2" |
| 10 | 86582406 | 1 | DUST CAP, 1" |
| 11 | 86581687 | 1 | COVER, Red |
| 12 | 86581686 | 1 | COVER, Blue |
| 13 | 86581680 | 2 | CONNECTOR, HYD., Male |
| 14 | 86581691 | 1 | BAND, Red, 1" |
| 15 | 86581690 | 1 | BAND, Blue, 1" |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

52LA FARM LOADER (5/99- )

08 BUCKETS, QUICK ATTACH

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | W0 | 1 | Bucket, 72", Standard |
| 1 | W0 | 1 | Bucket, 60", Heavy Duty |
| 1 | W0 | 1 | Bucket, 72", Heavy Duty |
| 1 | W0 | 1 | Bucket, 84", Heavy Duty |
| 1 | W0 | 1 | Bucket, 84", High Volume |
| 2 | SML280861 | 1 | Edge, Cutting, Left Side, Heavy Duty |
| 2 | SML328171 | 1 | Edge, Cutting, Left Side, 72" Standard & 84" High Volume |
| 3 | SML225425 | 1 | Edge, Cutting, Bottom, 72" Standard ( No Holes ) |
| 3 | SML467343 | 1 | Edge, Cutting, Bottom, 60" Heavy Duty |
| 3 | SML467341 | 1 | Edge, Cutting, Bottom, 72" Heavy Duty |
| 3 | SML467342 | 1 | Edge, Cutting, Bottom, 84" Heavy Duty |
| 3 | SML225428 | 1 | Edge, Cutting, Bottom, 84" High Volume ( No Holes ) |
| 4 | SML280862 | 1 | Edge, Cutting, Right Side, Heavy Duty |
| 4 | SML328172 | 1 | Edge, Cutting, Right Side, 72" Standard & 84" High Volume |
| 5 | 86582385 | 2 | Decal, Reflective, White, Alignment, 14" |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PLUMBING LOADER CONTROL VALVE TO TRACTOR HYDRAULICS

NOTE: ROUTE TANK HOSE (19) TO TANK PORT ON OTHER SIDE OF TRACTOR REGARDLESS OF WHETHER CONTROL VALVE IS TO BE PLUMBED TO HYDRAULIC MANIFOLD OR TO TRACTOR REMOTES.




NOTE: WHEN TRACTOR IS EQUIPPED WITH TWO PUMP MID MOUNT HYDRAULIC KIT (8651162) HOSES (1 & 19) ARE USED DIFFERENTLY AND HOSE (3) IS DISCARDED. SEE INSTRUCTIONS IN THAT KIT FOR PROPER HOSE INSTALLATION.

TRACTOR TANK PORT AND REMOTES




HYDRAULIC PRESSURE TAPPING MANIFOLD




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

026 CONTROL VALVE MOUNTING, 715806002 & 715808002




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

045B PALLET FORK, PIN-ON-9863276




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

7310 QUICK ATTACH FARM LOADER (10/93- )

013 CYLINDER, BUCKET, 9861953 - SERIES 7310

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| | SML41504 | 2 | Cylinder, Bucket, Code JL Includes: Ref. 1 thru 14 |
| 1 | SML41506 | 1 | Rod, Cylinder |
| 2 | NSS | 1 | Seal, Wiper, These Parts are in Repair Kit - SML-41555 |
| 3 | NSS | 1 | Seal, Rod, These Parts are in Repair Kit - SML-41555 |
| 4 | SML41488 | 1 | Head, Cylinder |
| 5 | NSS | 1 | Ring, Wear, These Parts are in Repair Kit - SML-41555 |
| 6 | NSS | 1 | Washer, Backup, These Parts are in Repair Kit - SML-41555 |
| 7 | NSS | 1 | O-Ring, These Parts are in Repair Kit - SML-41555 |
| 8 | NSS | 1 | Seal, Piston, These Parts are in Repair Kit - SML-41555 |
| 9 | NSS | 1 | O-Ring, These Parts are in Repair Kit - SML-41555 |
| 10 | SML35519 | 1 | Piston |
| 11 | NSS | 1 | Ring, Wear, These Parts are in Repair Kit - SML-41555 |
| 12 | 514101 | 1 | Nut, Lock, G8, 1"-14 |
| 13 | SML41508 | 1 | Tube, Cylinder |
| 14 | NSS | 1 | Wire, Retainer, These Parts are in Repair Kit - SML-41555 |
| | SML41555 | 1 | Kit, Repair |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

7312 QUICK ATTACH FARM LOADER (4/96- )

013 HOSE KIT - 9607331

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | SML368456 | 4 | Hose, 1/2 x 216 |
| 2 | 86581718 | 1 | Strap, Rubber |
| 3 | 86582400 | 4 | Strap, Plastic Tie, 11 |
| 4 | 86581720 | 2 | Strap, Plastic Tie, 20 |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

7312 QUICK ATTACH FARM LOADER (4/96- )

043 BUCKETS

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | W0 | AR | Bucket, Material, 84" {9607319} |
| 1 | W0 | AR | Bucket, Snow, 108", Includes: Bucket Plus: Ref. 1 thru 3 {9801386} |
| 1 | SML328171 | 1 | Edge, Cutting Left Side, 9607349 |
| 1 | SML280861 | 1 | Edge, Cutting Left Side, 9801386 |
| 2 | SML225433 | 1 | Edge, Cutting Bottom, 84", 9607319 |
| 2 | SML389452 | 1 | Edge, Cutting Bottom, 108", 9801386 |
| 3 | SML328172 | 1 | Edge, Cutting Right Side, 9607319 |
| 3 | SML280862 | 1 | Edge, Cutting Right Side, 9801386 |
| 3 | W0 | AR | Bucket, Heavy Duty Material, 96", Includes: Bucket Plus: Ref. 4 thru 6 {9801385} |
| 4 | SML280861 | 1 | Edge, Cutting Left Side, 9801385 |
| 5 | SML389451 | 1 | Edge, Cutting Bottom 96", 9801385 |
| 6 | SML280862 | 1 | Edge, Cutting Right Side, 9801385 |
| 6 | W0 | AR | Bucket, Manure, 72", Includes: Bucket Plus: Ref. 7 thru 12 {9607323} |
| 7 | PL | 2 | Bolt, HH, 1/2" - 13 x 1 |
| 8 | PL | 11 | Nut, Lock, 1/2" - 13 |
| 9 | SML37052 | 1 | Plate, Dirt |
| 10 | SML28154 | 9 | Tine, 1-1/4" Sq. x 33-1/4" |
| 11 | PL | 9 | Bolt, HH, 1/2"-13 x 2 |
| 12 | PL | 2 | Washer, Flat, 1/2" |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

**Figure 4**
**Alternate**
**Plumbing Control Valve**
**to Single Set of**
**Rear Remotes**




Older 40 Series




Flat Deck Only




Straddle Deck Only

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

INSTALLING CONTROL VALVE TO TRACTOR




731219.cdr

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

7314 QUICK ATTACH FARM LOADER (4/96- )

051 GRAPPLE FORK MOUNTING BRACKET - 9863772

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | NS | 1 | Bracket, Right (not available as repair part) order 9863772 |
| 2 | NS | 1 | Bracket, Left (not available as repair part) order 9863772 |
| 3 | PL | 4 | Washer, Hinge |
| 4 | PL | 4 | Screw, Cap, 3/4-10 x 1-1/2 |
| 5 | PL | 4 | Nut, Lock, 3/4 |
| 6 | PL | 4 | Screw, Cap, 5/8-11 x 1-1/2 |
| 7 | PL | 4 | Nut, Lock |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

7511 FARM LOADER (2/98- )

003 MOUNTING KIT - 715834006 - FOR MODELS 5640, 6640 & 7740 WITH FWD

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | SML40610 | 1 | Bracket, Front |
| 2 | SML40627 | 1 | Bracket, Midmounting, Left |
| 3 | SML40626 | 1 | Bracket, Midmounting, Right |
| 4 | PL | 4 | Washer, Flat, 3/4" |
| 5 | SML46171 | 1 | Yoke, Front |
| 6 | SML40688 | 1 | Bracket, Lower Step |
| 7 | SML40660 | 1 | Step, Upper |
| 8 | SML258203 | 2 | Tread, Anti-Slip Surface |
| 9 | 88725 | 16 | Screw, Cap, HH, G5, 3/4"-10 x 1-3/4" |
| 10 | 88692 | 9 | Screw, Cap, HH, G5, 3/4"-10 x 1-1/2" |
| 11 | 86837544 | 1 | Screw, Cap, 3/4-10x4" |
| 12 | 9707515 | 2 | Screw, Cap, HH, G5, 5/16"-18 x 1-3/4" |
| 13 | 87340 | 26 | Washer, Lock, 3/4" |
| 14 | 9635082 | 2 | Nut, G5, 5/16"-18 |
| 15 | 88556 | 4 | Screw, Cap, HH, G5, 5/8"-11 x 2-1/4" |
| 16 | SML39240 | 2 | Decal, Saftey |
| 17 | 280173 | 4 | Screw, Cap, HH, G5, 3/4"-10 x 2-3/4" |
| 18 | 280375 | 4 | Nut, Lock, GC, 3/4"-10 |
| 19 | 87365 | 4 | Washer, SAE, 5/8" |
| 20 | 86729275 | 4 | Washer, Lock, 5/8" |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

7511 FARM LOADER (2/98- )

032 CONTROL VALVE PLUMBING TO SINGLE SET OF REAR REMOTES - 715806002

| Ref | Part Number | Qty | Description |
|---|---|---|---|
| 1 | 325059 | 1 | Connector, Male, 7/8"-14, Flare x 7/8"-14, W/O-Ring |
| 2 | 182977 | 1 | Fitting, Elbow, 7/8-14 JIC Swivel x 7/8-14 JIC x 90 Degree |
| 3 | 86512933 | 1 | Elbow, 7/16"-20 x 7/16"-20 Flare x 90° |
| 4 | SML406551 | 1 | Fitting, Run Tee, 1-14x1-14x1-14 Face Seal |
| 5 | 9840541 | 1 | Elbow, 7/16-20 O-Ring x 9/16-18 Face Seal |
| 6 | SML40639 | 1 | Fitting, Tank Port, Rear Axle |
| 7 | SML40777 | 1 | Valve, Shuttle |

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

# PREVIEW ONLY

You're viewing 24 of 1232 pages

## The full manual includes:

- All 1232 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

**New Holland TB110, 32LA, 33LA, 46LB, 52LA, 7210, 7310, 7312, 7314, 7511, TB110 4 CYL AG Parts Catalog**

**Scan or click anywhere**
**youfixthis.com**

*Click anywhere on this page to get the full manual*