How To Use Figure Search

1). Locate the figure list index at the beginning of manual

examples:

01A01 FRONT WHEEL ASSEMBLY - 2100,2110,2120,2150,2300,2310,3055,3100,3120,3150,3190,3300,3310,3550,4140

01A01[C] FRONT WHEEL ASSEMBLY, W/16" WHEELS - 3400, 3500, 3550, 4400, 4500, 4410, 5100, 5200, 5190, 7100, 7200

01B01 STANDARD REAR WHEELS - 2000, 4100 & 3000 EXCEPT 3550

01B01[A] STANDARD REAR WHEELS - 3500, 3550, 5000, 7000, 4000 EXCEPT 4110

01B02 POWER ADJUSTABLE REAR WHEELS - 2000, 3000, 4140

Use the “search” feature in adobe to jump to the figure number.

Press **Ctrl** key, and letter **F** on the keyboard, at the same time. This will bring up the “search” feature in Adobe Acrobat. Then simply type in the figure number you wish to locate, and press enter.

Adobe takes you immediately to that page!

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

Figure Search for TJ275 TRACTOR

01 -01 HYDRAULIC PICTORIAL INDEX - TRANSMISSON AND PTO CLUTCH LUBRICATION, MANUAL SHIFT TRANSMISSION
01 -02 HYDRAULIC PICTORIAL INDEX - TRANSMISSION AND PTO CLUTCH LUBRICATION, POWER SHIFT TRANSMISSION
01 -03 HYDRAULIC PICTORIAL INDEX - STEERING CIRCUIT
01 -04 HYDRAULIC PICTORIAL INDEX - AXLE LUBRICATION CIRCUIT
01 -05 HYDRAULIC PICTORIAL INDEX - CHARGE PUMP AND BRAKE CIRCUIT
01 -06 HYDRAULIC PICTORIAL INDEX - CHARGE PUMP AUXILIARY REMOTE CIRCUIT, STANDARD HYDRAULICS
01 -07 HYDRAULIC PICTORIAL INDEX - CHARGE PUMP AUXILIARY REMOTE CIRCUIT, HIGH OUTPUT HYDRAULICS
01 -08 HYDRAULIC PICTORIAL INDEX - MANUAL HITCH
01 -09 HYDRAULIC PICTORIAL INDEX - ELECTRONIC HITCH
01 -10 HYDRAULIC PICTORIAL INDEX - POWER TAKEOFF TRANSFER CASE LUBRICATION
02 -01 RADIATOR PLUMBING
02 -02 RADIATOR MOUNTING - TJ275
02 -04 ETHER START SYSTEM
02 -05 AIR INTAKE
02 -06 AIR COOLER - MOUNTING (TJ275)
02 -08 AIR CLEANER ASSY
02 -09 BLOCK HEATER
02 -10 ENGINE MOUNTING
02 -11 WATER PUMP SYSTEM - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -12 FRONT GEAR COVER - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -13 MANIFOLDS - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -14 TURBOCHARGER SYSTEM - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -15 TURBOCHARGER ASSY - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -16 WASTEGATE ACTUATOR - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -17 FILTER AND COOLER - OIL 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -18 OIL PUMP AND OIL PAN - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -19 CYLINDER HEAD - COVER (6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE)
02 -20 CYLINDER HEAD - VALVE MECHANISM (6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE)
02 -21 THERMOSTAT - FILTER, WATER (6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE)
02 -22 CRANKCASE, BREATHER - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -23 CAMSHAFT - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -24 CYLINDER BLOCK - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE (6TAA-8304)
02 -25 CRANKSHAFT - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -26 FLYWHEEL
02 -27 PISTONS - CONNECTING RODS
02 -28 VALVE GRIND KIT - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
02 -29 CLYLINDER BLOCK GASKET KIT - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE
03 -01 THROTTLE - DECELARATOR CONTROL
03 -02 EXHAUST SYSTEM
03 -03 FUEL LINES
03 -04 THROTTLE
03 -05 FUEL INJECTION SYSTEM
03 -06 PUMP, FUEL TRANSFER
03 -07 FUEL FILTER AND CONNECTIONS
03 -08 FUEL INJECTION PUMP
03 -09 FUEL INJECTION PUMP
03 -10 FUEL INJECTION PUMP
03 -11 FUEL INJECTION PUMP


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Figure Search for TJ275 TRACTOR

06 -02[1] TRANSMISSION SHIFT CONTROLS, MANUAL SHIFT TRANSMISSION
06 -02[2] SHIFTER BOX
06 -03 WHEELS - SINGLE AND DUALS WITH SPACERS
06 -04 HUB ASSEMBLY
06 -05[1] TRANSMISSION MOUNTING - MANUAL SHIFT
06 -05[2] TRANSMISSION MOUNTING - POWER SHIFT
06 -06[1] TRANSMISSION - LUBRICATION, MANUAL SHIFT
06 -06[2] TRANSMISSION - LUBRICATION, POWER SHIFT
06 -08[1] POWER TAKEOFF - CLUTCH LUBRICATION, MANUAL SHIFT TRANSMISSION
06 -08[2] POWER TAKEOFF - CLUTCH LUBRICATION, POWER SHIFT TRANSMISSION
06 -09[01] MANUAL SHIFT TRANSMISSION - VALVE ASSY MOUNTING
06 -09[02] MANUAL SHIFT TRANSMISSION - COVERS AND YOKES
06 -09[03] MANUAL SHIFT TRANSMISSION - REAR HOUSING
06 -09[04] MANUAL SHIFT TRANSMISSION - FRONT HOUSING AND SHIFT LEVERS
06 -09[05] MANUAL SHIFT TRANSMISSION - SHAFT ASSY AND SHIFTER FORKS
06 -09[06] MANUAL SHIFT TRANSMISSION - SHIFTER FORKS
06 -09[07A] MANUAL SHIFT TRANSMISSION - INPUT SHAFT ASSY
06 -09[07B] MANUAL SHIFT TRANSMISSION - INPUT SHAFT ASSY
06 -09[08] MANUAL SHIFT TRANSMISSION - SECOND SHAFT ASSY.
06 -09[09] MANUAL SHIFT TRANSMISSION - THIRD SHAFT ASSY.
06 -09[10] MANUAL SHIFT TRANSMISSION - FOURTH SHAFT ASSY
06 -09[11] MANUAL SHIFT TRANSMISSION - FIFTH SHAFT ASSY
06 -09[12] MANUAL SHIFT TRANSMISSION - CONTROL VALVE ASSY.
06 -09[13] MANUAL SHIFT TRANSMISSION - LOCKOUT VALVE ASSY.
06 -09[14] MANUAL SHIFT TRANSMISSION - REGULATOR VALVE ASSY.
06 -10[01] POWER SHIFT TRANSMISSION - VALVE AND PUMP MOUNTING
06 -10[02] POWER SHIFT TRANSMISSION - COVERS AND YOKES
06 -10[03] POWER SHIFT TRANSMISSION - REAR HOUSING
06 -10[04] POWER SHIFT TRANSMISSION - HOUSING AND CLUTCHES
06 -10[05] POWER SHIFT TRANSMISSION - REGULATOR VALVE ASSY.
06 -10[06] POWER SHIFT TRANSMISSION - RANGE SELECTOR VALVE
06 -10[07] VALVE ASSY PULSE WITH MODULATION
06 -10[08] VALVE ASSY POWER TAKE OFF
06 -10[09A] POWER SHIFT TRANSMISSION - INPUT SHAFT ASSY
06 -10[09B] POWER SHIFT TRANSMISSION - INPUT SHAFT ASSY
06 -10[10] POWER SHIFT TRANSMISSION - SECOND SHAFT ASSY
06 -10[11] POWER SHIFT TRANSMISSION - THIRD SHAFT ASSY
06 -10[12A] POWER SHIFT TRANSMISSION - FOURTH SHAFT ASSY
06 -10[12B] POWER SHIFT TRANSMISSION - FOURTH SHAFT ASSY
06 -10[13A] POWER SHIFT TRANSMISSION - FIFTH SHAFT ASSY
06 -10[13B] POWER SHIFT TRANSMISSION - FIFTH SHAFT ASSY
06 -27 DRIVE SHAFTS AND MOUNTING
06 -28 DRIVE SHAFT ASSY
06 -31 POWER TAKEOFF - DRIVE SHAFT MOUNTING
06 -32 POWER TAKEOFF ASSEMBLIES
06 -33 POWER TAKEOFF LUBRICATION, BSN RVS001801
06 -33[01] POWER TAKEOFF LUBRICATION, ASN RVS001801
06 -34 COUPLER MOUNTS - WITHOUT POWER TAKEOFF AND THREE POINT HITCH

PREVIEW. YOUFIXTHIS.COM

Download full manual at youfixthis.com


02 -06 AIR COOLER - MOUNTING (TJ275)



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

02 -23 CAMSHAFT - 6TAA-8304 / 6TAA-9004 EMISSIONS CERTIFIED ENGINE



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TJ275 TRACTOR

04 -10 RADIO AND SPEAKERS

Ref	Part Number	Qty	Description
1	366631A2	1	RADIO, AM / FM / WB
1	355623A2	1	RADIO, AM / FM / WB / Cassette
1	325061A2	1	RADIO, AM / FM / WB / Cassette / CD
1	86998223	1	Delco, AM / FE/ WB/ Single CD
2	258342A2	2	SPEAKER, Co-Axial
3	388445A1	1	HOUSING, Subwoofer
4	360215A1	1	ANTENNA,
5	388444A1	1	SPEAKER, Subwoofer, 8
6	86639120	4	SCREW, M4,2 x 19, Australian Models
7	86505868	4	NUT, LOCK, Flg, USR, M8 x 1.25
8	177269A1	8	NUT, Special
9	1270741C1	8	SCREW, Pointed
10	360432A2	1	HARNESS, Antenna, Includes : 11
11	NSS	1	NOT SERVICED SEPARATELY, Grommet
12	317688A1	1	ELECTRONIC UNIT, CONTROL, Delco, 6 Disc
13	86624181	1	WASHER, 6,6 x 12 x 1,6 mm
14	86625265	1	WASHER, LOCK, M6
15	86639137	1	SCREW, M6,3 st x 13
16	1535219C1	1	COVER, , Without Radio
17	303433A1	1	HARNESS, CD Changer, 3048 mm (120 in), if used
17	449071A1	1	HARNESS, WIRE, CD Changer, 5486 mm (216 in), if used
18	388489A1	1	CLIP,
19	86625213	3	SCREW, Socket, M5 x 12
20	334229A1	1	KIT, SERVICE, AM / FM / WB / Cassette / CD, Includes : 1, 2, 8, 9
21	186158A1	1	KIT, SERVICE, AM / FM / WB, Includes : 1, 2, 8, 9
22	719582003	1	Single CD Player / Radio

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TJ275 TRACTOR

04 -27 HARNESS - CAB ROOF

Ref	Part Number	Qty	Description
1	373457A1	1	HARNESS,
2	245483C1	2	CONNECTOR, HYD., Two Cavity, Used Without Field Lights
3	225127C1	4	TERMINAL CONNECTOR, Type V4
4	408658A1	2	DECAL, , Used Without Field Lights

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

05 -18 TRANSMISSION CONTROL ASSY. - POWER SHIFT TRANSMISSION

Ref	Part Number	Qty	Description
	86991898	1	CONTROL, Consists Of : 1 - 3, 5 -16, 17-19, With Self Cancel
	360058A2	1	CONTROL, Consists Of : 1, 2, 4 - 15, 16-19, Without Self Cancel
1	325362A1	1	CHASSIS,
2	325065A1	1	HOUSING, Lower
3	284777A1	1	SWITCH, , With Self Cancel
4	284776A1	1	SWITCH,IGNITION, , Without Self Cancel
5	86991897	1	SWITCH,IGNITION, FNRP, Without Nuetral Start
6	86585706	7	SCREW, Pan Hd, CL 4.8, M4 x .7 x 10
7	325064A1	1	HOUSING, Upper
8	303466A1	1	LENS, RH
9	303467A1	1	LENS, LH
10	86639307	7	WASHER, Lock, M4
11	325363A1	1	LEVER,
12	250939A1	1	SPRING,
13	325068A1	1	BELLOWS,
14	325066A2	1	GUARD,
15	303465A2	1	LAMP, Flasher
15	404053A1	1	LIGHT ASSY., Flasher, Without Self Cancel
16	375681A1	1	SENSOR, Not Illustrated, With Self Cancel
16	303463A1	1	HARNESS, Not Illustrated, Without Self Cancel
17	325533A1	1	KNOB,
18	905974R1	2	SCREW,
19	358353A1	1	SYMBOLS,
20	435437A1	1	STRAP, 7 in
21	392699A1	1	FASTENER,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Ref	Part Number	Qty	Description
34	427519A1	AR	SHIM, 0,30 mm (0,012 in)
35	428165A1	2	O-RING,
36	427552A1	1	YOKE, 7C, Output, TJ275
36	427551A1	1	YOKE, 8C, Output, TJ325
37	427549A1	1	RING, PRESSURE,
38	427514A1	2	SEAL, OIL,
39	427563A1	1	RETAINER, Output
40	427547A1	1	GASKET, Mounting
41	373135A1	1	YOKE, 7C, Output, TJ275
41	373138A1	1	YOKE, 8C, Output, TJ325
42	427558A1	1	COVER, Power Takeoff
43	303493A1	2	PLUG, Drain, M42 orb x 2, Includes : 44
44	86639047	2	O-RING, 1-1/2 ID x 7/64
45	375456A1	1	PLUG, MAGNETIC, M42 orb x 2, Includes : 46
46	86639047	1	O-RING, 1-1/2 ID x 7/64
47	220064A1	3	PLUG, M14 - 1,5, Includes : 50
48	86639042	3	GASKET, 11,3 ID x 2,2
49	428181A1	3	SCREW,
50	428180A1	6	BOLT, M10 x 35
51	86637972	1	BOLT, M12 x 20; 8.8
52	86637967	2	BOLT, M10 x 45; 8.8
53	86637964	4	BOLT, M10 X 50; 8.8
54	16043224	2	SCREW, Cap, HH, CL 8.8, M8 x 1.25 x 16
55	86637970	6	BOLT, M12 x 35; 8.8
56	86637974	4	BOLT, M12 x 25; 8.8
	178889A1	2	FITTING, Diagnostic, Includes : 57, 58
57	H434163	1	CAP, Dust
58	NSS	1	NOT SERVICED SEPARATELY, Fitting, Includes : 59
59	86639042	1	GASKET,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Ref	Part Number	Qty	Description
29	86637974	4	BOLT, M12 x 25
30	86625261	1	WASHER, 5,5 x 10 x 1 mm
31	375450A1	1	O-RING, Filter
32	87408706	1	FILTER, Pulse With Modulation
33	427515A1	2	WASHER, SPECIAL,
34	427517A1	AR	SHIM, 0,10 mm (0,004 in)
34	427519A1	AR	SHIM, 0,30 mm (0,012 in)
35	428165A1	2	O-RING,
36	373134A1	1	COUPLING FLANGE, 7C, Output, TJ275
36	373137A1	1	COUPLING FLANGE, 8C, Output, TJ325
37	362601A1	1	O-RING,
38	427514A1	2	SEAL, OIL,
39	362602A1	1	RETAINER, Output
40	362603A1	1	GASKET, Mounting
41	373135A1	1	YOKE, 7C, Output, TJ275
41	373138A1	1	YOKE, 8C, Output, TJ325
42	427558A1	1	COVER, Power Takeoff
43	303493A1	2	PLUG, Drain, M42 orb x 2, Includes : 44
44	86639047	2	O-RING, 1-1/2 ID x 7/64
45	375456A1	1	PLUG, MAGNETIC, M42 orb x 2, Includes : 46
46	86639047	1	O-RING, 1-1/2 ID x 7/64
47	220064A1	9	PLUG, M14 - 1,5, Includes : 50
48	86639042	9	GASKET, 11,3 ID x 2,2
49	86642441	2	BOLT,
50	86637966	24	SCREW, M10 x 35
51	140028	6	WASHER, Lock, M10
52	412159	2	SCREW, M10 x 25
53	86642434	4	BOLT, M10 x 60
54	120106	2	SCREW, Cap, HH, CL 8.8, M8 x 1.25 x 40
55	86642438	6	BOLT,
	178889A1	2	FITTING, Diagnostic, Includes : 56, 57
56	120106	1	SCREW, Cap, HH, CL 8.8, M8 x 1.25 x 40
57	NSS	1	NOT SERVICED SEPARATELY, Fitting, Includes : 62
62	86639042	1	GASKET, 11,3 ID x 2,2
63	86637971	2	SCREW, M12 x 30; 8,8
	398441A1	1	KIT, GASKET, Short Gasket Overhaul Kit, Includes : 9, 16, 18, 20, See Figure(s) : 06-10 (01) - 06-10 (06)
	398440A1	1	SEAL, Transmission Repair, Includes : 5, 7, 9, 16, 18, 20, 21, See Figure(s) : 06-10 (01) - 06-10 (13B)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TJ275 TRACTOR


06 -28 DRIVE SHAFT ASSY

Ref	Part Number	Qty	Description
	402171A1	1	SHAFT, DRIVE, Input, Consists Of : 1 - 5, With Manual Shift Transmission, TJ275
	402178A1	1	SHAFT, DRIVE, Input, Consists Of : 1 - 5, With Manual Shift Transmission, TJ325
	402170A1	1	SHAFT, DRIVE, Input, Consists Of : 1 - 5, With Power Shift Transmission, TJ275
	402177A1	1	SHAFT, DRIVE, Input, Consists Of : 1 - 5, With Power Shift Transmission, TJ325
1	NSS	1	NOT SERVICED SEPARATELY, Shaft, Slip Yoke
2	NSS	1	NOT SERVICED SEPARATELY, Shaft, Flanged
3	337476	4	SCREW, Cap, HH, CL 10.9, M12 x 1.75 x 50
4	411524A1	1	SEAL, , TJ275
4	404151A1	1	SEAL, , TJ325
5	431620A1	1	SPIDER ,U-JOINT, 7C, TJ275
5	431621A1	1	SPIDER ,U-JOINT, 8C, TJ325
	402173A1	1	SHAFT, DRIVE, Front Axle, Consists Of : 6 - 8, TJ275
	402180A1	1	SHAFT, DRIVE, Front Axle, Consists Of : 6 - 8, TJ325
6	NSS	1	NOT SERVICED SEPARATELY, Shaft
7	337476	8	SCREW, Cap, HH, CL 10.9, M12 x 1.75 x 50
8	431620A1	2	SPIDER ,U-JOINT, 7C, TJ275
8	431621A1	2	SPIDER ,U-JOINT, 8C, TJ325
	402175A1	1	SHAFT, DRIVE, Articulation, Consists Of : 9 - 11, TJ275
	402182A1	1	SHAFT, DRIVE, Articulation, Consists Of : 9 - 11, TJ325
9	NSS	1	NOT SERVICED SEPARATELY, Slip Yoke
10	337476	8	SCREW, Cap, HH, CL 10.9, M12 x 1.75 x 50
11	431620A1	2	SPIDER ,U-JOINT, 7C, TJ275
11	431621A1	2	SPIDER ,U-JOINT, 8C, TJ325
12	411524A1	1	SEAL, , TJ275
12	404151A1	1	SEAL, , TJ325
	402176A1	1	SHAFT, DRIVE, Rear Axle, Consists Of : 13 - 18, TJ275
	402183A1	1	SHAFT, DRIVE, Rear Axle, Consists Of : 13 - 18, TJ325
13	NSS	1	NOT SERVICED SEPARATELY, Shaft
14	337476	4	SCREW, Cap, HH, CL 10.9, M12 x 1.75 x 50
15	431620A1	1	SPIDER ,U-JOINT, 7C, TJ275
15	431621A1	1	SPIDER ,U-JOINT, 8C, TJ325
16	404451A1	1	YOKE, 7C, TJ275
16	411525A1	1	YOKE, 8C, TJ325
17	86637815	1	WASHER,
18	86637649	1	NUT,
19	409684A1	1	BEARING, Support, Pillow Block, TJ275
19	451767A1	1	BEARING, Support, Pillow Block, TJ325

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

06 -45 AXLE ASSY - BRAKE AND RIGHT-HAND CARRIER



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TJ275 TRACTOR

08 -08 AXLE HYDRAULICS - LUBRICATION CIRCUIT, BSN RVS001801

Ref	Part Number	Qty	Description
1	86579678	1	FITTING, 13/16 fc sl x 22 or, Includes : 2, 3
2	9992298	1	O-RING, 90 Duro, .489" ID x .070" Thk
3	86639044	1	O-RING, 19,3 ID x 2,2 mm
4	360201A4	1	HOSE ASSY., 1925 mm (75-1/2 in)
5	348357A1	1	HOSE ASSY., 1903mm (90 in)
6	43234	2	SCREW, Cap, HH, CL 10.9, M8 x 1.25 x 25
7	416278A1	1	TUBE ASSY.,
8	86639083	2	NUT, Lock, 13/16 in
9	507586	6	CLAMP, No. 20
10	337545A1	2	CONNECTOR, HYD., Axle Drain
11	370250A1	1	HOSE, 990 mm (39 in), Cut From : S118383
12	416280A1	1	TUBE ASSY.,
13	327491A1	1	HOSE ASSY., 660 mm (26 in), Cut From : 443082A1
14	437170A1	1	HOSE, 1219mm (48 in), Cut From : 443082A1
15	406045A1	1	HOSE ASSY., 394 mm (15-1/2 in)
16	411104A1	1	VALVE, HYDRAULIC, Regulator, See Figure(s) : 08-15
17	86579675	1	CONNECTOR, HYD., 13/16 fc sl x M16 Or, Includes : 18, 19
18	9992298	1	O-RING, 90 Duro, .489" ID x .070" Thk
19	86642449	1	O-RING, 13,3 ID x 2,2
20	413338A1	1	TUBE ASSY.,
21	413334A1	1	TUBE ASSY.,
22	86579676	1	CONNECTOR, HYD., 13/16 fc sl x 18 Or, Includes : 23, 24
23	9992298	1	O-RING, 90 Duro, .489" ID x .070" Thk
24	86639043	1	O-RING, 15,3 ID x 2,2
25	413327A1	1	TUBE ASSY.,
26	86639080	1	TEE, M12 fc sl x blkhd fc sl, Includes : 27
27	9992298	3	O-RING, 90 Duro, .489" ID x .070" Thk
28	86639061	1	CONNECTOR, HYD., 13/16 fc sl x blkhd, Includes : 29
29	9992298	2	O-RING, 90 Duro, .489" ID x .070" Thk
30	86624184	11	WASHER, 9 x 17 x 1,6 mm
31	43362	10	NUT, CL 10, M8 x 1.25
32	86637998	2	CLAMP, 1-1/2 ID
33	435468A1	3	PLATE, COVER,
34	86639058	1	TEE, 13/16 fc sl x 22 orb, Includes : 35, 36
35	86639044	1	O-RING, 19,3 ID x 2,2 mm
36	9992298	2	O-RING, 90 Duro, .489" ID x .070" Thk
37	86637976	1	CLAMP, 3/4 ID
38	S120426	1	HOSE,PROTECTION, Protective
39	L18337	2	STRAP, 15 in
40	435470A1	6	CLAMP,
41	416512A1	1	PLATE,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Ref	Part Number	Qty	Description
41	84989392	1	CONNECTOR, HYD., 90, 11/16 fc sl x swl, Includes : 42
42	9993141	1	O-RING, 90 Duro, .364" ID x .070" Thk
43	43234	1	SCREW, Cap, HH, CL 10.9, M8 x 1.25 x 25
44	327471A1	1	HOSE ASSY., 724 mm (28 in)
45	363294A1	1	VALVE, Priority, See Figure(s) : 08-25
46	86639084	1	NUT, Lock, M25
47	86516395	2	SCREW, M8 x 90; 10.9
48	86639054	1	ELBOW, 45, 1-7/16 fc sl x 33 orb, Includes : 49, 50
49	86639046	1	O-RING, 29,6 ID x 2,9
50	9824050	1	O-RING, 90 Duro, .926" ID x .070" Thk
51	86579697	1	ROD, CONNECTING, 90, 1-3/16 fc sl x 27 Or, Includes : 52, 53
52	86639045	1	O-RING, 23,6 ID x 2,9
53	9991976	1	O-RING, 90 Duro, .739" ID x .070" Thk
54	9843615	1	CONNECTION, 3 WAY, 11/16 fc sl x 11/16 sw, Includes : 55
55	9993141	2	O-RING, 90 Duro, .364" ID x .070" Thk
56	86579671	1	CONNECTOR, 11/16 fc sl x 14 Or, Includes : 57, 58
57	86639042	2	GASKET, 11,3 ID x 2,2
58	9993141	2	O-RING, 90 Duro, .364" ID x .070" Thk
59	86579686	1	ELBOW, 11/16 fc sl x 14 Or, Includes : 57, 58
60	86580179	1	UNION, 1-7/16 fc sl x 33 Or, Includes : 61, 62
61	86639046	1	O-RING, 29,6 ID x 2,9
62	9824050	1	O-RING, 90 Duro, .926" ID x .070" Thk
63	327474A1	1	HOSE ASSY., 1650 mm (65 in)
64	407666A1	1	TUBE ASSY.,
65	86639060	1	UNION, 1-7/16 fc sl x blkhd, Includes : 66
66	9824050	1	O-RING, 90 Duro, .926" ID x .070" Thk
67	9993141	1	O-RING, 90 Duro, .364" ID x .070" Thk, Sequence, Shuttle, Includes 68
68	9993141	2	O-RING, 90 Duro, .364" ID x .070" Thk
69	428078A1	1	ELBOW, 90, M14 or, Includes : 70
70	86639042	1	GASKET, 11,3 ID x 2,2
71	86639050	1	CONNECTOR, HYD., 1-7/16 fc sl x 22 Or, Includes : 72, 73
72	86639044	1	O-RING, 19,3 ID x 2,2
73	9824050	1	O-RING, 90 Duro, .926" ID x .070" Thk

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TJ275 TRACTOR

08 -38 MAIN AND AUXILIARY VALVE ASSY - ELECTRONIC REMOTE

Ref	Part Number	Qty	Description
	292295A2	1	VALVE, Main, Consists Of : 1, 4 - 50
	393972A2	1	VALVE, Auxiliary, LH, Consists Of : 2, 4 - 50
	393973A1	1	VALVE, Auxiliary, RH, Consists Of : 3 - 50
1	292296A1	1	BODY, VALVE,
2	NSS	1	NOT SERVICED SEPARATELY, Body
3	NSS	1	NOT SERVICED SEPARATELY, Body
4	9625178	1	PLUG, Hex Socket, 9/16 Or, Includes : 5
5	9617873	1	O-RING, 90 Duro, .468" ID x .078" Thk
6	301973A1	1	SPRING,
	278550A2	1	VALVE, CHECK, Consists Of : 7 - 19
7	NSS	1	NOT SERVICED SEPARATELY, Body
8	NSS	1	NOT SERVICED SEPARATELY, Poppet, Valve
9	1971801C2	1	VALVE, CHECK,
10	1957964C1	1	RETAINER,
11	NSS	1	NOT SERVICED SEPARATELY, Cap
12	1957817C1	1	SPRING, VALVE,
13	167269	2	O-RING, 90 Duro, .755" ID x .097" Thk
14	G108727	1	BACK-UP RING,
15	9992069	1	O-RING, 90 Duro, .614" ID x .070" Thk
16	G103862	1	BACK-UP RING,
17	165212	1	O-RING, 90 Duro, .551" ID x .070" Thk
18	G108723	1	BACK-UP RING,
19	NSS	1	NOT SERVICED SEPARATELY, Spring
20	86625138	1	PLUG, Hex Socket, 7/8 Or, Includes : 21
21	167269	1	O-RING, 90 Duro, .755" ID x .097" Thk
22	9672549	2	O-RING, .987" ID x .103" Thk
23	280927A1	2	WASHER,
24	283514A3	1	SPOOL,
25	86632547	2	PLUG, Hex, 5/16 Or, Includes : 26
26	9617873	2	O-RING, 90 Duro, .468" ID x .078" Thk
27	301969A2	2	SPRING, Outer
28	321689A1	1	SPRING, Inner-B
	336278A2	2	VALVE, Pilot Block, Consists Of: 29 - 39
29	NSS	1	NOT SERVICED SEPARATELY, Body
30	278506A1	2	VALVE, SOLENOID, Consists Of : 31 - 33
31	319723A1	2	O-RING, 8,3 ID x 2,4
32	319722A1	2	O-RING, 10,3 ID x 2,4
33	319721A1	2	O-RING, 15,3 ID x 2,4
34	353830A1	2	GUARD,
35	86639307	2	WASHER, Lock, M4
36	86624126	2	SCREW, Socket, M4 x 12


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Ref	Part Number	Qty	Description
1	403740A1	1	BRACKET,
2	403742A1	1	ROCKSHAFT, See Figure(s) : 09-02
3	435504A1	2	PIN,
4	86529976	4	SCREW, M6 x 35; 10.9
5	86625266	20	WASHER, 17,5 x 30 x 4 mm
6	435501A1	8	SPACER,
7	403718A1	2	LINK, Draft
8	347641A1	1	PIN, LH
9	348061A1	1	PIN, RH, Not Illustrated
10	86639033	10	BOLT, M16 x 60; 10.9
11	392530	4	NUT, CL 10, M16 x 2
12	86624980	4	SCREW, M12 x 65; 10.9
13	NSS	1	NOT SERVICED SEPARATELY, Link Assy, Lift, RH, Not Illustrated, Order Component Parts, See Figure(s) : 09-05
13	NSS	1	NOT SERVICED SEPARATELY, Link Assy, Lift, LH, Not Illustrated, Order Component Parts, See Figure(s) : 09-05
13	NSS	1	NOT SERVICED SEPARATELY, Link Assy, Lift, RH, Not Illustrated, See Figure(s) : 09-05
14	NSS	1	NOT SERVICED SEPARATELY, Link Assy, Lift, LH, See Figure(s) : 09-05
15	403735A1	2	PLATE,
16	403744A1	1	BLOCK ASSY.,
17	403745A1	1	BLOCK ASSY.,
18	403746A1	1	BLOCK ASSY.,
19	403747A1	1	BLOCK ASSY.,
20	403748A1	2	BLOCK ASSY.,
21	322096A1	2	PIN,
22	A30338	2	PIN, LOCK,
23	403204A1	2	PLATE, LARGE,
24	321188A2	2	PIN,
25	86577946	2	SCREW, M16 x 80; 10.9
26	86639319	28	WASHER, 26 x 44 x 5 mm
27	9780064	4	SCREW, Cap, HH, CL 10.9, M24 x 3 x 110
28	9846950	2	SCREW, Cap, HH, CL 10.9, M20 x 2.5 x 90
29	86625260	8	WASHER, 22 x 37 x 4 mm
30	259389A1	2	PLATE,
31	9848973	12	NUT, CL 10, M24 x 3.0
32	86639036	12	BOLT, M24 x 60; 10.9
33	435501A1	2	SPACER,
34	86625266	2	WASHER, 17,5 x 30 x 4 mm
35	86639032	2	BOLT, M16 x 25; 10.9
36	9843590	4	SCREW, Cap, HH, CL 10.9, M20 x 2.5 x 50
37	407145A1	2	CYLINDER, Lift, See Page(s) : 8-45

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Ref	Part Number	Qty	Description
41	86508619	2	SCREW, M10 x 60; 10.9
42	86625237	4	WASHER, 11 x 24 x 2 mm
43	434068A1	6	SPACER,
44	434069A1	2	FENDER,
45	86977726	4	SCREW, Cap, HH, CL 8.8, M6 x 1 x 12
46	86517328	4	WASHER, LOCK, M6
47	404287A1	4	INSERT, THREADED,
48	86624181	4	WASHER, Lock, 6,6 x 12 x 1,6 mm
49	86514335	4	NUT, LOCK, CL 10, M6 x 1
50	436218A2	1	SHIELD, LH
51	436162A2	1	SHIELD, RH, Not Illustrated
52	432280A1	1	LAMP, TAIL, Mounting, LH

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TJ275 TRACTOR

09 -50 WEIGHTS - WHEEL

Ref	Part Number	Qty	Description
1	405829A1	2	WEIGHT, 500 lb, Order From Machinery Price List
1	405830A1	2	WEIGHT, 1000 lb, Order From Machinery Price List
2	86625266	12	WASHER, 17,5 x 30 x 4 mm
3	412066	6	NUT, M16 x 2
4	86639152	6	SCREW, M16 x 200; 10.9, Use With 500 lbs. Application
4	43281	6	SCREW, Cap, HH, CL 10.9, M16 x 2 x 120, Use With 1000 lbs. Application

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 25 of 602 pages

The full manual includes:

- All 602 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

New Holland TJ275 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual