
TB25FR

Book No.BE4Z001
Serial No.12810004-



PREVIEW - YOUFIXTHIS.COM
TAKEUCHI

Download full manual at youfixthis.com

NAME	Page
MACHINERY	-
LOWER FRAME (12810004-12810091)	1-1
LOWER FRAME (12810092-)	1-2
CRAWLER BELT	1-3
CARRIER ROLLER	1-4
TRACK ROLLER	1-5
FRONT IDLER	1-6
TRACK ADJUSTER	1-7
TRAVEL DEVICE	1-8
SLEW BEARING	1-9
SWIVEL JOINT & ACCESSORIES	1-10
DOZER BLADE	1-11
PIPING; LOWER (12810004-12810091)	1-12
PIPING; LOWER (12810092-)	1-13
SLEWING DEVICE	2-1
TURNTABLE	2-2
BOOM OFFSET (1/2)	2-3
BOOM OFFSET (2/2)	2-4
OFFSET SWITCH (12810092-)	2-5
TRAVEL LEVER	2-6
DOZER BLADE LEVER	2-7
OPERATION LEVER & STAND (R.H.)	2-8
OPERATION LEVER & STAND (L.H.)	2-9
PIPING; OPERATION LEVER (1/2) (12810004-12810079)	2-10
PIPING; OPERATION LEVER (2/2) (12810004-12810079)	2-11
PIPING; OPERATION LEVER (1/2) (12810080-)	2-12
PIPING; OPERATION LEVER (2/2) (12810080-)	2-13
PIPING; OPERATION LEVER (1/2) (multi pattern; 12810004-12810079)	2-14
PIPING; OPERATION LEVER (2/2) (multi pattern; 12810004-12810079)	2-15
PIPING; OPERATION LEVER (1/2) (multi pattern; 12810080-)	2-16
PIPING; OPERATION LEVER (2/2) (multi pattern; 12810080-)	2-17
PIPING; OPERATION LEVER (1/2) (ISO-JCB pattern)	2-18
PIPING; OPERATION LEVER (2/2) (ISO-JCB pattern)	2-19
ENGINE & ACCESSORIES (1/2)	3-1
ENGINE & ACCESSORIES (2/2)	3-2
DRAIN PLUG	3-3
CONTROL BOX	3-4
ENGINE CONTROL	3-5
ENGINE CONTROL (with decel.)	3-6
ELECTRICAL (12810004-12810079)	3-7
ELECTRICAL (12810080-)	3-8
BATTERY	3-9
MAINTENANCE LIGHT SOCKET	3-10
VALVE & ACCESSORIES	4-1
PIPING; UPPER (1/2)	4-2
PIPING; UPPER (2/2)	4-3
PUMP DRIVE	4-4
HYDRAULIC TANK	4-5
FUEL TANK & FUEL PIPING	4-6
COVER (1/2)	5-1
COVER (2/2) (engine hood)	5-2
FLOOR FRAME	5-3
SEAT (for Japan)	5-4
SEAT BELT	5-5
CANOPY	5-6
REAR HOOD	5-7

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


LOWER FRAME (12810004-12810091)

Item		Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
			FRAME ASSY, lower					X03510-04000-0
1	X	*****-*****	FRAME	1				
2		03510-03001	COVER	2				
3		03410-04000	COVER	2				
4		04310-03600	COVER	1				
6		11000-51016	BOLT	10				
7		11400-20010	WASHER, spring	10				
8		11411-10010	WASHER	10				
9		11000-40816	BOLT	4				
10		11400-20008	WASHER, spring	4				
		U1a010						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

LOWER FRAME (12810004-12810091)




U1A010

S=1/10

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


BOOM OFFSET (1/2)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

HYDRAULIC TANK



S=1/8

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1 タイトル及びサブタイトル

2 符 号
イラスト内の各部品を示す番号です。

3 部品番号
部品に付けられた固有の番号です。
販売されない部品は、部品番号の前に「X」印が付けられています。

4 部品名称
部品の名前を示します。
組立品を構成する部品は、部品名称の前に「★」印を付け、組立品の次につづけて記載されています。更に、「★」印の部品が組立品の場合は、その構成部品に「★★」印が付けてあります。以下「★」を順次増やして組立品の構成部品であることを表しています。
(R) .... 右側
(L) ..... 左側

5 個 数
「1台分の個数」を示しています。
ただし、組立品の構成部品及び「油圧機器詳細」の項の構成部品は、その組立品「1組分の個数」が示されています。
AR .... 任意選択・必要数使用

6 互換性
単品での互換性
(H) .... すぐ上の行に記載されている部品の代わりに使用できます。
(L) ..... すぐ下の行に記載されている部品の代わりに使用できます。
複数の部品が組になった場合の互換性
英文字(H・Lを除く)の付いた部品は、同じ文字の大文字と小文字ごとに組になっています。これらの文字の後に記号(H)又は(L)を付け、組での互換性を示します。
(H) .... 同じ英文字の大文字が付いた部品の代わりに使用できます。
(L) ..... 同じ英文字の小文字が付いた部品の代わりに使用できます。

7 適用号機
その部品が使用されている機械の号機を示します。
号機表示のない部品は全ての機械に使用されています。但し、小見出しに適用号機が記載されている場合は、個々に号機表示のあるものを除き、そのページの部品すべてにこの号機が適用されます。

8 備 考

9 ノート

10 機械の型式


11 ページ番号

12 改訂番号
改訂されたときの番号が付けられており、そのページが何回改訂されたかを示すものではありません。

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CONTROL BOX



U1C030

S=1/6

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

MANUAL STORAGE

Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
		MANUAL STORAGE					X03584-15000-2
1	03584-15100	BOX	1				
2	03382-25300	LOCK	1			M	
3	16543-01008	URETHANE	1				sold by the meter
4	17001-00019	KEY	1				
	U1e081						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



U1G110

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SOLENOID VALVE (4 blocks; 12810004-12810079)

Item		Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
0		19017-29600	VALVE, solenoid	1				
0-1		19017-29699	· KIT, seal	1				
1	X	*****-*****	· · O-RING	4				
2	X	*****-*****	· · O-RING	1				
3	X	*****-*****	· · O-RING	4				
4	X	*****-*****	· · O-RING	1				
5		19017-29601	· SHIM t=0.5	1				
6		19017-28701	· SHIM t=0.2	1				
7		19017-28702	· PLUG	1				
8		19017-28703	· SPRING	4				
9		19017-29604	· PLUNGER	1				
10		19017-29605	· SPRING	2				
11		19017-29606	· ORIFICE	1				
12		19017-29607	· SOLENOID	4				
13		19017-28708	· SPRING	1				
14		19017-29610	· PLUNGER	1				
15		19017-28711	· STOPPER	4				
16		19017-29616	· RING	1				
17		19017-20720	· PLUG	4				
18		19017-29618	· PLUG	1				
19		11100-50510	· SCREW, socket head	8				
20		11411-90004	· WASHER	4				
21		13900-20005	· BALL, steel	13				
22		19017-29630	· PLUNGER	1				
		U1h180						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 11 of 249 pages

The full manual includes:

- All 249 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Takeuchi TB25FR Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual