
LOWER FRAME




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

L9A010

S=1/16

SWIVEL JOINT & ACCESSORIES




L9A080

S=1/6

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

BOOM OFFSET 1/4




PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

ENGINE & ACCESSORIES (1/3) 1/2



PREVIEW ONLY
Download full manual at youfixthis.com

CAB (1/4) 1/4




PREVIEW: YOUFIXTHIS.COM

Download full manual at youfixthis.com

L9E180a

S=1/24, 1/15


CRAWLER BELT (rubber)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PIPING; LOWER




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

S=1/8, 1/14


BOOM (1/3) (with 2nd aux. line + boom shut-off valve) 1/4



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ENGINE & ACCESSORIES (2/3)




L9C020

S=1/10

PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com


CAB (2/4) (door)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SLEWING DEVICE




L9B010

S=free

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


BOOM (2/3) (boom cylinder) (with shut-off valve)



PREVIEW.YOUFIXTHIS.COM

Download full manual at youfixthis.com


ENGINE & ACCESSORIES (3/3)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CAB (3/4) (front sash)



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Q0E141

TITLE	PAGE
LOWER FRAME	1-1
CRAWLER BELT (rubber)	1-2
CARRIER ROLLER	1-3
TRACK ROLLER	1-4
FRONT IDLER	1-5
TRACK ADJUSTER	1-6
TRAVEL DEVICE	1-7
SLEW BEARING	1-8
SWIVEL JOINT & ACCESSORIES	1-9
DOZER BLADE	1-10
PIPING; LOWER	1-11
SLEWING DEVICE	2-1
TURNTABLE	2-2
BOOM OFFSET	2-3
BOOM OFFSET	-
BOOM OFFSET	-
BOOM OFFSET	-
OFFSET SWITCH	2-4
TRAVEL LEVER	2-5
DOZER BLADE LEVER	2-6
DOZER BLADE LEVER (with blade float)	2-7
VALVE BRACKET (R.H.)	2-8
VALVE BRACKET (L.H.)	2-9
PIPING; OPERATION LEVER	2-10
PIPING; OPERATION LEVER	-
PIPING; OPERATION LEVER (ISO-JCB pattern)	2-11
PIPING; OPERATION LEVER (ISO-JCB pattern)	-
ENGINE & ACCESSORIES (1/3)	3-1
ENGINE & ACCESSORIES (1/3)	-
ENGINE & ACCESSORIES (2/3)	3-2
ENGINE & ACCESSORIES (3/3)	3-3
CONTROL BOX (R.H.)	3-4
CONTROL BOX (L.H.)	3-5
ELECTRICAL	3-6
ELECTRICAL	-
ELECTRICAL	-
BATTERY	3-7
RADIO	3-8
WINDOW WASHER	3-9
CAB LIGHT	3-10
CAB LIGHT STAY	3-11
REAR LIGHT	3-12
REAR LIGHT STAY	3-13
GREASE PIPING	4-1
VALVE & ACCESSORIES (1/2)	4-2
VALVE & ACCESSORIES (1/2)	-
VALVE & ACCESSORIES (1/2)	-
VALVE & ACCESSORIES (1/2)	-
VALVE & ACCESSORIES (1/2)	-
VALVE & ACCESSORIES (2/2)	4-3
VALVE & ACCESSORIES (1/2) (with blade float)	4-4
VALVE & ACCESSORIES (1/2) (with blade float)	-
VALVE & ACCESSORIES (1/2) (with blade float)	-
VALVE & ACCESSORIES (1/2) (with blade float)	-
VALVE & ACCESSORIES (1/2) (with blade float)	-

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1 タイトル及びサブタイトル

2 符 号
イラスト内の各部品を示す番号です。

3 部品番号
部品に付けられた固有の番号です。
販売されない部品は、部品番号の前に「X」印が付けられています。

4 部品名称
部品の名前を示します。
組立品を構成する部品は、部品名称の前に「★」印を付け、組立品の次につづけて記載されています。更に、「★」印の部品が組立品の場合は、その構成部品に「★★」印が付けてあります。以下「★」を順次増やして組立品の構成部品であることを表しています。
(R) .... 右側
(L) ..... 左側

5 個 数
「1 台分の個数」を示しています。
ただし、組立品の構成部品及び「油圧機器詳細」の項の構成部品は、その組立品「1 組分の個数」が示されています。
AR .... 任意選択・必要数使用

6 互換性
単品での互換性
(H) .... すぐ上の行に記載されている部品の代わりに使用できます。
(L) ..... すぐ下の行に記載されている部品の代わりに使用できます。
複数の部品が組になった場合の互換性
英文字(H・Lを除く)の付いた部品は、同じ文字の大文字と小文字ごとに組になっています。これらの文字の後に記号(H)又は(L)を付け、組での互換性を示します。
(H) .... 同じ英文字の大文字が付いた部品の代わりに使用できます。
(L) ..... 同じ英文字の小文字が付いた部品の代わりに使用できます。

7 適用号機
その部品が使用されている機械の号機を示します。
号機表示のない部品は全ての機械に使用されています。但し、小見出しに適用号機が記載されている場合は、個々に号機表示のあるものを除き、そのページの部品すべてにこの号機が適用されます。

8 備 考

9 ノート


10 機械の型式

11 ページ番号

12 改訂番号
改訂されたときの番号が付けられており、そのページが何回改訂されたかを示すものではありません。

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

VALVE & ACCESSORIES (1/2) (with auto tank & auto pressure release) 4/5



L9D070d

S=1/8, 1/15

Reference L9D070a

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

BOOM (1/3) (with 4th aux. line + shut-off valve)

Item		Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
3-4		0566045644	· BUSHING	2				
3-5		1432200075	· SEAL, dust	4				
4		0566023581	PLATE	1				
5		0566030470	COVER	1				
6		0566045580	PROTECTOR	1				
7		0566022655	RUBBER	2				
8		0566022656	PLATE	2				
9	X	**********	LINK ASSY, hose (R.H.)	1				
9-1		0567333980	· ARM	1				
9-2		0566045160	· ARM	1				
9-3		0566045170	· LINK, hose	1				
9-4		0566023870	· SHAFT	2				
9-5		0566023875	· SHAFT	2				
9-6		0566045180	· SPACER	1				
9-7		0566023885	· WASHER	1				
9-8		1120801035	· SCREW	2				
9-9		1120801020	· SCREW	2				
10	X	**********	LINK ASSY, hose (L.H.)	1				
10-1		0567333980	· ARM	1				
10-2		0566023940	· ARM, hose	1				
10-3		0567333960	· LINK, hose	1				
10-4		0566023870	· SHAFT	2				
10-5		0566023875	· SHAFT	2				
10-6		1120801020	· SCREW	4				
10-7		0566023885	· WASHER	1				
11		0566023720	PIN	1				
12		0566000329	PIN	1				
13		0566022700	PIN	1				
14		0566022710	PIN	2				
15		0566030500	PIN	1				
16		0566022730	PLATE	1				
17		0566022735	PLATE	1				
18		0566023730	PLATE	1				
19		0566000322	PLATE	1				
20		0872433150	TUBE	2				
21		0003600026	WASHER	4				
22		0011907007	PIN	1				
23		0001607200	PIN	1				
24		0566021600	PIN	1				
25		0056031510	PROTECTOR	1				
26		0003600057	WASHER	1				
27		0003600099	SHIM	AR				t=1.0mm
28		0003600102	SHIM	AR				t=0.5mm
29	X	**********	CYLINDER ASSY, boom	1				see page (2/3)
30	X	**********	CYLINDER ASSY, arm	1				see page (3/3)
31		1703006100	LAMP ASSY	1				
31-1		1703006106	· BULB	1				
32		1140330012	WASHER	1				
33		1141110012	WASHER	1				
34		1101141220	BOLT	3				
35		1934802070	HOSE ASSY	1				
36		1225120022	WASHER, conical	1				
37		1101041225	BOLT	1				
38		1140020012	WASHER, spring	5				
39		1100041445	BOLT	4				
40		1802743049	HOSE ASSY	1				

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 432 pages

The full manual includes:

- All 432 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Takeuchi TB280FR Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual