
TRACK ROLLER A

Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
		ROLLER ASSY, track					X08801-30000-4
0-1	**08801-30100**	ROLLER SUB ASSY, track	8				
1	**08801-30010**	· ROLLER	1				
2	**08601-34010**	· SHAFT	1				
3	**02212-40400**	· COVER	2				
5	**13330-73535**	· BUSHING	2				
6	**14325-00560**	· SEAL, floating	2				
6-1	**14325-00561**	· · O-RING	2				
6-2	**14325-00562**	· · RING, seal	2				
7	**12200-00035**	· RING, snap	2				
8	**14201-00300**	· O-RING	2				
9	**15018-10001**	· PLUG	1				
11	**11000-41645**	BOLT	16				
12	**11415-50016**	WASHER	16				
	T8a013						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TRACK ROLLER A




T8A010

S=1/8, 1/20

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


ENGINE & ACCESSORIES (1/2) (21300004-21301932)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


VALVE & ACCESSORIES (21300004-21301932)



S=1/8, 1/30

Download full manual at youfixthis.com
PREVIEW YOUFIXTHIS.COM

CANOPY (1/3) (for US; 21301099-21305348)



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
00010-90002	6-1	10
00013-23506	6-1	12
00016-03125	6-1	9
00016-72004	6-1	11
00024-00045	6-1	1-15
00024-00060	6-1	1-17
00024-00066	6-1	
00036-00003	3-2	59
	3-4	59
	4-15	38
	4-5	39
00036-00011	3-6	67
	3-8	62
00036-00020	2-4	
	4-10	64
	4-11	64
	4-2	27
	4-3	27
	4-6	64
	4-9	64
	5-1	34
	5-2	34
	6-7	36
00036-00025	2-1	14
	3-6	59
	3-8	59
	4-10	39
	4-14	18
	4-16	38
	4-17	38
	4-7	39
	4-8	39
	5-1	28
	5-2	28
	6-2	14
00036-00035	6-1	42
00036-00036	6-1	43
00036-00043	2-6	39
	2-8	39
	4-16	1-17
	4-17	1-17
00036-00047	5-58	37
00036-00051	6-1	46
00036-00052	6-1	47
00036-00110	3-25	41
	3-29	34
00036-00136	3-2	60
	3-4	60
	3-6	60
	3-8	60
00036-00163	6-1	40
00036-00165	5-22	39
	5-24	21
	5-31	21
	5-34	21
	5-38	21
	5-41	21
00036-00176	6-1	30
00036-00188	6-1	44
00036-00189	6-1	45
00036-00222	5-58	39
00036-00223	5-58	40
00036-06202	3-2	58
	3-21	32
	3-22	32
	3-23	32
	3-25	32
	3-29	31
	3-4	58
	3-6	58
00036-08003	4-10	69
	5-11	28
	5-12	28
	5-13	28
	6-1	41
00036-08252	3-24	25
	3-26	25
	3-30	6
	3-5	87
	3-7	58
	3-8	58
	5-10	17
	5-11	17
	5-12	17
	5-13	17
	5-3	15
	5-4	15
	5-5	15
	5-53	3
	5-6	15
	5-7	10
	5-9	15
	6-1	28
	6-7	35
00036-09003	4-3	30-7
00039-00037	5-3	21
	5-4	16
	5-5	16
	5-6	16
00039-00038	5-3	
	5-4	
	5-5	
00039-00039	4-12	22
00039-00040	5-1	36
	5-2	35
00039-00041	5-1	
	5-2	
00039-00044	5-22	21
	5-24	8
	5-31	8
	5-34	8
	5-38	8
	5-41	8
00040-10025	5-22	23
	5-24	10
	5-3	6
	5-31	10
	5-34	10
	5-38	10
	5-41	10
00040-15002	5-4	5
	5-5	5
	5-6	5
00070-00004	1-4	3
00070-00016	6-2	10
00070-00070	5-3	5
	5-8	15
	5-9	16
00070-00076	6-2	11
00070-00106	6-1	13
00070-00112	5-4	6
	5-5	6
	5-6	6
00070-00114	6-1	
00070-00119	6-2	
00072-03007	4-2	10-2
	4-2	2-3
	4-3	10-2
	4-3	2-3
00072-03017	4-2	2-4
	4-3	2-4
	6-7	61
00072-03058	4-2	10-3
	4-3	10-3
00072-03069	1-5	8
	1-6	8
00072-03072	4-1	1-3
	4-2	1-3
	4-3	1-3
00072-03073	1-5	9
	1-6	9
00072-13006	6-10	58
	6-12	58
00072-13011	6-11	40
	6-4	40
	6-5	40
	6-6	40
	6-8	40
	6-9	40
00072-13014	2-5	43
	2-7	43
00072-13020	4-10	47
	4-4	47
	4-5	47
	4-7	47
	4-8	47
00072-13034	4-10	46
	4-4	46
	4-5	46
	4-7	46
	4-8	46
00072-13043	2-5	41
00072-13049	4-1	1-2
	4-2	1-2
	4-3	1-2
00072-13056	4-1	1-1
	4-2	1-1
	4-3	1-1
00072-13058	2-6	42
	2-8	42
	4-10	45
	4-4	45
	4-5	45
	4-7	45
	4-8	45
00072-13061	4-1	3-9
	4-2	3-9
	4-3	3-9
00072-24009	5-58	23
00072-36041	6-10	60
	6-12	60
00072-36045	6-7	60
00072-56006	4-14	10
00073-00003	3-21	35
00073-00010	5-61	23
00073-00013	4-15	54
	4-16	54
	4-17	54
00073-00030	4-10	72
	4-8	52

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1 タイトル及びサブタイトル

2 符 号
イラスト内の各部品を示す番号です。

3 部品番号
部品に付けられた固有の番号です。
販売されない部品は、部品番号の前に「X」印が付けられています。

4 部品名称
部品の名前を示します。
組立品を構成する部品は、部品名称の前に「★」印を付け、組立品の次につづけて記載されています。更に、「★」印の部品が組立品の場合は、その構成部品に「★★」印が付けてあります。以下「★」を順次増やして組立品の構成部品であることを表しています。
(R) .... 右側
(L) ..... 左側

5 個 数
「1 台分の個数」を示しています。
ただし、組立品の構成部品及び「油圧機器詳細」の項の構成部品は、その組立品「1 組分の個数」が示されています。
AR .... 任意選択・必要数使用

6 互換性
単品での互換性
(H) .... すぐ上の行に記載されている部品の代わりに使用できます。
(L) ..... すぐ下の行に記載されている部品の代わりに使用できます。
複数の部品が組になった場合の互換性
英文字(H・Lを除く)の付いた部品は、同じ文字の大文字と小文字ごとに組になっています。これらの文字の後に記号(H)又は(L)を付け、組での互換性を示します。
(H) .... 同じ英文字の大文字が付いた部品の代わりに使用できます。
(L) ..... 同じ英文字の小文字が付いた部品の代わりに使用できます。

7 適用号機
その部品が使用されている機械の号機を示します。
号機表示のない部品は全ての機械に使用されています。但し、小見出しに適用号機が記載されている場合は、個々に号機表示のあるものを除き、そのページの部品すべてにこの号機が適用されます。

8 備 考

9 ノート

10 機械の型式

11 ページ番号

12 改訂番号
改訂されたときの番号が付けられており、そのページが何回改訂されたかを示すものではありません。

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com


PIPING; OPERATION LEVER (2/2) (21300004-21303768)

Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
48	**11000-40816**	BOLT	6				
52	**08807-17520**	PROTECTOR	1				sold by the meter
	T8b054						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CONTROL BOX; R.H. (21303229-)



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

MAINTENANCE LIGHT SOCKET



S=1/20

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


PIPING (1/2) (high flow; 21306717-)

Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
49	**14200-10240**	· O-RING	1				
50	**15150-10044**	ELBOW	2				
	14200-10290	· O-RING	1				
51	**08807-35090**	HOSE	1				
52	**15305-38011**	HOSE	1				sold by the meter
53	**08807-08240**	HOSE	1				
54	**14200-10110**	O-RING	1				
55	**14200-10240**	O-RING	2				
56	**08807-08250**	HOSE	1				
59	**11400-20010**	WASHER, spring	12				
63	**11000-41020**	BOLT	6				
64	**00036-00020**	WASHER	1		21306717~21307665		
65	**08817-01670**	PROTECTOR	1				
67	**11000-40816**	BOLT	2				
68	**11400-20008**	WASHER, spring	2				
69	**00036-08003**	WASHER	2				
71	**15150-10133**	ELBOW	1				
	14200-10240	· O-RING	1				
72	**00073-00030**	CLAMP	1				
		<<NOTE>>				M	
		SET "A" is interchangeable with SET "a".				M	
	T8d134						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

COVER (3/3) (engine hood; 21300073-21301932)




T7E032

S=1/10

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CANOPY (2/3) (for US; 21301099-21305348)




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CAB (4/6)





PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

ARM




PREVIEW: YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

BLOCK ASSY; No. 2




SECTION "X-X"

T7H030

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

TRAVEL MOTOR (2/3) (motor sec. ; 21305001-)



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 18 of 464 pages

The full manual includes:

- All 464 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Takeuchi TL130 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual