
ILLUSTRATION 1/2




U8A010a

S=1/8, 1/20

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

ILLUSTRATION 1/2



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

ILLUSTRATION 1/2




S=1/8, 1/25

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

COVER (1/3)



PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

TITLE	PAGE
TRACK ROLLER	1-1
TRACK ROLLER	○
FRONT IDLER	1-2
TRACK ADJUSTER	1-3
TRAVEL DEVICE	1-4
CRAWLER BELT	1-5
FRAME	2-1
OPERATION LEVER & STAND	2-2
PIPING; OPERATION LEVER	2-3
PIPING; OPERATION LEVER (for pattern change)	2-4
PIPING; OPERATION LEVER (for pattern change)	○
PIPING; OPERATION LEVER (for pattern change)	○
ENGINE & ACCESSORIES (1/4)	3-1
ENGINE & ACCESSORIES (1/4)	○
ENGINE & ACCESSORIES (2/4)	3-2
ENGINE & ACCESSORIES (3/4)	3-3
DRAIN PLUG	3-4
CONTROL BOX; R.H.	3-5
CONTROL BOX; L.H.	3-6
CONTROL BOX; L.H. (hydraulic quick hitch type)	3-7
FOOT ACCELERATOR	3-8
ELECTRICAL (1/2)	3-9
ELECTRICAL (1/2)	○
ELECTRICAL (1/2)	○
ELECTRICAL (1/2)	○
ELECTRICAL (1/2) (with 14 pin connector)	3-10
ELECTRICAL (1/2) (with 14 pin connector)	○
ELECTRICAL (1/2) (with 14 pin connector)	○
ELECTRICAL (1/2) (with 14 pin connector)	○
ELECTRICAL (2/2)	3-11
ELECTRICAL (cab)	3-12
BATTERY	3-13
REAR LAMP	3-14
MAINTENANCE LIGHT SOCKET	3-15
WINDOW WASHER	3-16
RADIO	3-17
VALVE & ACCESSORIES	4-1
VALVE & ACCESSORIES	○
VALVE & ACCESSORIES (for pattern change)	4-2
VALVE & ACCESSORIES (for pattern change)	○
PIPING	4-3
PIPING	○
PIPING (for pattern change)	4-4
PIPING (for pattern change)	○
PUMP DRIVE	4-5
HYDRAULIC TANK	4-6
FUEL TANK & FUEL PIPING (1/2)	4-7
FUEL TANK & FUEL PIPING (1/2)	○
FUEL TANK & FUEL PIPING (2/2)	4-8
COVER (1/3)	5-1
COVER (2/3) (engine hood)	5-2
COVER (3/3) (rear door)	5-3
FLOOR FRAME	5-4
FLOOR FRAME (for pattern change)	5-5
SEAT (1/2)	5-6

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1 タイトル及びサブタイトル

2 符 号
イラスト内の各部品を示す番号です。

3 部品番号
部品に付けられた固有の番号です。
販売されない部品は、部品番号の前に「X」印が付けられています。

4 部品名称
部品の名前を示します。
組立品を構成する部品は、部品名称の前に「★」印を付け、組立品の次につづけて記載されています。更に、「★」印の部品が組立品の場合は、その構成部品に「★★」印が付けてあります。以下「★」を順次増やして組立品の構成部品であることを表しています。
(R) .... 右側
(L) ..... 左側

5 個 数
「1 台分の個数」を示しています。
ただし、組立品の構成部品及び「油圧機器詳細」の項の構成部品は、その組立品「1 組分の個数」が示されています。
AR .... 任意選択・必要数使用

6 互換性
単品での互換性
(H) .... すぐ上の行に記載されている部品の代わりに使用できます。
(L) ..... すぐ下の行に記載されている部品の代わりに使用できます。
複数の部品が組になった場合の互換性
英文字(H・Lを除く)の付いた部品は、同じ文字の大文字と小文字ごとに組になっています。これらの文字の後に記号(H)又は(L)を付け、組での互換性を示します。
(H) .... 同じ英文字の大文字が付いた部品の代わりに使用できます。
(L) ..... 同じ英文字の小文字が付いた部品の代わりに使用できます。

7 適用号機
その部品が使用されている機械の号機を示します。
号機表示のない部品は全ての機械に使用されています。但し、小見出しに適用号機が記載されている場合は、個々に号機表示のあるものを除き、そのページの部品すべてにこの号機が適用されます。

8 備 考

9 ノート


10 機械の型式

11 ページ番号

12 改訂番号
改訂されたときの番号が付けられており、そのページが何回改訂されたかを示すものではありません。

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

ILLUSTRATION 2/2



PREVIEW YOUFIXTHIS.COM
Download full manual at youfixthis.com


COVER (2/3) (engine hood)

Item	Part number	Description	Q'ty	Chan.	Serial No.	Serv.	Remarks
0	**0668200017**	HOOD, engine	1				
1	**0668200018**	· PIPE	1				
2	**0668200021**	· HOOD, engine	1				
4	**0668200027**	· PLATE	1				
5	**0668200040**	· SPRING	1				
6	**0553500337**	· COLLAR	1				
7	**0004012035**	· PIN	1				
8	**1214000010**	· PIN, snap	1				
9	**1141810012**	· WASHER	2				
10	**0668200030**	· PLATE	1				
11	**1100040816**	· BOLT	3				
15	**0003608252**	· WASHER	3				
17	**1650202300**	· CAP	1				
18	**1653601395**	· LOCK	1				
20	**1140020008**	· WASHER, spring	3				
	U8e020						

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


AIR CONDITIONER (3/5) (air conditioner unit)



PREVIEW FROM YOUFIXTHIS.COM


Download full manual at youfixthis.com

PILOT VALVE (R.H.)



PREVIEW-YOUFIXTHIS.COM
Download full manual at youfixthis.com


CONTROL BOX; R.H.



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PUMP DRIVE



PREVIEW-YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 233 pages

The full manual includes:

- All 233 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Takeuchi TL8 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual