
```
1,1,,719610-01560,,"BLOCK ASSY, CYLINDER",1,,,,,,,,,,,,,,,,
2,2,,124160-01910,,"PLUG PT1/4",1,,,,,,,,,,,,,,,,
2-1,2,,119600-01050,,"PLUG PT1/4",1,,,,,,N,,*,EXXX,,,,,,,,,,I
3,2,,23871-010000,,"PLUG PT 1/8",1,,,,,,,,,,,,,,,,
4,2,,27231-450000,,"PLUG 45",1,,,,,,,,,,,,,,,,
5,2,,27241-120000,,"PLUG 12",1,,,,,,,,,,,,,,,,
6,2,,27241-300000,,"PLUG 30",6,,,,,,,,,,,,,,,,
7,2,,119620-02020,,BOLT,8,,,,,,,,,,,,,,,,
8,2,,719620-02800,,"MAIN BEARING",4,,,,,,,,,,,,,,,,
9,2,,719620-02930,,"BEARING, THRUST",2,,,,,,,,,,,,,,,,
10,2,,119620-02410,,"BUSH, CAMSHAFT",1,,,,,,,,,,,,,,,,
11,1,,119620-02450,,"BEARING, THRUST",1,,,,,,,,,,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

**Blurred on purpose. The manual you buy has this page in full quality.**

Download full manual at youfixthis.com

Fig. 1 シリンダブロック
CYLINDER BLOCK





Blurred on purpose. The manual you buy has this page in full quality.

REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

# Fig. 31 スターティングモータ STARTING MOTOR




Download full manual at youfixthis.com

```
0,Y00B3761
1,002,,"ENGINE 3TNA72L-UTB"
2,1,,"CYLINDER BLOCK",3TNA72L-UTB,,,
2,2,,"GEAR HOUSING",3TNA72L-UTB,,,
2,3,,"GEAR HOUSING BLIND COVER",3TNA72L-UTB,,,
2,4,,"FLYWHEEL HOUSING",3TNA72L-UTB,,,
2,5,,"OIL SEAL HOUSING",3TNA72L-UTB,,,
2,6,,"LUB. OIL SUMP",3TNA72L-UTB,,,
2,7,,"CYLINDER HEAD",3TNA72L-UTB,,,
2,8,,"ROCKER ARM",3TNA72L-UTB,,,
2,9,,BONNET,3TNA72L-UTB,,,
2,10,,"AIR CLEANER",3TNA72L-UTB,,,
2,11,,"SUCTION MANIFOLD",3TNA72L-UTB,,,
2,12,,"EXHAUST MANIFOLD",3TNA72L-UTB,,,
2,13,,CAMSHAFT,3TNA72L-UTB,,,
2,14,,CRANKSHAFT,3TNA72L-UTB,,,
2,15,,FLYWHEEL,3TNA72L-UTB,,,
2,16,,PISTON,3TNA72L-UTB,,,
2,17,,"CONNECTING ROD",3TNA72L-UTB,,,
2,18,,"DRIVING GEAR",3TNA72L-UTB,,,
2,19,,"LUB. OIL PUMP",3TNA72L-UTB,,,
2,20,,"LUB. OIL SYSTEM",3TNA72L-UTB,,,
2,21,,"COOLING WATER PUMP",3TNA72L-UTB,,,
2,22,,THERMOSTAT,3TNA72L-UTB,,,
2,23,,"FUEL INJECTION PUMP",3TNA72L-UTB,,,
2,24,,"FUEL INJECTION VALVE",3TNA72L-UTB,,,
2,25,,"FUEL STRAINER",3TNA72L-UTB,,,
2,26,,"FUEL INJECTION LINE",3TNA72L-UTB,,,
2,27,,"FUEL LINE",3TNA72L-UTB,,,
2,28,,"FUEL RETURN LINE",3TNA72L-UTB,,,
2,29,,GOVERNOR,3TNA72L-UTB,,,
2,30,,"CONTROL SYSTEM",3TNA72L-UTB,,,
2,31,,"STARTING MOTOR",3TNA72L-UTB,,,
2,32,,GENERATOR,3TNA72L-UTB,,,
2,33,,"GLOW PLUG",3TNA72L-UTB,,,
2,34,,"GASKET SET & SPECIAL TOOL (OP)",3TNA72L-UTB,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


```
1,1,,119660-01492,,"HOUSING ASSY, GEAR",1,,,,,,,,,,,,,,,,
2,2,,119660-01510,,"PLUG 10X14",1,,,,,,,,,,,,,,,,
3,1,,119660-01521,,"COVER, GEAR HOUSING",1,,,,,,,,,,,,,,,,
4,1,,121450-01560,,"STUD M 8X 22",4,,,,,,,,,,,,,,,,
5,1,,119620-01800,,"SEAL HTC456208, OIL",1,,,,,,,,,,,,,,,,
6,1,,119660-01911,,"PIPE, KNOCK",4,,,,,,,,,,,,,,,,
7,1,,119620-01950,,"SHIM SET",1,,,,,,,,,,,,,,,,
8,1,,194990-22050,,"NUT W/WASHER  8",4,,,,,,,,,,,,,,,,
9,1,,119640-77250,,"BRACKET,GENERATOR",1,,,,,,,,,,,,,,,,
10,1,,22351-040010,,"SPRING PIN 4X10",2,,,,,,,,,,,,,,,,
11,1,,24311-000120,,"O-RING 1A P-12.0",2,,,,,,,,,,,,,,,,
12,1,,26106-060162,,"BOLT M 6X 16 PLATED",7,,,,,,,,,,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

**Blurred on purpose. The manual you buy has this page in full quality.**


Download full manual at youfixthis.com

Fig. 9 ベンワンシツ
BONNET





Download full manual at youfixthis.com

# Fig. 17 コネクティングロッド CONNECTING ROD




Download full manual at youfixthis.com

# Fig. 25 FOコシキ FUEL STRAINER




Download full manual at youfixthis.com

# PREVIEW ONLY

You're viewing 8 of 70 pages

## The full manual includes:

- All 70 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

**GET FULL MANUAL NOW**

**Yanmar 3TNA72L-UTB (YB10-2), 3TNA72L-UTB, YB10-2, T-series, Vertical multi cyl, diesel (T-series) Parts Catalog**

**Scan or click anywhere**
**youfixthis.com**

*Click anywhere on this page to get the full manual*