[Info]
PcNo=Y00B5871
PcName=3TNE78A-B1(B22-2B)
JpnUse=1
JpnSec1=ƒGƒ“ƒWƒ“
JpnSec2=—§ ¬
JpnSec3=TNE
JpnPreface=0
EngUse=1
EngSec1=ENGINE (US)
EngSec2=SMALL VERTICAL (B)
EngSec3=TNE
EngPreface=0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
0,Y00B5871
1,001,,"ENGINE 3TNE78A-B1"
2,1,,"CYLINDER BLOCK",3TNE78A-B1,,,
2,2,,"GEAR HOUSING",3TNE78A-B1,,,
2,3,,"FLYWHEEL HOUSING&LUB.OIL SUMP",3TNE78A-B1,,,
2,4,,"CYLINDER HEAD & BONNET",3TNE78A-B1,,,
2,5,,"SUCTION MANIFOLD & AIR CLEANER",3TNE78A-B1,,,
2,6,,"EXHAUST MANIFOLD & SILENCER",3TNE78A-B1,,,
2,7,,"CAMSHAFT & DRIVING GEAR",3TNE78A-B1,,,
2,8,,"CRANKSHAFT & PISTON",3TNE78A-B1,,,
2,9,,"LUB.OIL SYSTEM",3TNE78A-B1,,,
2,10,,"COOLING WATER SYSTEM",3TNE78A-B1,,,
2,11,,"FUEL INJECTION PUMP",3TNE78A-B1,,,
2,12,,GOVERNOR,3TNE78A-B1,,,
2,13,,"FUEL INJECTION PIPE",3TNE78A-B1,,,
2,14,,"FUEL OIL PIPE",3TNE78A-B1,,,
2,15,,"STARTING MOTOR",3TNE78A-B1,,,
2,16,,GENERATOR,3TNE78A-B1,,,
2,17,,"GASKET SET(OPTIONAL) & TOOL",3TNE78A-B1,,,
```


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
1,1,,719822-01560,,"BLOCK ASSY, CYLINDER",1,,,,,,,,,,,,,,,,
4,2,,124160-01910,,"PLUG PT1/4",2,,,,,,,,,,,,,,,,
5,2,,171051-01921,,PLUG,1,,,,,,,,,,,,,,,,
6,2,,23871-010000,,"PLUG PT1/8,SCREW",1,,,,,,,,,,,,,,,,
7,2,,27231-500000,,"PLUG 50",1,,,,,,,,,,,,,,,,
8,2,,27241-120000,,"PLUG 12",2,,,,,,,,,,,,,,,,
9,2,,27241-300000,,"PLUG 30",6,,,,,,,,,,,,,,,,
12,2,,119620-02020,,BOLT,8,,,,,,,,,,,,,,,,
13,2,,119810-02800,,"MAIN BEARING",4,,,,,,,,,,,,,,,,
16,2,,119810-02930,,"BEARING, THRUST",1,,,,,,,,,,,,,,,,,,I
19,2,,129795-02411,,"BUSH, CAMSHAFT",1,,,,,,,,,,,,,,,,
20,2,,23887-120002,,"PLUG 12,HEX.",1,,,,,,,,,,,,,,,,
20-1,2,,124160-01910,,"PLUG PT1/4",1,,,,,,S,,TE-97382,E/#14543,,,,,,,,
21,1,,119810-01200,,"BOLT, CYL. HEAD",14,,,,,,,,,,,,,,,,
22,1,,119818-01330,,"GASKET, CYL. HEAD",1,,,,,,,A,,,,,,,,,,
23,1,,119810-02870,,"MAIN BEARING US=0.25",4,,,,,,,1,,,,,,,,,,
26,1,,119810-02940,,"BEARING,THRUST .25OS",2,,,,,,,2,,,,,,,,,,
```


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
1,1,,129400-01520,,"FLANGE,GEARS HOUSING",1,,,,,,,,,,,,,,,
2,1,,121450-01560,,"STUD M 8X 22",3,,,,,,,,,,,,,,,
3,1,,719810-01500,,"HOUSING ASSY, GEAR",1,,,,,,,,,,,,,,,
5,2,,129795-01800,,"SEAL, OIL",1,,,,,,,,,,,,,,,
6,1,,124160-01751,,"CAP, LUB.OIL SUPPLY",1,,,,,,,,,,,,,,,
7,1,,124240-01871,,"COVER, HO-P",1,,,,,,,,,,,,,,,
8,1,,124240-01883,,"GASKET, (NON-ASB.)",1,,,,,,,A,,,,,,,,,
9,1,,129795-01950,,"PIPE, KNOCK L=18",2,,,,,,,,,,,,,,,
10,1,,129150-03100,,RETAINER,1,,,,,,,,,,,,,,,
11,1,,121850-51960,,"O-RING, F.I.PUMP",1,,,,,,,A,,,,,,,,,
12,1,,22190-080002,,"SEAL WASHER  8S",4,,,,,,,,,,,,,,,
13,1,,22190-080002,,"SEAL WASHER  8S",1,,,,,,,,,,,,,,,
14,1,,24311-000160,,"O-RING 1A P-16.0",2,,,,,,,A,,,,,,,,,
15,1,,24311-000320,,"O-RING 1A P-32.0",1,,,,,,,A,,,,,,,,,
16,1,,26106-080122,,"BOLT M 8X 12 PLATED",4,,,,,,,,,,,,,,,
17,1,,26106-080162,,"BOLT M 8X 16 PLATED",1,,,,,,,,,,,,,,,
18,1,,26106-080162,,"BOLT M 8X 16 PLATED",3,,,,,,,,,,,,,,,
19,1,,26106-080202,,"BOLT M 8X 20 PLATED",2,,,,,,,,,,,,,,,
20,1,,26106-080452,,"BOLT M 8X 45 PLATED",6,,,,,,,,,,,,,,,
21,1,,26106-080552,,"BOLT M 8X 55 PLATED",3,,,,,,,,,,,,,,,
22,1,,26106-080852,,"BOLT M 8X 85 PLATED",4,,,,,,,,,,,,,,,
22-1,1,,129001-91840,,"BOLT M 8X 85 PLATED",4,,,,,N,,,E/#18361,,,,,,,
23,1,,26366-080002,,"NUT M 8",3,,,,,,,,,,,,,,,
24,1,,121023-01550,,"COVER, BLIND",1,,,,,,,,,,,,,,,
25,1,,24341-000240,,"O-RING 1A S-24.0",1,,,,,,,A,,,,,,,,,
26,1,,26106-060122,,"BOLT M 6X 12 PLATED",2,,,,,,,,,,,,,,,
26-1,1,,26106-060162,,"BOLT M 6X 16 PLATED",2,,,,,,N,,,EXXX,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1,1,,129001-32001,,"PUMP ASSY, LUB. OIL",1,,,,,,,,,,,,,,,,
14,1,,129150-32020,,"GASKET, L.O. PUMP",1,,,,,,,A,,,,,,,,,
15,1,,26450-060252,,"BOLT M 6X 25",4,,,,,,,,,,,,,,,,
16,1,,119812-34800,,"DIPSTIC, LUB OIL",1,,,,,,,,,,,,,,,,
17,1,,121520-34810,,"GUIDE, DIPSTICK",1,,,,,,,,,,,,,,,,
18,1,,129150-35041,,"GASKET, (NON-ASB.)",1,,,,,,,A,,,,,,,,,
19,1,,119810-35401,,"PIPE ASSY, OIL INLET",1,,,,,,,,,,,,,,,,
23,1,,26106-080352,,"BOLT M 8X 35 PLATED",2,,,,,,,,,,,,,,,,
24,1,,129150-35101,,"BRACKET, STRAINER",1,,,,,,,,,,,,,,,,
25,1,,129150-35111,,"GASKET, (NON-ASB.)",1,,,,,,,A,,,,,,,,,
26,1,,129150-35151,,"FILTER 80X80L",1,,,,,,,,,,,,,,,,
27,1,,129001-35300,,"BOLT,LUB.O. STRAINER",1,,,,,,,,,,,,,,,,
28,1,,129150-35350,,NUT,1,,,,,,,,,,,,,,,,
29,1,,24311-000160,,"O-RING 1A P-16.0",1,,,,,,,A,,,,,,,,,
30,1,,26106-080202,,"BOLT M 8X 20 PLATED",3,,,,,,,,,,,,,,,,
31,1,,124160-39140,,"BOLT 10, PIPE JOINT",1,,,,,,,,,,,,,,,,
32,1,,119810-39200,,"PIPE ASSY, LUB. OIL",1,,,,,,,,,,,,,,,,
36,1,,124550-59820,,"BOLT 8, PIPE JOINT",1,,,,,,,,,,,,,,,,
37,1,,22190-080002,,"SEAL WASHER 8S",2,,,,,,,,,,,,,,,,
38,1,,23414-100000,,"GASKET 10, ROUND",2,,,,,,,A,,,,,,,,,
39,1,,124160-39450,,"SWITCH, OIL PRESSURE",1,,,,,,,,,,,,,,,,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 36 pages

The full manual includes:

- All 36 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 3TNE78A-B1 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual