How to read Parts Catalog

見出 REF NO.	部品番号 PARTS NO.	部品名 Description	数量 Q'ty	互換性 I	R	備考

ENGINE
3TNE82A-TB
S/N 12510009-12510451
2006.06.28

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

目次 CONTENST

コウモクNO. GROUP	コウモク メイ	GROUP NAME
1	ｼﾘﾝﾀﾞﾌﾞﾛｯｸ	CYLINDER BLOCK
2	ｷﾞﾔｹｰｽ	GEAR HOUSING
3	ﾌﾗｲﾎｲﾙﾊｳｼﾞﾝｸﾞ & ｵｲﾙﾊﾟﾝ	FLYWHEEL HOUSING & OIL SUMP
4	ｼﾘﾝﾀﾞﾍｯﾄﾞ & ﾎﾞﾝﾈｯﾄ	CYLINDER HEAD & BONNET
5	ｷｭｳｷﾏﾆﾎｰﾙﾄﾞ & ｴｱｸﾘｰﾅ	SUCTION MANIFOLD & AIR CLEANER
6	ﾊｲｷﾏﾆﾎｰﾙﾄﾞ & ｻｲﾚﾝｻ	EXHAUST MANIFOLD & SILENCER
7	ｶﾑｼｬﾌﾄ & ｸﾄﾞｳｷﾞﾔ	CAMSHAFT & DRIVING GEAR
8	ｸﾗﾝｸｼｬﾌﾄ & ﾋﾟｽﾄﾝ	CRANKSHAFT & PISTON
9	LOｼｽﾃﾑ	LUB.OIL SYSTEM
10	CWｼｽﾃﾑ	COOLING WATER SYSTEM
11	FOﾌﾝｼｬﾎﾟﾝﾌﾟ	FUEL INJECTION PUMP
12	ｶﾞﾊﾞﾅ	GOVERNOR
13	FOﾌﾝｼｬﾍﾞﾝ	FUEL INJECTION VALVE
14	FOﾊﾟｲﾌﾟ	FUEL LINE
15	ｽﾀｰﾃｲﾝｸﾞﾓｰﾀ	STARTING MOTOR
16	ｼﾞｪﾈﾚｰﾀ	GENERATOR
17	ﾊﾟｯｷﾝｾｯﾄ	GASKET SET

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
101304-59020	14	14
101720-55750	14	29
102103-55520	14	8
	14	24
103854-39140	14	13
104200-55321	14	20
104200-55330	14	3
	14	21
104200-55341	14	22
104200-55750	14	5
	14	30
104200-92350	17	27
104211-11180	4	18
104211-11370	4	22
105025-59750	13	57
110250-55610	14	7
	14	25
114250-39450	9	I 36- 1
114250-53080	13	5
114250-53120	13	9
114250-53130	13	10
114250-53140	13	11
114250-53210	13	12
114250-53400	13	13
119032-77910	16	14
119131-18320	6	6
	6	15
119140-12680	5	13
119259-44570	10	I 32
119266-49350	10	29
119285-77951	12	78
119305-59120	13	20
119620-01750	3	3
119620-02020	1	7
119625-11870	4	23
	17	6
119625-11880	4	24
	17	7
119625-11900	4	25
119632-77920	16	15
119640-01640	3	9
119640-13510	6	16
119640-34800	9	16
119640-92750	17	28
119660-61901	12	56
119808-12520	5	10
119808-12540	5	12
119810-01200	1	22
119810-01730	3	6
119810-01780	3	17
119810-01790	3	8
119810-02800	1	15
119810-02870	1	24
119810-02930	1	18
119810-02940	1	27
119810-11100	4	15
119810-11110	4	16
119810-11120	4	17
119810-11240	4	27
119810-13110	6	2
	17	11
119810-14400	7	2
119810-14580	7	3
119810-23200	8	30
119810-23600	8	31
119810-23610	8	33
119810-23910	8	29
119810-35401	9	19
119810-39200	9	32
119810-42001	10	1
119810-51040	11	6
119810-55340	14	2
119810-55650	14	9
119810-77340	16	12
119812-01330	1	23
	17	2
119812-11700	4	7
119813-12100		2
119813-12110	5	1
	17	10
119813-21000	8	1
119813-22080	8	17
119813-22300	8	23
119813-22500	8	19
119813-22900	8	35
119813-44580	10	I 36
119813-59812	13	25
119813-59821	13	29
119813-59831	13	33
119820-77340	16	9
119823-12210	5	I 25- 1
119823-13600	6	8
119823-42000	10	1- 1
119833-55620	14	1
119836-77201	16	1
119836-77920	16	I 4
119840-13100	6	1
119840-13150	6	11
119840-13650	6	12
119840-59500	13	I 38A
119840-59560	13	I 39
119840-59570	13	40
119840-59601	14	34
119840-59621	14	37
119859-49010	10	48
119865-11210	4	26
119865-11310	4	47
	17	8
119865-21600	8	16
119866-12541	5	11
119867-77331	16	11
119869-12210	5	25
119869-49020	10	49
119910-12210		5
119910-12510	5	9
119910-12560	5	6
121023-01550	2	25
121111-21501	8	12
121120-13590	6	17
121250-44590	10	33
121250-44590	10	33
121250-44901	10	27
121250-55620	14	10
121250-59550	13	38
121254-55510	14	6
121256-44600	10	46
121257-55720	14	26
121257-55731	14	27
121450-01560	2	6
121450-44531	10	40
121470-44581	10	42
121520-34810	9	17
121520-44740	10	19
121550-49111	10	55
121750-49110	10	56
121850-21680	8	11
	2	12
121850-51960	17	4
121855-12060	5	23
122117-51560	11	50
122710-51090	11	10
124060-11800	4	11
124064-55510	14	23
124066-59100	13	37
	13	38B
124160-01751	2	7
	4	41
124160-01910	1	5
	1	11
	4	20
124160-11340	17	5
124160-11360	4	51
124160-39140	9	31
124240-01871	2	8
	2	I 9
124240-01883	17	I 3
124450-44550	10	44
124450-44560	10	41
	10	28
124465-44950	17	21
124550-51350	11	32
124550-51370	11	33
124550-59820	9	38
124550-59830	9	37
124550-66370	12	58
124550-77030	15	31
124701-11911	6	10
	6	23
	17	20
124736-07900	4	5
	13	56
124766-59050	14	16
	14	35
	4	21
124950-11340	17	12
124950-51190	11	17
129001-01250	1	12
129001-32001	9	1
129001-35300	9	27
129001-91841	2	21
129003-22950	8	37
129030-12201	5	24
129030-44520	10	31
129030-44760	10	20
129052-61050	12	5
129052-61060	12	6
129052-61070	12	7
129052-61390	12	30
129052-61500	12	31
129052-61540	12	46
129100-01580	3	1
	3	14
	8	2
129100-25061	7	9
129100-52200	11	93
129100-53100	13	6
129100-59951	13	42
129100-61400	12	16
129100-61440	12	75
129100-61650	12	76


Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

CYLINDER BLOCK

Y00D6941
3TNE82A-(E) TB

1 シリンダブロック
CYLINDER BLOCK




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6941
3TNE82A-(E) TB

5 キュウキマニホールド & エアクリーナ
SUCTION MANIFOLD &AIR CLEANER




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6941
3TNE82A-(E) TB

9 LOシステム
LUB.OIL SYSTEM




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6941
3TNE82A-(E) TB

15 スターティングモータ STARTING MOTOR



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

ｼﾘﾝﾀﾞﾌﾞﾛｯｸ　CYLINDER BLOCK

見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	719813-01560	ｼﾘﾝﾀﾞﾌﾞﾛｯｸASSY	BLOCK ASSY, CYLINDER	1			
5	124160-01910	・ﾌﾟﾗｸﾞ PT1/4	・PLUG PT1/4	2			
6	171051-01921	・ﾌﾟﾗｸﾞ NPTF1	・PLUG	1			
7	119620-02020	・ﾎﾞﾙﾄ (ﾒﾀﾙｷｬｯﾌﾟ	・BOLT	8			
10	23871-010000	・ﾈｼﾞﾌﾟﾗｸﾞPT 1/8	・PLUG PT1/8,SCREW	1			
I 10- 1	23876-010000 (A=EXXX)	・ﾈｼﾞﾌﾟﾗｸﾞPT1/8	・PLUG PT1/8,SCREW	1	N		
11	124160-01910	・ﾌﾟﾗｸﾞ PT1/4	・PLUG PT1/4	1			
12	27231-500000	・ｻﾗｶﾞﾀﾌﾟﾗｸﾞ 50	・PLUG 50	1			
I 12- 1	129001-01250 (A=EXXX)	・ｻﾗｶﾞﾀﾌﾟﾗｸﾞ 50	・PLUG 50	1	N		
13	27241-120000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 12	・PLUG 12	2			
14	27241-300000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 30	・PLUG 30	6			
15	119810-02800	・ﾒｲﾝﾍﾞｱﾘﾝｸﾞ	・MAIN BEARING	4			
18	119810-02930	・ｽﾗｽﾄﾍﾞｱﾘﾝｸﾞ	・BEARING, THRUST	2			
21	129795-02411	・ﾌﾞｯｼｭ (A	・BUSH, CAMSHAFT	1			
22	119810-01200	ﾍｯﾄﾞﾎﾞﾙﾄ	BOLT, CYL. HEAD	14			
23	119812-01330	ﾍｯﾄﾞｶﾞｽｹｯﾄ	GASKET, HEAD	1			
24	119810-02870	ﾒｲﾝﾍﾞｱﾘﾝｸﾞ U.S=0.25	MAIN BEARING US=0.25	4		(1)	ｱﾝﾀﾞｰｻｲｽﾞ(U.S=0.25)ﾌﾞﾋﾝﾃﾞｽ.
27	119810-02940	ｽﾗｽﾄﾒﾀﾙCMP 0.S=0.25	BEARING,THRUST .25OS	2		(2)	ｵｰﾊﾞｰｻｲｽﾞ(0.S=0.25)ﾌﾞﾋﾝﾃﾞｽ.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

スタ-テイング゛モ-タ　STARTING MOTOR


見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	129400-77012	スタ-タ (S13-294)	STARTING MOTOR	1			
2	129486-77400	・ アマチユア	・ ARMATUER	1			
3	171008-77410	・・ ヘ゛アリング゛(1)	・・ BEARING(1)	1			
4	171008-77420	・・ ヘ゛アリング゛(2)	・・ BEARING(2)	1			
5	129400-77441	・ フイ-ルト゛コイル CMP	・ FIELD COIL ASSY	1			
6	129486-77460	・・ フ゛ラシ (+)	・・ BRUSH	2			
7	129486-77470	・ フ゛ラシホルタ゛- シクミ	・ HOLDER ASSY, BRUSH	1			
8	129486-77460	・・ フ゛ラシ (+)	・・ BRUSH	2			
9	129486-77490	・・ スフ゜リング゛,フ゛ラシ	・・ SPRING,START BRUSH	4			
10	129900-77460	・ リヤカハ゛-	・ COVER, REAR	1			
11	171008-77510	・ キ゛アケ-ス	・ HOUSING ASSY, GEAR	1			
12	129400-77520	・ センタ-ハウシ゛ング゛	・ HOUSING, CENTER	1			
13	129400-77531	・ マグ゛ネチツク スイツチ CMP	・ SWITCH ASSY,MAGNETIC	1			
14	171008-77540	・ レハ゛- セツト	・ LEVER SET, SHIFT	1			
17	129400-77571	・ タ゛ストカハ゛-キツト(ノンアス)	・ DUST COVER,(NON-ASB.	1			
18	129900-77640	・ スロ-トホ゛ルト	・ BOLT, THROUGHT	2			
19	171008-77650	・ ピ゜ニオン シクミ	・ PINION ASSY	1			
20	171008-77660	・・ ピ゜ニオンシヤフト	・・ SHAFT, PINION	1			
21	171008-77670	・・ ストツハ゛-セツト	・・ STOPPER SET, PINION	1			
25	X2114555500	・・ クラツチ ASY	・・ CLUTCH ASSY	1			
26	X2114955020	・・・ ホ゛-ルヘ゛アリング゛(3	・・・ BALL BEARING	1			
27	X2240410100	・・・ ホ゛-ルヘ゛アリング゛(4	・・・ BALL BEARING	1			
28	26106-060322	・ ツハ゛ホ゛ルト 6X 32	・ BOLT M 6X 32 PLATED	2			
29	26106-060402	・ ツハ゛ホ゛ルト 6X 40	・ BOLT M 6X 40 PLATED	3			
30	26116-120252	ホ゛ルト 12X 25	BOLT M12X 25 PLATED	2			
31	124550-77030	カハ゛-(ST:Bタ-ミナル	COVER, TERMINAL	1			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6942
3TNE82A- (E) TB (Z)

10 CWシステム
COOLING WATER SYSTEM



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ｼﾘﾝﾀﾞﾍｯﾄﾞ & ﾎﾞﾝﾈｯﾄ　CYLINDER HEAD & BONNET

見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	129900-07900	ﾂﾘｱｹﾞｶﾅｸﾞ	LIFTER, ENGINE	2			
2	26106-080142	ﾂﾊﾞﾎﾞﾙﾄ M 8X 14	BOLT M 8X 14 PLATED	4			
3	119802-11241	ﾍﾞﾝﾜﾝｼﾞｸ CMP	SHAFT ASSY, ROCKER	1			
4	119802-11251	・ﾍﾞﾝﾜﾝｼﾞｸ	・SHAFT, ROCKER ARM	1			
6	119802-11260	・ﾍﾞﾝﾜﾝｻﾎﾟｰﾄ (A	・SUPPORT, ROCKER ARM	2			
7	119802-11270	・ﾍﾞﾝﾜﾝｻﾎﾟｰﾄ (B	・SUPPORT, ROCKER ARM	2			
8	119802-11280	・ｳｴｺﾐﾎﾞﾙﾄ	・STUD	3			
9	129150-11280	・ﾍﾞﾝﾜﾝｼﾞｸﾊﾞﾈ	・SPRING	3			
10	119802-11650	・ﾍﾞﾝﾜﾝKIT	・ARM ASSY, ROCKER	6			
11	129150-11230	・・ｱｼﾞｬｽﾀ (ﾍﾞﾝｽｷﾏ	・・SCREW, VALVE	6			
13	129150-11750	・・ﾅｯﾄ M8XP1.0	・・NUT M8XP1.0	6			
14	104211-11370	ｷｬｯﾌﾟ(ﾊﾞﾙﾌﾞ	CAP, VALVE	6			
15	119802-11700	ｼﾘﾝﾀﾞﾍｯﾄﾞ CMP	HEAD ASSY, CYLINDER	1			
19	124060-11800	・ｷｭｳｷﾍﾞﾝｱﾝﾅｲ	・GUIDE, VALVE	3		(1)	ﾎﾖｳﾌﾞﾋﾝﾃﾞｽ
21	119802-11810	・ﾊｲｷﾍﾞﾝｶﾞｲﾄﾞ	・GUIDE, VALVE	3		(1)	ﾎﾖｳﾌﾞﾋﾝﾃﾞｽ
23	27241-400000	・ﾜﾝｶﾞﾀﾌﾞﾗｸﾞ 40	・PLUG 40	2			
24	119802-11100	・ﾊﾞﾙﾌﾞ(INT	・VALVE, INTAKE	3			
25	119802-11110	・ﾊﾞﾙﾌﾞ(EXH	・VALVE, EXHAUST	3			
26	119810-11120	・ﾍﾞﾝﾊﾞﾈ	・SPRING, VALVE	6			
27	104211-11180	・ｵｻｴ(ﾍﾞﾝﾊﾞﾈ	・RETAINER, SPRING	6			
28	124160-11340	・ﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ	・SEAL, VALVE STEM	3			
29	124950-11340	・ﾊﾞﾙﾌﾞｽﾃﾑｼｰﾙ	・SEAL, VALVE STEM	3			
30	27310-070001	・ｺｯﾀｰ(ｽﾃﾑ)7 2ｹ=1SET	・COTTER ASSY	6			
32	119802-11870	ﾌﾟﾛﾃｸﾀ(ﾉｽﾞﾙ	PROTECTOR, NOZZLE	3			
33	119625-11880	ﾉｽﾞﾙｼｰﾄ	SEAT, NOZZLE	3			
34	119802-11900	ﾉｽﾞﾙｵｻｴ	RETAINER, NOZZLE	3			
35	120270-54410	・・ｻﾞｶﾞﾈ(ｲﾝｼﾞｪｸﾀ	・・WASHER	3			
36	22351-060012	ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 6.0AX 12	SPRING PIN 6X12	2			
37	26106-080252	ﾂﾊﾞﾎﾞﾙﾄ 8X 25	BOLT M 8X 25 PLATED	2			
38	26106-080452	ﾂﾊﾞﾎﾞﾙﾄ 8X 45	BOLT M 8X 45 PLATED	3			
39	26106-080502	ﾂﾊﾞﾎﾞﾙﾄ 8X 50	BOLT M 8X 50 PLATED	6			
40	124160-01751	ﾌﾀ(ｵﾕｺｳ)	COVER,FILLER	1			
41	119802-11350	ﾎﾞﾝﾈｯﾄ CMP	BONNET ASSY, HEAD	1			
42	119802-03010	・ﾊﾞﾂﾌﾙﾌﾟﾚｰﾄ	・PLATE, BAFFLE	1			
43	129150-03070	・ﾊﾞﾂﾌﾙ(ﾌﾞﾘｰｻﾞ	・BAFFLE, BREATHER	1			
44	119802-03110	・ｾﾝﾀﾌﾟﾚｰﾄ	・PLATE, DIAPHRAGM	1			
45	119802-03121	・ﾌﾀ,ﾀﾞｲﾔﾌﾗﾑ	・COVER, DIAPHRAGM	1			
46	119802-03130	・ﾀﾞｲﾔﾌﾗﾑ	・DIAPHRAGM	1			
47	119802-03141	・ﾊﾞﾈ,ﾀﾞｲﾔﾌﾗﾑ	・SPRING, DIAPHRAGM	1			
50	119802-11310	・PK(ﾎﾞﾝﾈｯﾄ	・GASKET, BONNET	1			
51	22857-500100	・ﾀｯﾋﾟﾝﾈｼﾞ 5.0X10	・SCREW 5X10,TAPPING	4			
52	22857-500100	・ﾀｯﾋﾟﾝﾈｼﾞ 5.0X10	・SCREW 5X10,TAPPING	4			
53	124160-11360	ﾄﾂﾃ	KNOB	3			
54	24311-000120	Oﾘﾝｸﾞ 1A P 12.0	O-RING 1A P 12.0	3			
55	24311-000320	Oﾘﾝｸﾞ 1A P 32.0	O-RING 1A P-32.0	1			
56	977770-1207F	ｼﾘｺｰﾝｹｲ ｴｷｼﾞﾖｳｶﾞｽｹｯﾄ	GASKET, LIQUID	1		(2)	ｵﾌﾟｼｮﾝ ﾌﾞﾋﾝﾃﾞｽ

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 11 of 124 pages

The full manual includes:

- All 124 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 3TNE82A-TB, 3TNE82A-ETB, 3TNV82A-QTB, QTB1, TB125 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual