NUMERICAL INDEX

Part number	Page	Item
Y101304-59020	14	16
Y101720-55750	14	31
Y102103-55520	14	26
Y103854-39140	14	15
Y103954-13201	17	23
	6	17
Y104200-55321	14	2
	14	22
Y104200-55330	14	3
	14	23
Y104200-55341	14	24
Y104200-55750	14	10
	14	32
Y104200-92350	17	35
Y106500-44810	16	37
Y110250-55610	14	27
Y114250-53080	13	5
Y114250-53120	13	9
Y114250-53130	13	10
Y114250-53140	13	11
Y114250-53210	13	12
Y114250-53400	13	13
Y114654-77900	16	36
Y119032-77910	16	36-1
Y119131-18320	6	5
Y119140-12680	5	27
Y119266-49350	10	27
Y119285-77951	12	78
Y119305-59120	13	47
Y119620-01750	3	3
Y119625-11870	17	19
	4	21
Y119625-11880	17	20
	4	22
Y119625-11900	4	23
Y119632-77920	16	35
Y119640-01640	3	9
Y119640-92750	17	36
Y119660-61901	12	56
Y119808-12520	5	24
Y119808-12540	5	26
Y119810-51040	11	7
Y119810-77340	16	32
Y119820-77340	16	28
Y119831-42290	10	15-1
Y119836-77200	16	1
Y119836-77201	16	1-1
Y119836-77700	16	2
Y119836-77710	16	4
Y119836-77721	16	5
Y119836-77730	16	6
Y119836-77741	16	7
Y119836-77750	16	8
Y119836-77760	16	9
Y119836-77770	16	10
Y119836-77780	16	11
Y119836-77790	16	15
Y119836-77800	16	16
Y119836-77810	16	19
Y119836-77820	16	20
Y119836-77830	16	21
Y119836-77840	16	17
Y119836-77850	16	3
Y119836-77860	16	18
Y119836-77871	16	12
Y119836-77880	16	13
Y119836-77890	16	14
Y119840-59560	13	35
Y119840-59570	13	36
Y119840-59601	14	37
Y119840-59621	14	40
Y119859-49020	10	52-1
Y119860-49010	10	51
Y119860-49020	10	52
Y119865-21600	8	14
Y119866-12541	5	25
Y119869-12210	5	18
Y119869-12220	5	33
Y119910-12210	5	6
Y119910-12510	5	23
Y119910-12560	5	7
Y120130-11860	4	7
Y121023-01550	2	25
Y121111-21501	8	40
Y121120-13590	6	10
Y121250-44590	10	44
Y121250-44901	10	41
Y121250-59550	13	34
Y121256-44600	10	39
Y121257-55720	14	28
Y121257-55731	14	29
Y121400-11340	17	17
	4	18
Y121450-01560	2	6
Y121450-44531	10	34
Y121470-44581	10	36
Y121520-34810	9	14
Y121520-44740	10	17
Y121550-23200	8	28
Y121750-49110	10	1
Y121850-21680	8	10
Y121850-51960	17	8
	2	12
Y121855-12060	5	30
Y122117-51560	11	50
Y122710-51090	11	10
Y123682-44210	10	43
Y124064-55510	14	25
Y124066-59100	13	33
Y124160-01751	2	7
	4	41
Y124160-01910	1	5
Y124160-11360	4	40
Y124160-39140	9	29
Y124160-39450	9	28-1
Y124160-39451	9	28
Y124240-01871	2	8
Y124240-01883	17	2
	2	9
Y124450-44550	10	38
Y124450-44560	10	35
Y124460-11340	17	18
	4	19
Y124465-44950	10	26
	17	24
Y124550-51350	11	32
Y124550-51370	11	33
Y124550-59820	9	35
Y124550-59830	9	34
Y124550-66370	12	58
Y124550-77030	15	31
Y124701-11911	17	32
	6	7
Y124736-07900	4	2
Y124766-59050	13	52
	14	19
	14	38
Y124950-51190	11	17
Y126150-25301	7	20
Y129001-01340	1	28
	17	15
Y129001-02800	1	15
Y129001-11310	17	16
	4	45
Y129001-11340	4	46
Y129001-11350	4	42
Y129001-11700	4	3
Y129001-12100	5	1
Y129001-12110	17	21
	5	3
Y129001-21000	8	1
Y129001-22081	8	15
Y129001-22500	8	17
Y129001-22901	8	31
Y129001-22950	8	33
Y129001-32001	9	1
Y129001-35300	9	24
Y129001-42002	10	2
Y129001-42040	10	29
Y129001-59910	13	21
Y129001-59920	13	25
Y129001-59930	13	29
Y129001-91840	2	21
Y129002-13501	6	8
Y129030-12200	5	32-1
	5	32-2
Y129030-12201	5	17
Y129030-13561	6	8-1
Y129030-13570	6	18
Y129030-13580	6	19
Y129030-13600	6	20
Y129030-44510	10	42-1
Y129052-55620	14	1
Y129052-61050	12	5
Y129052-61060	12	6
Y129052-61070	12	7
Y129052-61390	12	30
Y129052-61500	12	31
Y129052-61540	12	46
Y129100-01580	3	15
	3	1
	8	2
Y129100-01640	3	16
Y129100-01730	3	6
Y129100-11100	4	13
Y129100-11110	4	14
Y129100-11240	4	24
Y129100-11650	4	31
Y129100-23910	8	27
Y129100-25061	7	19
Y129100-42020	10	40
	17	6
Y129100-49840	10	24
	17	14
Y129100-51300	11	27
Y129100-52200	11	102
Y129100-53100	13	6
Y129100-55650	14	4
Y129100-55670	14	6
Y129100-55680	14	7

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

シリンダブロック　CYLINDER BLOCK

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	**Y729001-01560**	BLOCK ASSY, CYLINDER	1			
5	**Y124160-01910**	・ PLUG PT1/4	3			
6	**Y171051-01921**	・ PLUG	1			
7	**Y129150-02020**	・ BOLT, METAL CAP	8			
10	**Y23871-010000**	・ PLUG PT1/8, SCREW	1			
11	**Y27231-500000**	・ PLUG 50	1			
12	**Y27241-120000**	・ PLUG 12	2			
13	**Y27241-300000**	・ PLUG 30	6			
14	**Y129795-02411**	・ BUSH, CAMSHAFT	1			
15	**Y129001-02800**	・ MAIN BEARING	4			
24	**Y129150-02930**	・ METAL, THRUST	2			
27	**Y129150-01200**	STUD, CYL. HEAD	14			
28	**Y129001-01340**	GASKET, (NON-ASB.)	1			
29	**Y129150-02940**	METAL, THRUST OS=0.25	2		(1)	OVER-SIZED(O.S=0.25)PART.
32	**Y129150-02870**	MAIN METAL US=0.25	4		(2)	UNDER-SIZED(U.S=0.25)PART.


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER BLOCK

Y00D6840
3TNE88- (E) TB (1)

1 シリンダブロック
1 CYLINDER BLOCK




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FUEL INJECTION PUMP

Y00D6840
3TNE88- (E) TB (1)

11 FOフンシャポンプ
FUEL INJECTION PUMP




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6840
3TNE88- (E) TB (1)

16 ジェネレータ GENERATOR




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

EXHAUST MANIFOLD & SILENCER

Y00D6840
3TNE88- (E) TB (1)

6 ハイキマニホールド & サイレンサ
EXHAUST MANIFOLD & SILENCER




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SUCTION MANIFOLD & AIR CLEANER

Y00D6840
3TNE88- (E) TB (1)

5 キュウキマニホールド & エアクリーナ
SUCTION MANIFOLD & AIR CLEANER




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

How to read this Parts Catalog.

1. Parts mentioned in this Parts Catalog may not necessarily be standard equipping parts.
2. Parts change may be made without prior notice.
3. Form of this Parts Catalog.



Y00F2161 (1997.09.01)

Fig.29 燃料噴射ポンプ(ブーコン用)
FUEL INJECTION PUMP (W/BOOST)

A= 4JH-DT	D= 4JH-DTZA
B= 4JH-DTZ	E= 4JH-DTZY
C= 4JH-DTZP	F=

●見出 REF.No.	レベル LEV.	0	部品番号 PARTS No.	部品名	DESCRIPTION	個数 (Q'ty) A	B	C	D	E	F	I	R
1	•		729595-51390	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
1- 1	•		729595-51391	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
			(A=E/#00185)(B=E/#00200)										
3	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	9	9	9	9	9			
3- 1	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	4	4	4	4	4			K
			(A=E/#00185)(B=E/#00200)(C=E/#00156)(D=E/#00156)(E=E/#00156)										
4	••		129470-51040	カムシャフト	CAMSHAFT	1	1	1	1	1			
5	••		122710-51050	ベアリングキローラ	BEARING, ROLLER	2	2	2	2	2			
6	••		129470-51060	ベアリングオサエ	RETAINER	1	1	1	1	1			

備考	Remarks
(1) ブーストコンペンセータ付き、4JH-DT、4JH-DTZとも E/#00155までは、特別注文仕様とします	(1) BOOST COMPEMSATOR TYPE. OPTIONAL PART, TO E/#00155, (4JH-DT,4JH-DTZ)

① Ref. No.

The Ref. No. in the list may not be accord with the Ref. No. on illustration.

(Ex.) Illustration No. 1 — List head No. 1 (Befor change) ⟶ 1 − 1 (After change)

When interchangeable symbol N, R, and K, illustrations for new parts are sometimes omitted.

② Lev.(Level)

Indication and Meaning of Level

Level : Hereunder is given the relation among the number of dots(•),the level and the nominal parent- child relationship.

- • ……Parent parts(Assembly parts)
- •• ……Child parts included in "•" (Semi- Assembly parts,component parts of Assembly parts.)
- ••• ……Child parts included in "••", Grand- child parts in terms of "•". (Compornent parts of Semi- Assembly parts.)

Note) A parts of non- sale parts are illustlated but not listed.

③ Change Mark

Change Mark "I" is given to the part for which a desigh change was made at this time.
The design change was not shown in the last published Parts Catalog.

④ Interchangeability Mark

In the case where a part change took place,one of the following interchangeability marks is indicated for that part.

Symbol	interchangeability	Contents note
N	Old ⟶ New	New Part is interchangeable for Old Part but not interchangeable conversely.
Q	Old ⟶ New	New Part is not interchangeable for Old Part but interchangeable conversely.
R	Old ⟷ New	New Part is interchangeable for Old Part and vice versa.
S	Old ⟷ New	New Part is not interchangeable for Old Part and vice versa.
W		Part newly added.
Z		Part discontinued.
F		Not interchangeable single part but interchangeable by set of the related parts.
K		Changed only in quantity used.

⑤ Effective Machine No.

When a part is changed,Effective Machine No. of a Model for which the part is applicable is indication in each column of (A)- (F).

Product Symbol	Product No.	Product Symbol	Product No.
C	Clutch No. Compressor No.	M	Machine No.
D	Drive No.	T	Tractor No.
E	Engine No.	Note1) ※	Date

Note1) Date may follow the symbol in some cases. (Ex.) ※ 1996.01
Note2) As far as engine models shown by "XXX" are concerned, the modification of the parts could not be predicted or the engine models themselves could not be identified.
Note3) (A=E/#00185) means that the design change on the part has been effective for the model at the column (A)(in this case, for 4JH- DT) on and from E/#(Engine Serial Number) 00185.

⑥ Remarks Mark

Figures or alphabets (Symbols) are entered in the remark column.
The comments(remarks)on the pertinent parts are indicated in the lower part of the list by the same symbols as those stated above.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 52 pages

The full manual includes:

- All 52 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 3TNE88-TB, 3TNE88-TB1, 3TNE88-ETB, 3TNE88-ETB1, TB135, TB1, ETB, ETB1, 3TNE88-TB(1), 3TNE88-ETB(1), 3TNE88-(E) TB (1) Parts Catalog



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual