
NANE	PAGE
CYLINDER BLOCK	Fig. 1
GEAR HOUSING	Fig. 2
FLYWHEEL HOUSING & OIL SUMP	Fig. 3
CYLINDER HEAD & BONNET	Fig. 4
SUCTION MANIFOLD & AIR CLEANER	Fig. 5
EXHAUST MANIFOLD & SILENCER	Fig. 6
CAMSHAFT & DRIVING GEAR	Fig. 7
CRANKSHAFT & PISTON	Fig. 8
LUB. OIL SYSTEM	Fig. 9
COOLING WATER SYSTEM	Fig. 10
FUEL INJECTION PUMP	Fig. 11
GOVERNOR	Fig. 12
FUEL INJECTION VALVE	Fig. 13
FUEL LINE	Fig. 14
STARTING MOTOR	Fig. 15
GENERATOR	Fig. 16
GASKET SET	Fig. 17

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6840
3TNE88-(E)TB(1)

1 シリンダブロック
1 CYLINDER BLOCK



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ｼﾘﾝﾀﾞﾌﾞﾛｯｸ　CYLINDER BLOCK


見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	互換性 R	備考
1	729001-01560	ｼﾘﾝﾀﾞﾌﾞﾛｯｸASSY	BLOCK ASSY, CYLINDER	1			
5	124160-01910	・ﾌﾟﾗｸﾞ PT1/4	・PLUG PT1/4	3			
6	171051-01921	・ﾌﾟﾗﾌﾞ NPTF1	・PLUG	1			
7	129150-02020	・ﾎﾞﾙﾄ(ﾒﾀﾙｷｬｯﾌﾟ	・BOLT, METAL CAP	8			
10	23871-010000	・ﾈｼﾞﾌﾟﾗｸﾞ PT1/8	・PLUG PT1/8, SCREW	1			
11	27231-500000	・ｻﾗｶﾞﾀﾌﾟﾗｸﾞ 50	・PLUG 50	1			
12	27241-120000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 12	・PLUG 12	2			
13	27241-300000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 30	・PLUG 30	6			
14	129795-02411	・ﾌﾞｯｼｭ(A	・BUSH, CAMSHAFT	1			
15	129001-02800	・ﾒｲﾝﾒﾀﾙ CMP	・MAIN BEARING	4			
24	129150-02930	・ｽﾗｽﾄﾒﾀﾙ	・METAL, THRUST	2			
27	129150-01200	ﾍｯﾄﾞﾎﾞﾙﾄ	STUD, CYL. HEAD	14			
28	129001-01340	ﾍｯﾄﾞｶﾞｽｹｯﾄ(ﾉﾝｱｽ)	GASKET, (NON-ASB.)	1			
29	129150-02940	ｽﾗｽﾄﾒﾀﾙ 0.S=0.25	METAL, THRUST OS=0.25	2		(1)	ｵｰﾊﾞｰｻｲｽﾞ(0.S=0.25)ﾌﾞﾋﾝﾃﾞｽ
32	129150-02870	ﾒｲﾝﾒﾀﾙ U.S=0.25	MAIN METAL US=0.25	4		(2)	ｱﾝﾀﾞｰｻｲｽﾞ(U.S=0.25)ﾌﾞﾋﾝﾃﾞｽ

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6840
3TNE88- (E) TB (1)

11 FOフンシャポンプ
FUEL INJECTION PUMP




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D6840
3TNE88- (E) TB (1)

16 ジェネレータ GENERATOR





PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

Y00D6840
3TNE88- (E) TB (1)

17 パッキンセット
GASKET SET







PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
101304-59020	14	16
101720-55750	14	31
102103-55520	14	26
103854-39140	14	15
103954-13201	6	17
	17	23
104200-55321	14	2
	14	22
104200-55330	14	3
	14	23
104200-55341	14	24
104200-55750	14	10
	14	32
104200-92350	17	35
106500-44810	16	37
110250-55610	14	27
114250-53080	13	5
114250-53120	13	9
114250-53130	13	10
114250-53140	13	11
114250-53210	13	12
114250-53400	13	13
114654-77900	16	36
119032-77910	16	36-1
119131-18320	6	5
119140-12680	5	27
119266-49350	10	27
119285-77951	12	78
119305-59120	13	47
119620-01750	3	3
119625-11870	4	21
	17	19
119625-11880	4	22
	17	20
119625-11900	4	23
119632-77920	16	35
119640-01640	3	9
119640-92750	17	36
119660-61901	12	56
119808-12520	5	24
119808-12540	5	26
119810-51040	11	7
119810-77340	16	32
119820-77340	16	28
119831-42290	10	15-1
119836-77200	16	1
119836-77201	16	1-1
119836-77700	16	2
119836-77710	16	4
119836-77721	16	5
119836-77730	16	6
119836-77741	16	7
119836-77750	16	8
119836-77760	16	9
119836-77770	16	10
119836-77780	16	11
119836-77790	16	15
119836-77800	16	16
119836-77810	16	19
119836-77820	16	20
119836-77830	16	21
119836-77840	16	17
119836-77850	16	3
119836-77860	16	18
119836-77871	16	12
119836-77880	16	13
119836-77890	16	14
119840-59560	13	35
119840-59570	13	36
119840-59601	14	37
119840-59621	14	40
119859-49020	10	52-1
119860-49010	10	51
119860-49020	10	52
119865-21600	8	14
119866-12541	5	25
119869-12210	5	18
119869-12220	5	33
119910-12210	5	6
119910-12510	5	23
119910-12560	5	7
120130-11860	4	7
121023-01550	2	25
121111-21501	8	40
121120-13590	6	10
121250-44590	10	44
121250-44901	10	41
121250-59550	13	34
121256-44600	10	39
121257-55720	14	28
121257-55731	14	29
121400-11340	4	18
	17	17
121450-01560	2	6
121450-44531	10	34
121470-44581	10	36
121520-34810	9	14
121520-44740	10	17
121550-23200	8	28
121750-49110	10	1
121850-21680	8	10
121850-51960	2	12
	17	8
121855-12060	5	30
122117-51560	11	50
122710-51090	11	10
123682-44210	10	43
124064-55510	14	25
124066-59100	13	33
124160-01751	2	7
	4	41
124160-01910	1	5
124160-11360	4	40
124160-39140	9	29
124160-39450	9	28-1
124160-39451	9	28
124240-01871	2	8
124240-01883	2	9
	17	2
124450-44550	10	38
124450-44560	10	35
124460-11340	4	19
	17	18
124465-44950	10	26
	17	24
124550-51350	11	32
124550-51370	11	33
124550-59820	9	35
124550-59830	9	34
124550-66370	12	58
124550-77030	15	31
124701-11911	6	7
	17	32
124736-07900	4	2
124766-59050	13	52
	14	19
	14	38
124950-51190	11	17
126150-25301	7	20
129001-01340	1	28
	17	15
129001-02800	1	15
129001-11310	4	45
	17	16
129001-11340	4	46
129001-11350	4	42
129001-11700	4	3
129001-12100	5	1
129001-12110	5	3
	17	21
129001-21000	8	1
129001-22081	8	15
129001-22500	8	17
129001-22901	8	31
129001-22950	8	33
129001-32001	9	1
129001-35300	9	24
129001-42002	10	2
129001-42040	10	29
129001-59910	13	21
129001-59920	13	25
129001-59930	13	29
129001-91840	2	21
129002-13501	6	8
129030-12200	5	32-1
	5	32-2
129030-12201	5	17
129030-13561	6	8-1
129030-13570	6	18
129030-13580	6	19
129030-13600	6	20
129030-44510	10	42-1
129052-55620	14	1
129052-61050	12	5
129052-61060	12	6
129052-61070	12	7
129052-61390	12	30
129052-61500	12	31
129052-61540	12	46
129100-01580	3	1
	3	15
	8	2
129100-01640	3	16
129100-01730	3	6
129100-11100	4	13
129100-11110	4	14
129100-11240	4	24
129100-11650	4	31
129100-23910	8	27
129100-25061	7	19
129100-42020	10	40
	17	6
129100-49840	10	24
	17	14
129100-51300	11	27
129100-52200	11	102
129100-53100	13	6
129100-55650	14	4
129100-55670	14	6
129100-55680	14	7

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 7 of 97 pages

The full manual includes:

- All 97 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar TB135, 3TNE88–TB, TB1, ETB, ETB1, 3TNV88-QTB, QTB1, QTB2, 3TNE88-TB Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual