
Fig.1. CYLINDER BLOCK



Remarks
(1) UNDER-SIZE(U.S=0.25)PART.
(2) OVER-SIZE(O.S=0.25)PART.
(3) REPAIR PART.

1. CYLINDER BLOCK

(A)=3TNV88-DSA (D)=3TNV88-GGE
(B)=3TNV88-DSA2 (E)=
(C)=3TNV88-DSA3 (F)=


REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	729005-01561	BLOCK ASSY, CYLINDER	1	1	1	1				
5	2	124060-01050	PLUG PT1/8	1	1	1	1				
6	2	129001-01250	PLUG 50	1	1	1	1				
7	2	124160-01910	PLUG PT1/4	2	2	2	2				
8	2	124160-01910	PLUG PT1/4	1	1	1	1				
9	2	171051-01921	PLUG	1	1	1	1				
10	2	129150-02020	BOLT, METAL CAP	8	8	8	8				
13	2	129795-02411	BUSH, CAMSHAFT	1	1	1	1				
14	2	27241-120000	PLUG 12	2	2	2	2				
15	2	27241-300000	PLUG, 30	6	6	6	6				
25	2	129001-02930	MAIN BEARING SET	4	4	4	4				3
28	2	129150-02930	METAL, THRUST	2	2	2	2				
31	1	129004-01190	SPACER	1	1	1	1				
32	1	129150-01200	STUD, CYL. HEAD	14	14	14	14				
33	1	129001-01340	GASKET, (NON-ASB.)	1	1	1	1				
34	1	129150-02870	MAIN METAL US=0.25	4	4	4	4				1
37	1	129150-02940	METAL,THRUST.25(2PIE	1	1	1	1				2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.13. FUEL INJECTION VALVE



13. FUEL INJECTION VALVE

(A)=3TNV88-DSA (D)=3TNV88-GGE
(B)=3TNV88-DSA2 (E)=
(C)=3TNV88-DSA3 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	119305-59120	RETAINER	1	1	1	1				
4	2	129150-59131	BOLT M4X14,HEX.SCKT.	1	1	1	1				
5	1	129150-59120	RETAINER, INJ. PIPE	1	1	1	1				
8	2	129150-59131	BOLT M4X14,HEX.SCKT.	2	2	2	2				
10	1	129004-59810	PIPE ASSY, INJECTION	1	1	1	1				
14	1	129004-59820	PIPE ASSY, INJECTION	1	1	1	1				
18	1	129004-59830	PIPE ASSY, INJECTION	1	1	1	1				
23	1	119802-59550	PIPE ASSY, RETURN	1	1	1	1				
24	2	124722-59050	CLAMP 9	2	2	2	2				
25	2	119802-59560	PIPE, FUEL RETURN	1	1	1	1				
26	1	129486-59551	PIPE, FUEL RETURN	2	2	2	2				
27	2	124722-59050	CLAMP 9	4	4	4	4				
29	1	119593-59580	CAP	1	1	1	1				
30	1	124060-77680	CLAMP 10	1	1	1	1				
31	1	729004-53101	VALVE ASSY, F.INJECT	3	3	3					
32	1	729246-53101	VALVE ASSY, F.INJECT				3				
33	2	129004-53001	NOZZLE CMP	3	3	3					
34	2	129246-53001	NOZZLE CMP				3				
38	2	114250-53080	NUT, NOZZLE CASE	3	3	3	3				
39	2	119802-53100	HOLDER ASSY, NOZZLE	3	3	3	3				
43	2	114250-53120	SPRING, NOZZLE	3	3	3	3				
44	2	114250-53130	SEAT, NOZZLE SPRING	3	3	3	3				
45	2	114250-53140	PLATE, STOP	3	3	3	3				
46	2	114250-53210	PIN	6	6	6	6				
47	2	114250-53400	SHIM PACK	3	3	3	3				


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Y00R5640

Fig.11. COOLING WATER SYSTEM



Y00R5640 **11. COOLING WATER SYSTEM**

(A)=3TNV88-DSA (D)=3TNV88-GGE
(B)=3TNV88-DSA2 (E)=
(C)=3TNV88-DSA3 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	129004-42001	PUMP ASSY, WATER	1	1	1	1				
3	2	129100-42051	GASKET, (NON-ASB.)	1	1	1	1				
4	2	129100-42121	PLATE	1	1	1	1				
8	2	121850-42410	SCREW	3	3	3	3				
10	2	119802-49113	JOINT	2	2	2	2				
11	2	23876-010000	PLUG PT1/8,SCREW	1	1	1	1				
12	2	23876-020000	PLUG PT1/4,SCREW	1	1	1	1				
13	2	129916-49740	PLUG, DRAIN R03	2	2	2	2				


PREVIEW - YOUFIXTHIS.COM


Blurred on purpose. The manual you buy has this page in full quality.

Download full manual at youfixthis.com

Y00R5640

Fig.17. GENERATOR





Y00R5640 17. GENERATOR

(A)=3TNV88-DSA (D)=3TNV88-GGE
(B)=3TNV88-DSA2 (E)=
(C)=3TNV88-DSA3 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	129795-01900	STUD	1	1	1	1				
2	1	129423-77200	GENERATOR	1	1	1	1				
3	2	X9490561001	NUT	1	1	1	1				
4	2	119620-77380	ROTOR ASSY	1	1	1	1				
5	3	123501-79240	BEARING, BALL	1	1	1	1				
6	3	119620-79250	COVER, BEARING	1	1	1	1				
7	3	119620-79360	THRUST WASHER	1	1	1	1				
8	2	119620-77421	FLAME ASSY, DRIVE	1	1	1	1				

PREVIEW - YOUFIXTHIS.COM

Blurred on purpose. The manual you buy has this page in full quality.

Download full manual at youfixthis.com

Y00R5640

Fig.7. EXHAUST MANIFOLD

Y00R5640 7. EXHAUST MANIFOLD

(A)=3TNV88-DSA (D)=3TNV88-GGE
(B)=3TNV88-DSA2 (E)=
(C)=3TNV88-DSA3 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	129004-13109	MANIFOLD, EXHAUST	1	1	1	1				
2	1	129150-13110	GASKET, EXH.MANIFOLD	1	1	1	1				
3	1	119131-18320	BOLT M 8X 22	4	4	4	4				
4	1	123900-13630	BOLT 8X80	4	4	4	4				
5	1	123900-13610	STUD BOLT M 8X 80	2	2	2	2				
6	1	26306-080002	NUT	2	2	2	2				
7	1	129004-13200	GASKET, SILENCER	1	1	1	1				

PREVIEW - YOUFIXTHIS.COM

Blurred on purpose. The manual you buy has this page in full quality.

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 5 of 29 pages

The full manual includes:

- All 29 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 3TNV88-GGE, 3TNV88-DSA, 3TNV88-DSA2, 3TNV88-DSA3, TNV SERIES, 3TNV84T-GGE, 3TNV84T-KSA, 3TNV82A-GGE, 3TNV82A-DSA Parts Catalog



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual