
NAME	PAGE
CYLINDER BLOCK	Fig. 1
GEAR HOUSING	Fig. 2
FLYWHEEL HOUSING & OIL SUMP	Fig. 3
CYLINDER HEAD & BONNET	Fig. 4
AIR CLEANER	Fig. 5
EXHAUST MANIFOLD & SILENCER	Fig. 6
CAMSHAFT & DRIVING GEAR	Fig. 7
CRANKSHAFT & PISTON	Fig. 8
LUB.OIL SYSTEM	Fig. 9
COOLING WATER SYSTEM	Fig. 10
FUEL INJECTION PUMP	Fig. 11
GOVERNOR	Fig. 12
FUEL INJECTION VALVE	Fig. 13
FUEL LINE	Fig. 14
STARTING MOTOR	Fig. 15
GENERATOR	Fig. 16
GASKET SET	Fig. 17

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER BLOCK



Y00D8560	1. シリンダブロック				
3TNV70-STB		1:05.05			PLUS

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

ｼﾘﾝﾀﾞﾌﾞﾛｯｸ　CYLINDER BLOCK

見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	719515-01560	ｼﾘﾝﾀﾞﾌﾞﾛｯｸ ASSY	BLOCK ASSY, CYLINDER	1			
5	124060-01050	・ﾌﾟﾗｸﾞ	・PLUG PT1/8	1			
6	105311-01090	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ30	・PLUG 30 (SUS)	4			
7	119623-01250	・ｻﾗｶﾞﾀﾌﾟﾗｸﾞ 45	・PLUG 45	1			
8	124160-01910	・ﾌﾟﾗｸﾞ PT1/4	・PLUG PT1/4	1			
9	119285-01990	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 25	・PLUG 25	3			
10	119620-02020	・ﾎﾞﾙﾄ (ﾒﾀﾙｷｬｯﾌﾟ	・BOLT	8			
13	119717-02410	・ﾌﾞｯｼｭ	・BUSH, CAMSHAFT	1			
14	27241-120000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 12	・PLUG 12	1			
15	719717-02900	・ﾒｲﾝﾒﾀﾙ CMP(STDﾎﾖｳﾋﾝ)	・MAIN BEARING SET	4		(2)	ﾎﾖｳﾌﾞﾋﾝﾃﾞｽ
27	119717-02930	・ｽﾗｽﾄﾍﾞｱﾘﾝｸﾞ	・BEARING, THRUST	2			
30	119515-01200	ﾍｯﾄﾞﾎﾞﾙﾄ	BOLT, CYLINDER HEAD	14			
31	119515-01330	ﾍｯﾄﾞｶﾞｽｹｯﾄ	GASKET, CYL.HEAD	1			
32	119810-02940	ｽﾗｽﾄﾒﾀﾙCMP 0.S=0.25	BEARING,THRUST .250S	2		(1)	ｵｰﾊﾞｰｻｲｽﾞ(0.S=0.25)ﾌﾞﾋﾝﾃﾞｽ
35	719717-02910	ﾒｲﾝﾒﾀﾙ CMP 0.25US	MAIN METAL US=0.25	4		(3)	ｱﾝﾀﾞｰｻｲｽﾞ(U.S=0.25)ﾌﾞﾋﾝﾃﾞｽ

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com



Y00D8560	8. クランクシャフト & ピストン				
3TNV70-STB		1·05 05			PLUS

PREVIEW ONLY YOUFIXTHIS.COM


Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Y00D8560	10. CWシステム				
3TNV70-STB	1:05.05				PLUS


Download full manual at youfixthis.com



PREVIEW-YOUFIXTHIS.COM

Y00D8560	11. FOフンシャポンプ			
3TNV70-STB	1:05.05			PLUS

Download full manual at youfixthis.com



PREVIEW ONLY YOUFIXTHIS.COM

Y00D8560	15. スターティングモータ				
3TNV70-STB	1·05 05				PLUS

Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
101304-59020	14	13
101720-55750	14	26
102103-55520	14	5
	14	21
103854-39140	14	12
103954-13201	6	8
	17	24
104200-55321	14	17
104200-55330	14	2
	14	18
104200-55341	14	19
104200-55750	14	9
	14	27
104200-92350	17	25
105010-11490	4	5
105027-12580	5	6
105311-01090	1	6
105425-01690	3	10
110250-55610	14	6
	14	22
114250-39450	9	10
118200-53010	13	2
118400-51370	11	55
119131-18320	6	5
119233-77932	12	125
119258-44740	10	20
119266-49350	10	28
119285-01990	1	9
119285-11990	4	13
119305-35151	9	3
119332-92751	17	26
119336-12570	5	5
119515-01200	1	30
119515-01330	1	31
	17	2
119515-01720	3	7
119515-01770	3	9
119515-11100	4	15
119515-11110	4	16
119515-11200	4	23
119515-11240	4	24
119515-11280	4	28
119515-11310	4	48
	17	6
119515-11320	4	49
119515-11330	4	50
	17	16
119515-11380	4	37
119515-11740	4	6
119515-11800	4	11
119515-12520	5	3
119515-12600	5	8
119515-13200	6	7
	17	8
119515-13550	6	9
119515-14400	7	2
119515-14580	7	3
119515-21700	8	1
119515-22080	8	16
119515-22300	8	22
119515-22500	8	18
119515-22550	8	34
119515-22900	8	32
119515-23000	8	24
119515-23600	8	30
119515-23610	8	38
119515-34801	9	1
119515-35080	9	5
119515-42020	10	13
	17	20
119515-42041	10	3
119515-51100	11	10
119515-59540	13	13
119515-59580	13	12
119515-59581	13	
119515-61440	12	21
119515-77010	15	2
119517-53001	13	1
119517-53010	13	3
119527-44601	10	44
119527-44610	10	46
119527-44630	10	47
119527-44640	10	48
119540-07920	4	60
119540-12500	5	2
119540-42000	10	1
119540-44500	10	42
119540-59570	13	20
119546-59810	13	9
119546-59820	13	10
119546-59830	13	11
119600-11460	4	4
	17	15
119620-01750	3	4
119620-02020	1	10
119620-14200	7	1
119620-21500	8	8
119620-21941	8	15
119620-59700	13	23
119620-77380	16	5
119620-77421	16	8
119620-77440	16	13
119620-77461	16	14
119620-77471	16	15
119620-77490	16	25
119620-79200	16	9
119620-79210	16	10
119620-79220	16	11
119620-79230	16	12
119620-79250	16	7
119620-79260	16	16
119620-79290	16	18
119620-79300	16	19
119620-79310	16	20
119620-79320	16	21
119620-79330	16	22
119620-79340	16	23
119620-79350	16	24
119620-79360	16	26
119621-21680	8	14
119623-01250	1	7
119624-32040	2	20
	17	13
119646-77900	16	35
119660-01911	2	19
119660-61300	12	78
119660-61901	12	66
119717-01501	2	1
119717-01521	2	6
119717-01570	2	3
119717-01601	3	2
119717-01750	2	18
119717-01800	2	8
119717-02410	1	13
119717-02930	1	27
119717-03031	4	38
119717-03070	4	39
	4	40
119717-11131	4	17
119717-11190	4	19
119717-11260	4	27
119717-11340	4	20
	17	4
119717-11350	4	21
	17	9
119717-11650	4	29
119717-13110	6	2
	17	7
119717-13600	6	3
119717-21200	8	6
119717-21650	8	13
119717-23200	8	29
119717-23910	8	28
119717-25050	7	10
119717-25100	7	11
119717-25930	7	16
119717-32050	2	21
	17	14
119717-32060	9	4
	17	12
119717-32080	2	11
119717-32100	2	10
119717-32110	2	15
119717-32120	2	16
119717-39210	9	11
119717-42031	10	4
119717-42320	10	11
119717-42350	10	18
119717-51030	11	6
119717-51060	11	7
119717-51070	11	8
119717-51150	7	17
119717-51180	11	15
119717-51190	11	16
119717-51200	11	17
119717-51300	11	44
119717-51330	11	47
119717-51420	11	86
119717-51480	11	91
119717-51490	11	92
119717-51500	11	65
119717-51710	11	76
119717-51750	11	77
119717-51760	11	78
119717-61050	12	2
119717-61060	12	3
119717-61070	12	4
119717-61120	12	8
119717-61130	12	9
119717-61140	12	10
119717-61150	12	11
119717-61200	12	74
119717-61400	12	14
119717-61550	12	89
119717-77340	16	2
119717-77800	4	57
119717-77820	4	58
119718-13100	6	1
119718-49800	10	24
119734-01590	2	4

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 40 pages

The full manual includes:

- All 40 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 3TNV70- STB, TB016 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual