
パーツカタログの見方

1. このパーツカタログに記載されている部品は、必ずしも標準装備部品ではありません。
2. 部品変更は、予告なく行うことがあります。
3. パーツカタログリスト様式



Y00F2161 (1997.09.01)

Fig. 29 燃料噴射ポンプ(ブーコン用)
FUEL INJECTION PUMP (W/BOOST)

A=	4JH-DT	D=	4JH-DTZA
B=	4JH-DTZ	E=	4JH-DTZY
C=	4JH-DTZP	F=	

●見出 REF.No.	レベル LEV.	0	部品番号 PARTS No.	部品名	DESCRIPTION	個数 (Q'ty) A	B	C	D	E	F	I	R
1	•		729595-51390	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
1-1	•		729595-51391	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
	(A=E/#00185)(B=E/#00200)												
3	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	9	9	9	9	9			
I 3-1	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	4	4	4	4	4		K	
	(A=E/#00185)(B=E/#00200)(C=E/#00156)(D=E/#00156)(E=E/#00156)												
4	••		129470-51040	カムシャフト	CAMSHAFT	1	1	1	1	1			
5	••		122710-51050	ベアリングキローラ	BEARING, ROLLER	2	2	2	2	2			
6	••		129470-51060	ベアリングオサエ	RETAINER	1	1	1	1	1			

備考	Remarks
(1) ブーストコンペンセータ付き、4JH-DT、4JH-DTZとも E／#00155までは、特別注文仕様とします	(1) BOOST COMPEMSATOR TYPE. OPTIONAL PART, TO E／#00155, (4JH－DT,4JH－DTZ)

① 見出No.(REF.No.)

リスト頁の見出No.とイラスト図番の末尾が一致しない場合があります。

(例) イラスト図番 1　　リスト頁の見出No. 1 (変更前) ⟶ 1 [－1] (変更後)

互換性記号N、R、Kの場合は新部品のイラストを省略している場合があります。

② レベル (LEV.)

レベル
- • ……表示している • 印の数をレベルと呼び親子の関係を示します。(•は親部品です)
- •• ……は • に含まれる子部品です。
- ••• ……は •• に含まれる子部品 (•から見れば孫部品) です。

注) 非販売部品のイラストは一部展開しておりますが、リストには記載しておりません。

③ 変更マーク

前回出版したパーツカタログには無く、今回新規に設計変更が発生した部品について"Ⅰ"印が表示されます。

④ 互換性区分

部分変更が行われた場合、その部品に対して下記の互換性記号が表示されます。

記号	互換性	内容
N	旧 ⟷ 新	新部品は、旧部品に対して互換性有り、その逆は無し。
Q	旧 ⟷ 新	新部品は、旧部品に対して互換性無し、その逆は有り。
R	旧 ⟷ 新	新・旧部品双方に対して互換性有り。
S	旧 ⟷ 新	新・旧部品双方に対して互換性無し。
W		新規追加となった部品。
Z		廃止された部品。
F		単品では、互換性無し。但し関連部品セットにて互換性有り。
K		使用個数のみの変更。

⑤ 実施号機

部品が変更された時には、適用される商品形式の実施号機が (A) ～ (F) 欄毎に表示されます。

商品記号	商品 No.	商品記号	商品 No.
C	クラッチNo. コンプレッサNo.	M	本機No.
D	ドライブNo.	T	トラクタNo.
E	エンジンNo.	注1)※	西暦年月

注1) 記号の後の西暦年月を記載している事もあります。(例) ※1996. 01

注2) 実施号機が×××は、部品変更の予告又は、実施号機が確定できなかった部品です。

注3) (A＝E／#00185)は、A欄の商品形式(＝4JH－DT)の部品変更実施号機は、E／#(＝エンジンNo.)が00185号機以降であることを示します。

⑥ 備考(リマークス)区分

R …… 欄に数字又は、英字 (記号) を表示してあります。

リスト下段に上記の記号と同一記号を表記して当該部品に対するコメント(備考)を表示しています。

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Page	Index
Fig01	CYLINDER BLOCK
Fig02	GEAR HOUSING
Fig03	FLYWHEEL HOUSING & OIL SUMP
Fig04	CYLINDER HEAD & BONNET
Fig05	SUCTION MANIFOLD & AIR CLEANER
Fig06	EXHAUST MANIFOLD & SILENCER
Fig07	CAMSHAFT & DRIVING GEAR
Fig08	CRANKSHAFT & PISTON
Fig09	LUB.OIL SYSTEM
Fig10	COOLING WATER SYSTEM
Fig11	RADIATOR
Fig12	FUEL INJECTION PUMP
Fig13	FUEL INJECTION VALVE
Fig14	FUEL LINE
Fig15	STARTING MOTOR
Fig16	GENERATOR
Fig17	GASKET SET & TOOL
Fig18	FUEL INJECTION PUMP (INNER PARTS)
Fig19	GOVERNOR (INNER PARTS)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
Y104200-92350	1	6
Y105025-59750	1	28
Y114250-39450	10	14
Y114250-53080	10	16
Y114250-53120	10	17
Y114250-53130	10	18
Y114250-53140	10	20
Y114250-53210	10	21
Y118400-77170	10	29
Y119032-77910	10	31
Y119131-18320	10	35
Y119233-77932	10	37
Y119266-49350	10	41
Y119593-59581	10	44
Y119609-32040	11	102
	11	103
Y119620-01750	11	104
Y119620-77380	11	110
Y119620-77421	11	111
Y119620-77440	11	116
Y119620-77461	11	126
Y119620-77471	11	129
Y119620-77490	11	130
Y119620-79200	11	33
Y119620-79210	11	53
Y119620-79220	11	97
Y119620-79230	12	84
Y119620-79250	13	62
Y119620-79260	14	10
Y119620-79290	14	4
Y119620-79300	14	5
Y119620-79310	16	32
Y119620-79320	17	10
Y119620-79330	17	11
Y119620-79340	17	12
Y119620-79350	17	13
Y119620-79360	17	14
Y119625-11880	17	15
	17	16
Y119629-49080	17	17
Y119640-01640	17	18
Y119640-92750	17	19
Y119646-77900	17	20
Y119660-61901	17	21
Y119740-77250	17	22
Y119802-01561	17	3
Y119802-03110	17	4
Y119802-03121	17	5
Y119802-03130	17	6
Y119802-03141	17	7
Y119802-11260	17	8
Y119802-11270	17	9
Y119802-11280	2	12
Y119802-11870	2	13
	2	14
Y119802-25071	2	17
Y119802-25101	2	18
Y119802-25901	2	6
Y119802-35100	3	1
Y119802-35110	3	11
Y119802-39450	3	12
Y119802-49113	3	14
Y119802-49730	3	19
Y119802-51090	4	36
Y119802-51250	4	37
Y119802-51560	4	49
Y119802-51590	5	12
Y119802-51600	6	10
Y119802-51680	7	7
Y119802-51690	9	34
Y119802-53100	17	34
Y119802-55710	14	11
Y119802-55730	9	30
Y119802-59550	13	5
Y119802-59560	13	10
Y119802-77200	13	11
Y119802-77330	13	12
Y119803-01520	13	13
Y119803-21200	15	11
Y119803-25050	16	35
Y119803-53400	6	5
Y119803-77830	12	130
Y119807-61420	10	36
Y119865-21600	13	67
Y119934-01800	2	9
Y119934-59910	3	3
Y119940-55690	16	2
Y119940-77270	16	5
Y120130-11860	16	10
Y120270-54410	16	11
Y121023-01551	16	12
Y121111-21501	16	13
Y121120-13590	16	6
Y121250-44901	16	7
Y121256-44600	16	8
Y121267-44760	16	9
Y121400-11340	16	4
	16	15
Y121450-44531	16	17
Y121470-44581	16	18
Y121520-34810	16	20
Y121550-23200	16	22
Y121750-49110	16	23
Y121850-21680	16	24
Y121850-42410	16	25
Y121850-51960	16	26
	4	32
Y123501-79240	10	56
Y123900-13610	3	8
Y123900-13630	17	35
Y124060-01050	16	34
Y124060-77680	12	60
Y124160-01751	16	27
	2	5
Y124160-01910	4	43
	4	44
Y124160-11360	4	45
Y124160-39140	4	46
Y124195-77770	4	6
Y124240-01871	4	7
Y124395-49840	4	8
	4	31
Y124450-44550	7	13
Y124450-44560	7	10
Y124460-11340	7	16
	9	24
Y124465-44950	9	25
	9	32
Y124722-59050	10	10
	10	40
	11	7
	11	128
Y124766-59050	11	52
	11	58
Y129001-01250	11	59
Y129001-01340	11	63
	11	64
Y129001-02931	13	6
Y129001-32001	14	15
Y129001-91841	14	16
Y129002-21590	13	61
Y129004-03010	13	63
Y129004-11241	16	33
Y129004-11251	16	30
Y129004-11310	2	4
	8	4
Y129004-11350	7	9
Y129004-11650	13	14
Y129004-11900	4	56
Y129004-13129	12	23
Y129004-13200	8	14
	2	3
Y129004-42001	11	125
Y129004-42040	14	2
Y129004-49610	16	29
Y129004-49620	4	29
Y129004-49711	4	34
Y129004-49721	2	19
Y129004-55612	8	11
Y129005-11100	6	11
Y129005-21650	10	34
Y129005-22080	10	52
Y129005-22500	10	26
Y129005-22900	4	25
Y129005-22950	10	47
Y129005-34802	10	49
Y129005-59830	9	17
Y129008-11700	8	27
Y129008-21000	10	33
Y129008-51300	8	10
Y129008-51340	10	8
Y129008-77800	2	10
Y129008-77820	16	3
Y129052-79270	6	3
Y129100-01580	6	4
	1	4
	13	68
Y129100-01640	4	39
Y129100-01730	1	7
Y129100-11112	4	51
Y129100-23910	9	31
Y129100-35140	15	23
Y129100-42051	2	7
Y129100-42121	17	25
Y129100-55690	10	51
Y129129-14580	10	48
Y129136-59110	4	26
Y129150-01200	17	29
Y129150-02020	13	65
Y129150-02450	14	7
Y129150-02871	1	5
Y129150-02931	17	2
Y129150-02941	1	29
Y129150-03070	9	1
Y129150-11230	2	11
Y129150-11280	8	12
Y129150-11370	4	41
Y129150-11750	4	3
Y129150-11810	4	4
Y129150-12111	4	48

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


シリンダブロック　CYLINDER BLOCK

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	Y729005-01560	BLOCK ASSY, CYLINDER	1			
4	Y124060-01050	· PLUG PT1/8	1			
5	Y129001-01250	· PLUG 50	1			
6	Y124160-01910	· PLUG PT1/4	2			
7	Y124160-01910	· PLUG PT1/4	1			
8	Y171051-01921	· PLUG	1			
9	Y129150-02020	· BOLT, METAL CAP	8			
12	Y129795-02412	· BUSH, CAMSHAFT	1			
13	Y27241-120000	· PLUG 12	2			
14	Y27241-300000	· PLUG 30	6			
24	Y129150-02931	· METAL, THRUST	2			
27	Y129150-01200	STUD, CYL. HEAD	14			
28	Y129001-01340	GASKET, (NON-ASB.)	1			
29	Y129001-02931	MAIN BEARING SET	4		(1)	REPAIR PART.
32	Y129150-02871	MAIN METAL US=0.25	4		(2)	UNDER-SIZED(U.S=0.25)PART.
35	Y129150-02941	METAL,THRUST.25(4PIE	1		(3)	OVER-SIZED(O.S=0.25)PART.

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

CYLINDER BLOCK



Y00D9960	1, シリンダブロック				
3TNV88-BPTBZ	1, 08/01	2	3	PLUS	


PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Y00D9960	11, FOフンシャポンプ			
3TNV88-BPTBZ	1, 08/01	2	3	PLUS

Download full manual at youfixthis.com



Y00D9960	15, スターティングモータ			
3TNV88-BPTBZ	1, 08/01	2	3	PLUS

PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 7 of 42 pages

The full manual includes:

- All 42 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 3TNV88-BPTBZ, TB138FR Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual