
Fig.1. CYLINDER BLOCK

Fig. 1 CYLINDER BLOCK



Remarks
(1) UNDER-SIZE(U.S=0.25) PART.
(2) OVER-SIZE(O.S=0.25) PART.

1. CYLINDER BLOCK

(A)=4TN100E-GB1 (D)=
(B)=4TN100TE-GB1 (E)=
(C)=4T112TLE-GB1 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	719129-01560	BLOCK ASSY, CYLINDER	1	1						
4	3	171051-01921	PLUG	1	1						
5	3	119000-02410	BUSH, CAMSHAFT	1	1						
6	3	23871-010000	PLUG PT1/8,SCREW	1	1						
7	3	23871-030000	PLUG PT3/8,SCREW	1	1						
8	3	27241-140000	PLUG 14	4	4						
8-1	3	27241-140000	PLUG 14	3	3					K	
	(A=E/# 07152)	(B=E/# 04420)									
8A	3	119000-01880	SETSCREW,OIL GALLERY	1	1					W	
	(A=E/# 07152)	(B=E/# 04420)									
9	3	27241-400000	PLUG 40	5	5						
9-1	3	119593-01870	PLUG,CUP	5	5					R	
	(A=E/# 06692)	(B=E/# 04034)									
10	2	135400-01790	PLUG	1							
11	2	119000-01840	PLUG 25,RUBBER	3	3						
12	2	119000-02020	BOLT, METAL CAP	10	10						
15	2	719000-02800	BEARING, MAIN	5	5						
18	2	719000-02930	BEARING, THRUST	2	2						
21	2	119000-25050	SHAFT, IDLE GEAR	1	1						
22	2	135602-34390	RETAINER	1	1						
23	2	119000-39650	NOZZLE, PISTON JET	4	4						
24	2	119620-49290	COCK ASSY 1/4	1	1						
25	2	119000-35140	STUD, LUB.OIL FILTER	1	1						
26	2	129100-01580	PARALLEL PIN 8X16	2	2						
27	2	129100-01580	PARALLEL PIN 8X16	2	2						
28	2	129100-01580	PARALLEL PIN 8X16	2	2						
29	2	22351-030010	SPRING PIN 3X10	4	4						
30	2	22351-080016	SPRING PIN 8X16	2	2						
31	2	23414-100000	GASKET 10, ROUND	1							
32	2	23414-140000	GASKET 14, ROUND	1	1						
33	2	23857-030000	JOINT BOLT 3	4	4						
34	2	23871-020000	PLUG PT1/4,SCREW	1	1						
35	2	26013-080452	BOLT M 8X 45	2	2						
36	1	119100-35100	STRAINER	1	1						
36-1	1	119005-35100	STRAINER 80X100L,LO.	1	1					R	
	(A=E/# 02414)	(B=E/# 01858)									
37	1	119000-01200	BOLT, CYLINDER HEAD	18	18						
38	1	119100-01311	GASKET, HEAD T=1.3	1	1						
38-1	1	119100-01340	GASKET, HEAD T=1.3	1	1					R	
	(A=E/# 01691)	(B=E/# 00812)									
39	1	119100-01980	RETAINER	1	1						
40	1	26106-080162	BOLT M 8X 16 PLATED	2	2						
41	1	27231-600000	PLUG 60	1	1						
42	1	719000-02870	MAIN BEARING 0.25U.S	5	5						1
45	1	719000-02940	THRUST BEARING .25OS	2	2						2
48	1	119000-25100	GEAR ASSY, IDLE	1	1						
50	2	119000-25060	BUSH, IDLE GEAR	1	1						


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.7. TURBOCHARGER

Fig. 7 TURBO CHARGER



7. TURBOCHARGER

(A)=4TN100E-GB1 (D)=
(B)=4TN100TE-GB1 (E)=
(C)=4T112TLE-GB1 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	129792-18090	GASKET		1						
1-1	1	129472-18090 (B=E/# 02818)	GASKET		1						N
2	1	26366-080002	NUT M 8		4						
2-1	1	194990-22050 (B=E/# 02818)	NUT W/WASHER 8		4						R
3	1	119101-18020	TURBOCHARGER ASSY		1						
4	2	119101-18500	SHAFT, TURBINE		1						
5	2	129404-18510	BUSHING		1						
6	2	129404-18520	OIL THROWER		1						
7	2	129404-18530	SEAL RING, COMP.SIDE		1						
8	2	129404-18540	SEAL RING, COMP.SIDE		1						
9	2	129404-18550	SEAL RING, TURB.SIDE		1						
10	2	129404-18560	LOCK NUT		1						
11	2	119101-18510	WHEEL, BLOWER		1						
12	2	129404-18580	PLATE, SEAL		1						
13	2	129404-18590	BEARING, JOURNAL		2						
14	2	129404-18600	BEARING, THRUST		1						
15	2	119101-18520	HOUSING ASSY, BLOWER		1						
16	2	129403-18620	BOLT M 5X 10.5		6						
17	2	119101-18530	RETAINER		6						
18	2	119101-18540	HOUSING, TURBINE		1						
19	2	119101-18550	BOLT M 8		4						
20	2	119101-18560	RETAINER		4						
21	2	119101-18570	HOUSING, BEARING		1						
22	2	129404-18680	RING, RETAINING		3						
23	2	129406-18690	SCREW		4						
24	2	129406-18700	SCREW		3						
25	2	129404-18720	PROTECTOR, HEAT		1						


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.13. FUEL INJECTION PUMP

Fig. 13 FUEL INJECTION PUMP



Remarks
(1) GOVERNOR(FIG.NO.14) & FEED PUMP (FIG.NO.15) ARE INCORPORATED IN THIS FUEL INJECTION PUMP ASSY(FIG. NO.13.REF.NO.1 & 2).


(A)=4TN100E-GB1 (D)=
(B)=4TN100TE-GB1 (E)=
(C)=4T112TLE-GB1 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	719100-51310	PUMP W/GOV.& F.PUMP	1							1
2	1	719101-51310	PUMP W/GOV.& F.PUMP		1						1
4	2	119140-51030	CAMSHAFT, F.I.PUMP	1	1						
4-1	2	119100-51030	CAMSHAFT, F.I.PUMP	1	1						N
	(A=*)	(B=*)									
5	2	119000-51050	BEARING	1	1						
6	2	122710-51050	BEARING, ROLLER	1	1						
7	2	119000-51060	SUPPORT, BEARING	1	1						
8	2	124410-51960	O-RING	1	1						Z
	(A=*)	(B=*)									
9	2	119100-51080	COVER	1	1						
9-1	2	119100-51081	COVER	1	1						N
	(A=E/# 01743)	(B=E/# 00837)									
10	2	119100-51090	GASKET	1	1						
10-1	2	119100-51091	GASKET, LOWER COVER	1	1						N
	(A=E/# 01743)	(B=E/# 00837)									
11	2	144626-51090	KEY 5X19	1	1						
12	2	119000-51101	PLUNGER W/BARREL	4	4						
12-1	2	119100-51101	PLUNGER W/BARREL	4	4						N
	(A=*)	(B=*)									
15	3	119000-51150	DEFLECTOR	4	4						
15-1	3	119000-51151	DEFLECTOR	4	4						N
	(A=E/# 01565)	(B=E/# 00686)									
15A	3	119000-51430	PIN, DEFLECTOR	4	4						W
	(A=E/# 01565)	(B=E/# 00686)									
15B	3	22242-000200	CIRCLIP 20	4	4						W
	(A=E/# 01565)	(B=E/# 00686)									
16	2	119000-51161	SPRING	4	4						
17	2	119000-51170	SEAT A, PLNGR.SPRING	4	4						
18	2	119000-51181	SEAT B, PLNGR.SPRING	4	4						
19	2	119000-51201	TAPPET ASSY	4	4						
25	2	129155-51270	LOCKING, TAPPET	4	4						
26	2	129155-51280	O-RING S6	4	4						
27	2	128400-51300	VALVE W/SEAT, DELIV	4	4						
30	2	119000-51330	SPRING,DELIVERY VLV.	4	4						
31	2	119000-51340	HOLDER,DELIVERY VLV.	4	4						
32	2	122710-51350	GASKET, DELIVERY	4	4						
33	2	119000-51360	STOPPER, DELIVERY	4	4						
34	2	119000-51410	O-RING S18	8	8						
35	2	119000-51430	PIN, DEFLECTOR	4	4						Z
	(A=E/# 01565)	(B=E/# 00686)									
36	2	119000-51450	SHIM SET, CAMSHAFT	1	1						
40	2	119100-51500	RACK	1	1						
41	2	119000-51510	SLEEVE, CONTROL	4	4						
42	2	26366-080002	NUT M 8	8	8						
43	2	119000-51550	COVER, RACK	1	1						
44	2	119000-51570	GUIDE, RACK	2	2						
45	2	119000-51580	SCREW A, GUIDE CAP	1	1						
46	2	119000-51590	SCREW B, GUIDE CAP	1	1						
47	2	119000-51650	SHIM SET, ADJUSTING	8	8						
48	2	121850-51700	BUSHING, OIL FEED	1	1						
49	2	26716-060002	NUT M 6	3	3						
50	2	119000-51800	BOLT,BARREL MOUNTING	8	8						
51	2	124410-51860	GASKET	1	1						

++ CONTINUE ++

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com
(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.20. STARTING MOTOR



Remarks
(1) CERTAIN THE NAME PLATE, THEN PLACE YOUR ORDER. (REFER TO ILLUSTRATION).
* NAME PLATE¢S13-68£=REF.NO.2,7,8,10, 11.
* NAME PLATE¢S13-68A£=REF.NO.2-1,7-1, 8-1,10-1,11-1.


(A)=4TN100E-GB1 (D)=
(B)=4TN100TE-GB1 (E)=
(C)=4T112TLE-GB1 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	124610-77010	STARTER	1	1						
2	2	X213011001	ARMATURE ASSY	1	1						
2-1	2	121254-77402	ARMATURE ASSY	1	1					S	1
	(A=E/# 07608)	(B=E/# 04697)									
3	3	X21302302	BALL BEARING	1	1						
3-1	3	121254-77410	BALL BEARING	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
4	3	X21303302	BALL BEARING	1	1						
4-1	3	121254-77420	BALL BEARING	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
5	2	X21302115	WASHER KIT, THRUST	1	1						
5-1	2	121254-77430	WASHER KIT, THRUST	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
6	2	X21303119	STOPPER SET, PINION	1	1						
6-1	2	121254-77480	STOPPER KIT, PINION	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
7	2	X21308220	COIL ASSY, FIELD	1	1						
7-1	2	121254-77521	COIL ASSY, FIELD	1	1					S	1
	(A=E/# 07608)	(B=E/# 04697)									
8	3	X21308311	BRUSH (+)	2	2						
8-1	3	121254-77541	BRUSH (+)	2	2					S	1
	(A=E/# 07608)	(B=E/# 04697)									
9	2	X225013012	COVER, REAR	1	1						
9-1	2	124610-77550	REAR COVER ASSY	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
10	2	X21307305	HOLDER ASSY, BRUSH	1	1						
10-1	2	121254-77571	HOLDER	1	1					S	1
	(A=E/# 07608)	(B=E/# 04697)									
11	3	X21305312	BRUSH (-)	2	2						
11-1	3	121254-77581	BRUSH (-)	2	2					S	1
	(A=E/# 07608)	(B=E/# 04697)									
12	3	X21305313	SPRING, BRUSH	4	4						
12-1	3	121254-77590	SPRING, BRUSH	4	4					R	
	(A=E/# 07608)	(B=E/# 04697)									
13	2	X22501113	SHAFT ASSY, GEAR	1	1						
13-1	2	121254-77640	SHAFT ASSY, GEAR	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
14	2	X21304400	BEARING ASSY, CENTER	1	1						
14-1	2	121254-77600	BEARING ASSY, CENTER	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
15	3	X21301402	SEAL, OIL	1	1						
15-1	3	119129-77210	SEAL, OIL	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
16	3	X21302402	O-RING	1	1					Z	
	(A=E/# 07608)	(B=E/# 04697)									
17	2	X213035002	PINION ASSY	1	1						
17-1	2	121254-77661	PINION ASSY	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
18	2	X213046003	HOUSING ASSY, GEAR	1	1						
18-1	2	121254-77681	CASE ASSY, GEAR	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									
19	3	X21302601	METAL, CASE BEARING	1	1						
19-1	3	121254-77690	METAL, GEAR CASE	1	1					R	
	(A=E/# 07608)	(B=E/# 04697)									

++ CONTINUE ++

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com
(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.50. GENERATOR



50. GENERATOR


(A)=YEG45 (B)=YEG65 (C)=YEG90 (D)=YEG45-BS (E)=YEG65-BS (F)=YEG90-BS

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I R
1	1	982174-81180	STATOR SET(50HZ/200V	1			1			
2	1	982174-81190	STATOR SET(50HZ/220V	1			1			
3	1	982174-81200	STATOR SET(50HZ/380V	1			1			
4	1	982174-81210	STATOR SET(50HZ/400V	1			1			
5	1	982174-81220	STATOR SET(50HZ/415V	1			1			
6	1	982174-81230	STATOR SET(60HZ/220V	1			1			
7	1	982174-81240	STATOR SET(60HZ/380V	1			1			
8	1	982174-81250	STATOR SET(60HZ/440V	1			1			
9	1	982174-81260	STATOR SET(60HZ/480V	1			1			
10	1	982174-81270	STATOR SET(50HZ/200V		1			1		
11	1	982174-81280	STATOR SET(50HZ/220V		1			1		
12	1	982174-81290	STATOR SET(50HZ/380V		1			1		
13	1	982174-81300	STATOR SET(50HZ/400V		1			1		
14	1	982174-81310	STATOR SET(50HZ/415V		1			1		
15	1	982174-81320	STATOR SET(60HZ/220V		1			1		
16	1	982174-81330	STATOR SET(60HZ/380V		1			1		
17	1	982174-81340	STATOR SET(60HZ/440V		1			1		
18	1	982174-81350	STATOR SET(60HZ/480V		1			1		
19	1	982174-81360	STATOR SET(50HZ/200V			1			1	
20	1	982174-81370	STATOR SET(50HZ/220V			1			1	
21	1	982174-81380	STATOR SET(50HZ/380V			1			1	
22	1	982174-81390	STATOR SET(50HZ/400V			1			1	
23	1	982174-81400	STATOR SET(50HZ/415V			1			1	
24	1	982174-81410	STATOR SET(60HZ/220V			1			1	
25	1	982174-81420	STATOR SET(60HZ/380V			1			1	
26	1	982174-81430	STATOR SET(60HZ/440V			1			1	
27	1	982174-81440	STATOR SET(60HZ/480V			1			1	
28	1	982190-00040	GUARD	1			1			
29	1	982190-00050	GUARD		1	1		1	1	
30	1	26116-100302	BOLT M10X 30 PLATED	12	12	12	12	12	12	
31	1	22217-100000	SPRING WASHER 10	20	20	20	20	20	20	
32	1	982116-90320	ROTOR	1			1			
33	1	982116-90330	ROTOR		1			1		
34	1	982116-90340	ROTOR			1			1	
35	1	982314-51030	BOLT M10X 30	8			8			
36	1	982314-51035	BOLT M10X 35		8	8		8	8	
37	1	982117-10011	RESISTOR	1	2	2	1	2	2	
38	1	26557-040402	SCREW M 4X 40	1	2	2	1	2	2	
39	1	22217-040000	SPRING WASHER 4	1	2	2	1	2	2	
40	1	22117-040000	WASHER 4	1	2	2	1	2	2	
41	1	982512-10120	RECTIFIER	4			4			
42	1	982512-10130	RECTIFIER	3			3			
43	1	982512-10020	SILICON		4	4		4	4	
44	1	982512-10090	SILICON		3	3		3	3	
45	1	982117-40010	WASHER	16	16	16	16	16	16	
46	1	982111-90130	CONNECTOR	6	6	6	6	6	6	
47	1	982110-90130	COIL, FIELD	1			1			
48	1	982110-90120	COIL, EXCITER		1			1		
49	1	982110-90200	COIL, FIELD			1			1	
50	1	26116-060702	BOLT M 6X 70 PLATED	6			6			
51	1	26116-060802	BOLT M 6X 80 PLATED		6			6		
52	1	26116-061002	BOLT M 6X100 PLATED			6			6	
53	1	22217-060000	SPRING WASHER 6	10	10	10	10	10	10	
54	1	22117-060000	WASHER 6	10	10	10	10	10	10	

++ CONTINUE ++

PREVIEW ONLY YOUFIXTHIS.COM
Download full manual at youfixthis.com
(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.52. INSTRUMENT PANEL



(A)=YEG45 (D)=
(B)=YEG65 (E)=
(C)=YEG90 (F)=


REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	982519-60010	PANEL(50HZ-200V)	1							
1-1	1	982519-60011	PANEL(50HZ-200V)	1							N
	(A=G/# 44146)										
2	1	982519-60020	PANEL(50HZ-220V)	1							
2-1	1	982519-60021	PANEL(50HZ-220V)	1							N
	(A=G/# 44146)										
3	1	982519-60030	PANEL(50HZ-380V)	1							
3-1	1	982519-60031	PANEL(50HZ-380V)	1							N
	(A=G/# 44146)										
4	1	982519-60040	PANEL(50HZ-400V)	1							
4-1	1	982519-60041	PANEL(50HZ-400V)	1							N
	(A=G/# 44146)										
5	1	982519-60050	PANEL(50HZ-415V)	1							
5-1	1	982519-60051	PANEL(50HZ-415V)	1							N
	(A=G/# 44146)										
6	1	982519-60060	PANEL(60HZ-200V)	1							
6-1	1	982519-60061	PANEL(60HZ-200V)	1							N
	(A=G/# 44146)										
7	1	982519-60070	PANEL(60HZ-380V)	1							
7-1	1	982519-60071	PANEL(60HZ-380V)	1							N
	(A=G/# 44146)										
8	1	982519-60080	PANEL(60HZ-440V)	1							
8-1	1	982519-60081	PANEL(60HZ-440V)	1							N
	(A=G/# 44146)										
9	1	982519-60090	PANEL(60HZ-480V)	1							
9-1	1	982519-60091	PANEL(60HZ-480V)	1							N
	(A=G/# 44146)										
10	1	982519-60100	PANEL(50HZ-200V)		1						
10-1	1	982519-60101	PANEL(50HZ-200V)		1						N
		(B=G/# 20617)									
11	1	982519-60110	PANEL(50HZ-220V)		1						
11-1	1	982519-60111	PANEL(50HZ-220V)		1						N
		(B=G/# 20617)									
12	1	982519-60120	PANEL(50HZ-380V)		1						
12-1	1	982519-60121	PANEL(50HZ-380V)		1						N
		(B=G/# 20617)									
13	1	982519-60130	PANEL(50HZ-400V)		1						
13-1	1	982519-60131	PANEL(50HZ-400V)		1						N
		(B=G/# 20617)									
14	1	982519-60140	PANEL(50HZ-415V)		1						
14-1	1	982519-60141	PANEL(50HZ-415V)		1						N
		(B=G/# 20617)									
15	1	982519-60150	PANEL(60HZ-220V)		1						
15-1	1	982519-60151	PANEL(60HZ-220V)		1						N
		(B=G/# 20617)									
16	1	982519-60160	PANEL(60HZ-380V)		1						
16-1	1	982519-60161	PANEL(60HZ-380V)		1						N
		(B=G/# 20617)									
17	1	982519-60170	PANEL(60HZ-440V)		1						
17-1	1	982519-60171	PANEL(60HZ-440V)		1						N
		(B=G/# 20617)									
18	1	982519-60180	PANEL(60HZ-480V)		1						
18-1	1	982519-60181	PANEL(60HZ-480V)		1						N
		(B=G/# 20617)									

++ CONTINUE ++

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com
(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.4. BONNET

Fig. 4 BONNET



Remarks
(1) REPAIR PART.

 4. BONNET

(A)=4TN100E-GB1 (D)=
(B)=4TN100TE-GB1 (E)=
(C)=4T112TLE-GB1 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	719129-11520	BONNET ASSY	1	1						
2	2	124160-01751	CAP, LUB.OIL SUPPLY	1	1						
3	2	24311-000320	O-RING 1A P-32.0	1	1						
4	2	119100-11310	BONNET ASSY	1	1						
4-1	2 (A=*)	119100-11311 (B=*)	BONNET ASSY,HEAD	1	1					N	
9	1	26106-080252	BOLT M 8X 25 PLATED	10	10						
10	1	119006-03090	HOSE, BREATHER	1	1						
11	1	129150-03100	RETAINER	1	1						
12	1 (A=E/# 04718)	23000-022000 (B=E/# 03190)	CLAMP 22	1	1					Z	
13	1	119100-11360	GASKET, BONNET	1	1						1


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.38. FUEL INJECTION PUMP

Fig. 38 FUEL INJECTION PUMP



Remarks
(1) GOVERNOR(FIG.43) & FEED PUMP(FIG. 39) ARE INCORPORATED IN THIS FUEL INJECTION PUMP ASSY(REF.NO.1).

(A)=4TN100E-GB1 (D)=
(B)=4TN100TE-GB1 (E)=
(C)=4T112TLE-GB1 (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	723660-51300	PUMP W/GOV.& F.PUMP			1					1
3	2	124410-51031	CAMSHAFT, F.I. PUMP			1					
4	2	122710-51050	BEARING, ROLLER			1					
5	2	124410-51050	BEARING, TAPER ROLLE			1					
6	2	124410-51061	RETAINER (A)			1					
7	2	121850-51070	RETAINER (B).			1					
8	2	124410-51081	SEAL VC20 32 5, OIL			1					
9	2	123560-51100	PLUNGER W/BARREL			4					
12	2	122710-51160	SPRING, PLUNGER			4					
13	2	122710-51170	RETAINER, SPRING			4					
14	2	122710-51180	RETAINER, SPRING			4					
15	2	124410-51200	TAPPET			4					
20	3	124410-51250	BOLT, ADJUSTING			4					
21	2	174307-51250	PIN			4					
22	2	122710-51270	STOPPER, GUIDE			4					
23	2	123500-51300	VALVE W/SEAT, DELIV.			4					
26	2	121952-51330	SPRING, DELIV.			4					
27	2	124410-51341	RETAINER			4					
28	2	122710-51350	GASKET, DELIVERY			4					
28-1	2	124410-51350	GASKET (C=E/# 02337)			4					N
29	2	121952-51370	STOPPER, VALVE			4					
30	2	121850-51380	STOPPER (A)			2					
31	2	121850-51390	STOPPER (B)			2					
32	2	124410-51400	PROTECTOR			4					
33	2	121850-51450	SHIM SET			1					
37	2	121950-51500	RACK, CONTROL			1					
38	2	122710-51510	PINION, CONTROL			4					
39	2	122710-51520	STOPPER, RACK			1					
40	2	121850-51530	SPACER, SPRING			1					
41	2	122710-51540	SPRING, RACK			1					
42	2	124410-51550	SLEEVE			4					
43	2	122117-51560	SCREW, PINION			4					
44	2	122710-51571	SCREW (B), RACK BUSH			1					
45	2	122710-51580	BUSH, RACK			2					
46	2	122710-51590	SCREW (A), RACK BUSH			1					
47	2	123500-51600	CAP NUT, RACK			1					
48	2	124410-51600	SHIM SET			4					
57	2	121850-51700	BUSHING, OIL FEED			1					
58	2	122710-51701	PLUG, OIL FEED			1					
58-1	2	129795-51680	PLUG (C=E/# 03130)			1					N
59	2	144626-51700	SEAL WASHER			2					
59-1	2	22190-060002	SEAL WASHER 6S (C=E/# 03447)			2					N
60	2	122710-51721	O-RING 2017			1					
61	2	124410-51730	PLUG (A)			4					
62	2	121950-51751	COVER, SIDE			1					
63	2	121950-51761	GASKET, COVER			1					
64	2	122710-51790	O-RING			4					
65	2	122710-51870	O-RING S32			1					
66	2	122710-51880	LEAD			4					
67	2	124220-51890	RIVET, LABEL			2					
68	2	124410-51890	GASKET			1					

++ CONTINUE ++

PREVIEW OF YOUFIXTHIS.COM
Download full manual at youfixthis.com
(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

PREVIEW ONLY

You're viewing 8 of 100 pages

The full manual includes:

- All 100 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TN100E-GB1, 4TN100TE-GB1, 4T112TLE-GB1, YEG45/65/90-BS, YEG30/42/57S-BS, YEG45/65/90, YEG30/42/57S Parts Catalog



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual