```
[Info]
PcNo=Y00B4202
PcName=4TN84L-RBA(B50,-1)
JpnUse=1
JpnSec1=ƒGƒ“ƒWƒ“
JpnSec2=—§ ¬
JpnSec3=TN
JpnPreface=0
EngUse=1
EngSec1=ENGINE
EngSec2=SMALL VERTICAL (B)
EngSec3=TN
EngPreface=0
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
0,Y00B4202
1,001,,"ENGINE 4TN84L-RBA"
2,1,,"CYLINDER BLOCK",4TN84L-RBAVM,,,
2,2,,"GEAR HOUSING",4TN84L-RBAVM,,,
2,3,,"FLYWHEEL HOUSING &LUB.OIL SUMP",4TN84L-RBAVM,,,
2,4,,"CYLINDER HEAD & BONNET",4TN84L-RBAVM,,,
2,5,,"SUC. MANIFOLD & AIR CLEANER",4TN84L-RBAVM,,,
2,6,,"EXH. MANIFOLD & SILENCER",4TN84L-RBAVM,,,
2,7,,"CAMSHAFT & DRIVING GEAR",4TN84L-RBAVM,,,
2,8,,"CRANKSHAFT & PISTON",4TN84L-RBAVM,,,
2,9,,"LUB. OIL SYSTEM",4TN84L-RBAVM,,,
2,10,,"COOLING WATER SYSTEM",4TN84L-RBAVM,,,
2,11,,"FUEL INJECTION PUMP",4TN84L-RBAVM,,,
2,12,,"FUEL INJECTION LINE",4TN84L-RBAVM,,,
2,13,,"FUEL LINE",4TN84L-RBAVM,,,
2,14,,GOVERNOR,4TN84L-RBAVM,,,
2,15,,"STARTING MOTOR(PREVIOUS)",4TN84L-RBAVM,,,
2,16,,"STARTING MOTOR(NEW)",4TN84L-RBAVM,,,
2,17,,GENERATOR,4TN84L-RBAVM,,,
2,18,,"GASKET SET & TOOL(OPTIONAL)",4TN84L-RBAVM,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


```
1,1,,729405-01560,,"BLOCK ASSY, CYLINDER",1,,,,,,,,,,,,,,,
2,3,,124160-01910,,"PLUG PT1/4",2,,,,,,,,,,,,,,,
3,3,,124160-01910,,"PLUG PT1/4",1,,,,,,,,,,,,,,,
4,3,,171051-01921,,PLUG,1,,,,,,,,,,,,,,,
5,3,,23871-010000,,"PLUG PT1/8,SCREW",1,,,,,,,,,,,,,,,
6,3,,27231-500000,,"PLUG 50",1,,,,,,,,,,,,,,,
7,3,,27241-120000,,"PLUG 12",2,,,,,,,,,,,,,,,
8,3,,27241-300000,,"PLUG 30",8,,,,,,,,,,,,,,,
9,2,,23414-080000,,"GASKET 8, ROUND",4,,,,,,,,,,,,,,,
10,2,,23871-030000,,"PLUG PT3/8,SCREW",1,,,,,,,,,,,,,,,
11,2,,26106-080122,,"BOLT M 8X 12 PLATED",4,,,,,,,,,,,,,,,
12,2,,129150-02020,,"BOLT, BEARING CAP",10,,,,,,,,,,,,,,,
13,2,,129150-02800,,"MAIN BEARING",5,,,,,,,,,,,,,,,
14,2,,129150-02930,,"BEARING, THRUST",2,,,,,,,,,,,,,,,
15,2,,129795-02411,,"BUSH, CAMSHAFT",1,,,,,,,,,,,,,,,
16,1,,129150-02450,,"BEARING, THRUST",1,,,,,,,,,,,,,,,
17,1,,26106-080162,,"BOLT M 8X 16 PLATED",2,,,,,,,,,,,,,,,
18,1,,129150-01200,,"STUD, CYL. HEAD",18,,,,,,,,,,,,,,,
19,1,,129405-01330,,"GASKET, CYL.HEAD",1,,,,,,,A,,,,,,,,,
20,1,,129150-02870,,"MAIN BEARING US=0.25",5,,,,,,,1,,,,,,,,,
21,1,,129150-02940,,"BEARING,THRUST .25OS",1,,,,,,,2,,,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SPEC. CODE
D29405-01100
D29400-01820
D29550-02101
D29129-02200

Fig. 1 シリンダブロック CYLINDER BLOCK




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SPEC. CODE
D29150-25200
729432-51370

Fig. 11 FOフンシャポンプ FUEL INJECTION PUMP




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

SPEC. CODE
D29100-77210
D29410-77300

Fig. 17 ジェネレータ GENERATOR



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1,1,,719810-01500,,"HOUSING ASSY, GEAR",1,,,,,W,,,E02819,,,,,,,,
2,2,,129795-01800,,"SEAL, OIL",1,,,,,,,,,,,,,,,
3,1,,121450-01560,,"STUD M 8X 22",3,,,,,,,,,,,,,,,
4,1,,124160-01751,,"CAP, LUB.OIL SUPPLY",1,,,,,,,,,,,,,,,
5,1,,129400-01520,,"FLANGE,GEARS HOUSING",1,,,,,,,,,,,,,,,
6,1,,124240-01871,,"COVER, HO-P",1,,,,,,,,,,,,,,,
7,1,,124240-01882,,"GASKET, HO-P",1,,,,,,,,,,,,,,,
7-1,1,,124240-01883,,"GASKET, (NON-ASB.)",1,,,,,,N,A,,E02010,,,,,,,,
8,1,,129795-01950,,"PIPE, KNOCK L=18",2,,,,,,,,,,,,,,,
9,1,,121850-51960,,"O-RING, F.I.PUMP",1,,,,,,,A,,,,,,,,,
10,1,,24311-000160,,"O-RING 1A P-16.0",2,,,,,,,A,,,,,,,,,
11,1,,24311-000320,,"O-RING 1A P-32.0",1,,,,,,,A,,,,,,,,,
12,1,,26106-080122,,"BOLT M 8X 12 PLATED",4,,,,,,,,,,,,,,,
13,1,,26106-080162,,"BOLT M 8X 16 PLATED",1,,,,,,,,,,,,,,,
14,1,,26106-080162,,"BOLT M 8X 16 PLATED",3,,,,,,,,,,,,,,,
15,1,,26106-080202,,"BOLT M 8X 20 PLATED",2,,,,,,,,,,,,,,,
16,1,,26106-080452,,"BOLT M 8X 45 PLATED",6,,,,,,,,,,,,,,,
17,1,,26106-080552,,"BOLT M 8X 55 PLATED",3,,,,,,,,,,,,,,,
18,1,,26106-080852,,"BOLT M 8X 85 PLATED",4,,,,,,,,,,,,,,,
19,1,,26366-080002,,"NUT M 8",3,,,,,,,,,,,,,,,
20,1,,43400-500410,,"SEAL WASHER 8S",4,,,,,,,,,,,,,,,
21,1,,43400-500410,,"SEAL WASHER 8S",1,,,,,,,,,,,,,,,
22,1,,121023-01550,,"COVER, BLIND",1,,,,,,,,,,,,,,,
23,1,,24311-000240,,"O-RING 1A P-24.0",1,,,,,,,,,,,,,,,
23-1,1,,24341-000240,,"O-RING 1A S-24.0",1,,,,,N,,,EXXX,,,,,,,,
24,1,,26106-060122,,"BOLT M 6X 12 PLATED",2,,,,,,,,,,,,,,,
25,1,,121420-01760,,O-RING,1,,,,,,,,,,,,,,,
25-1,1,,24311-000320,,"O-RING 1A P-32.0",1,,,,,,N,A,,E03581,,,,,,,,
26,1,,171031-11741,,PIPE,1,,,,,,,,,,,,,,,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
1,1,,121850-11860,,"PLUG PT1/4",1,,,,,,,,,,,,,,,,
2,1,,129100-42001,,"PUMP ASSY, C.WATER",1,,,,,,,,,,,,,,,,
2-1,1,,129100-42002,,"PUMP, C.W.(NON-ASB.)",1,,,,,,N,,,E03078,,,,,,,,
3,2,,23871-030000,,"PLUG PT3/8,SCREW",1,,,,,,,,,,,,,,,,
4,1,,129100-42020,,"GASKET, C.W. PUMP",1,,,,,,,A,,,,,,,,,
5,1,,26106-080602,,"BOLT M 8X 60 PLATED",3,,,,,,,,,,,,,,,,
6,1,,124732-42290,,"V-BELT (A-37)",1,,,,,,,,,,,,,,,,
6-1,1,,121492-42290,,"V-BELT (A-38)",1,,,,,,S,1,,E00360,,,,,,,,
7,1,,129403-42380,,"V-PULLEY, C.W. PUMP",1,,,,,,,,,,,,,,,,
8,1,,129432-44740,,"FAN,COOLING",1,,,,,,,,,,,,,,,,
9,1,,121267-44760,,SPACER,1,,,,,,,,,,,,,,,,
10,1,,26014-060302,,"BOLT W/WASHER 6X 30",4,,,,,,,,,,,,,,,,
11,1,,121550-49111,,"JOINT PT1/4",1,,,,,,,,,,,,,,,,
12,1,,129100-49050,,"PIPE, C.W. (BY-PASS",1,,,,,,,,,,,,,,,,
13,1,,23000-016000,,"CLAMP 16",2,,,,,,,,,,,,,,,,
14,1,,121450-42450,,"PLUG M16",1,,,,,,,,,,,,,,,,
15,1,,121250-44901,,"SWITCH, THERMO(110ßC",1,,,,,,,,,,,,,,,,
16,1,,124465-44950,,"GASKET 16",1,,,,,,,A,,,,,,,,,
17,1,,124465-44950,,"GASKET 16",1,,,,,,,A,,,,,,,,,
18,1,,129350-49530,,"COVER, THERMOSTAT",1,,,,,,,,,,,,,,,,
19,1,,129795-49550,,"GASKET, UPPER",1,,,,,,,,,,,,,,,,
19-1,1,,129795-49551,,"GASKET, (NON-ASB.)",1,,,,,,N,A,,E03078,,,,,,,,
20,1,,129100-49800,,"CASE ASSY,THERMOSTAT",1,,,,,,,,,,,,,,,,
21,2,,124770-11770,,"JOINT PT1/8",1,,,,,,,,,,,,,,,,
22,2,,129100-49820,,"GASKET, COVER",1,,,,,,,,,,,,,,,,
23,2,,129100-49830,,"COVER,THERMOST.CASE",1,,,,,,,,,,,,,,,,
24,2,,23871-030000,,"PLUG PT3/8,SCREW",1,,,,,,,,,,,,,,,,
25,2,,26116-060162,,"BOLT M 6X 16 PLATED",2,,,,,,,,,,,,,,,,
26,1,,129155-49800,,THERMOSTAT,1,,,,,,,,,,,,,,,,
27,1,,129150-49810,,"GASKET, LOWER",1,,,,,,,,,,,,,,,,
27-1,1,,129150-49811,,"GASKET, (NON-ASB.)",1,,,,,,N,A,,E03078,,,,,,,,
28,1,,129100-49840,,"GASKET, THERMO. CASE",1,,,,,,,A,,,,,,,,,
29,1,,26106-080202,,"BOLT M 8X 20 PLATED",2,,,,,,,,,,,,,,,,
30,1,,26106-080252,,"BOLT M 8X 25 PLATED",1,,,,,,,,,,,,,,,,
31,1,,26106-080502,,"BOLT M 8X 50 PLATED",1,,,,,,,,,,,,,,,,
32,1,,26106-080602,,"BOLT M 8X 60 PLATED",1,,,,,,,,,,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 39 pages

The full manual includes:

- All 39 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TN84L-RBA Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual