[Info]
PcNo=Y00B5422
PcName=4TNE88-3BY,3CY(B6U)
JpnUse=1
JpnSec1=ƒGƒ“ƒWƒ“
JpnSec2=—§ ¬
JpnSec3=TNE
JpnPreface=0
EngUse=1
EngSec1=ENGINE
EngSec2=SMALL VERTICAL (B)
EngSec3=TNE
EngPreface=0

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
0,Y00B5422
1,001,,"ENGINE 4TNE88-3BY,3CY"
2,1,,"CYLINDER BLOCK",4TNE88-3BY,4TNE88-3CY,,
2,2,,"GEAR HOUSING",4TNE88-3BY,4TNE88-3CY,,
2,3,,"FLYWHEEL HOUSING & OIL SUMP",4TNE88-3BY,4TNE88-3CY,,
2,4,,"CYLINDER HEAD & BONNET",4TNE88-3BY,4TNE88-3CY,,
2,5,,"SUC. MANIFOLD & AIR CLEANER",4TNE88-3BY,4TNE88-3CY,,
2,6,,"EXH. MANIFOLD & SILENCER",4TNE88-3BY,4TNE88-3CY,,
2,7,,"CAMSHAFT & DRIVING GEAR",4TNE88-3BY,4TNE88-3CY,,
2,8,,"CRANKSHAFT & PISTON",4TNE88-3BY,4TNE88-3CY,,
2,9,,"LUB.OIL SYSTEM",4TNE88-3BY,4TNE88-3CY,,
2,10,,"COOLING WATER SYSTEM",4TNE88-3BY,4TNE88-3CY,,
2,11,,"FUEL INJECTION PUMP",4TNE88-3BY,4TNE88-3CY,,
2,12,,GOVERNOR,4TNE88-3BY,4TNE88-3CY,,
2,13,,"FUEL INJECTION PIPE",4TNE88-3BY,4TNE88-3CY,,
2,14,,"FUEL PIPE",4TNE88-3BY,4TNE88-3CY,,
2,15,,"STARTING MOTOR",4TNE88-3BY,4TNE88-3CY,,
2,16,,GENERATOR,4TNE88-3BY,4TNE88-3CY,,
2,17,,"GASKET SET(OPTIONAL) & TOOL",4TNE88-3BY,4TNE88-3CY,,
```

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

```
1,1,,729407-01561,,"BLOCK ASSY, CYLINDER",1,1,,,,,,,,,,,,,,
4,2,,124160-01910,,"PLUG PT1/4",2,2,,,,,,,,,,,,,,
5,2,,124160-01910,,"PLUG PT1/4",1,1,,,,,,,,,,,,,,
6,2,,171051-01921,,PLUG,1,1,,,,,,,,,,,,,,
7,2,,129150-02020,,"BOLT, METAL CAP",10,10,,,,,,,,,,,,,,
10,2,,23871-010000,,"PLUG PT1/8,SCREW",1,1,,,,,,,,,,,,,,
11,2,,27231-500000,,"PLUG 50",1,1,,,,,,,,,,,,,,
12,2,,27241-120000,,"PLUG 12",2,2,,,,,,,,,,,,,,
13,2,,27241-300000,,"PLUG 30",8,8,,,,,,,,,,,,,,
14,2,,23871-030000,,"PLUG PT3/8,SCREW",1,1,,,,,,,,,,,,,,
15,2,,129001-02800,,"MAIN BEARING",5,5,,,,,,,,,,,,,,
18,2,,129150-02930,,"METAL, THRUST",2,2,,,,,,,,,,,,,,
21,2,,129795-02411,,"BUSH, CAMSHAFT",1,1,,,,,,,,,,,,,,
22,1,,129150-01200,,"STUD, CYL. HEAD",18,18,,,,,,,,,,,,,,
23,1,,129407-01340,,"GASKET,CYL.HEAD",1,1,,,,,A,,,,,,,,,
24,1,,129150-02870,,"MAIN METAL US=0.25",5,5,,,,,1,,,,,,,,,
27,1,,129150-02940,,"METAL,THRUST OS=0.25",2,2,,,,,2,,,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Fig. 1 シリンダブロック CYLINDER BLOCK



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Fig. 5 吸気マニホールド＆エアクリーナ
SUC. MANIFOLD & AIR CLEANER



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Fig. 6 排気マニホールド＆サイレンサ EXH. MANIFOLD & SILENCER



PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

Fig. 9 潤滑油システム LUB. OIL SYSTEM



PREVIEW ONLY
Download full manual at youfixthis.com

Fig. 10 冷却水システム COOLING WATER SYSTEM



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 37 pages

The full manual includes:

- All 37 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TNE88-3BY, 3CY, 3CY (B6U), 4TNE88-3CY Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual