MODEL : 4TNE98-BQFLC
PC NO : Y00W2770

PARTS No. INDEX

PARTS No.	Fig.	Ref.No.
105010-39140	8	17
105225-59500	11	40
105430-67110	12	10
114250-39450	8	15
119000-35140	8	7
119130-44760	9	31
119131-18320	5	7
119260-34810	8	2
119305-59120	11	15
119326-77820	4	60
119600-11460	4	12
	15	5
119620-59700	11	49
119640-01640	3	8
119717-53010	11	2
119717-77800	4	56
119802-13610	5	6
119802-13720	5	8
119810-77340	14	12
120130-22301	7	17
121023-26070	2	23
121400-11340	4	8
	15	9
121850-21130	7	35
121850-21290	7	5
121850-21920	7	6
121850-49550	9	6
	15	14
121850-49810	9	9
121850-77021	5	10
	15	26
121959-12140	5	11
124066-59100	11	41
124160-01751	2	6
	4	45
124160-11360	4	46
124250-49351	9	32
124460-11340	4	9
	15	3
124465-44950	9	30
	15	17
129001-91810	2	36
		37
129052-55630	12	11
129100-01580	2	27
	3	1
129107-44901	9	29
129136-77251	14	8
129150-02450	6	4
129150-11230	4	34

PARTS No.	Fig.	Ref.No.
129150-11230	4	38
129150-11370	4	10
129150-11750	4	36
		40
129150-11810	4	25
129150-14200	6	1
129150-25920	6	14
129150-35160	8	6
129150-49360	9	33
	15	24
129150-59131	11	18
		22
129150-77340	14	10
129400-92450	15	29
129550-59120	11	19
129612-77260	14	9
129612-77700	14	2
129612-77710	14	3
129612-77730	14	4
129612-77750	14	6
129795-11180	4	7
129900-01200	1	33
129900-01250	1	15
129900-02020	1	7
129900-02341	1	35
129900-02410	1	10
129900-02931	1	27
129900-02941	1	38
129900-11100	4	4
129900-11110	4	5
129900-11120	4	6
129900-11200	4	26
129900-11240	4	27
129900-11280	4	30
129900-11310	4	48
	15	6
129900-11370	4	47
129900-11510	4	31
129900-11520	4	32
129900-11530	4	43
129900-11600	4	51
129900-11650	4	33
129900-11660	4	37
129900-12050	5	1
	15	7
129900-12100	5	2
129900-13120	5	4
129900-13150	5	5
	15	8
129900-14110	6	7


PARTS No.	Fig.	Ref.No.
129900-14140	2	28
129900-14400	6	2
129900-14590	6	3
129900-21220	7	4
129900-21600	7	39
129900-23001	7	19
129900-23200	7	23
129900-23601	7	24
129900-23611	7	33
129900-23911	7	26
129900-25060	6	10
129900-25110	6	11
129900-26020	6	17
129900-26250	2	21
		29
129900-32001	2	10
129900-32030	2	25
	8	8
	15	10
129900-32040	2	26
	15	11
129900-42061	9	12
	15	12
129900-42140	9	16
	15	25
129900-42461	9	2
129900-49551	9	7
129900-49560	9	8
	15	13
129900-77010	13	1
129900-77330	14	11
129900-77400	13	2
129900-77440	13	5
129900-77450	13	7
		9
129900-77460	13	11
129900-77480	13	8
129900-77510	13	17
129900-77520	13	20
129900-77540	13	18
129900-77550	13	19
129900-77591	13	12
129900-77610	13	23
129900-77620	13	13
129900-77640	13	15
129900-77650	13	14
129900-77700	13	16
129900-77710	13	24
129901-01960	10	6
129901-11450	4	11

PARTS No.	Fig.	Ref.No.
129901-11450	15	4
129901-25900	6	16
129901-53020	11	3
129901-53800	11	4
129901-59500	12	8
129901-59510	11	43
129901-59560	11	48
	15	15
129901-59810	11	24
129901-59820	11	28
129901-59830	11	32
129901-59840	11	36
129901-77820	4	57
129902-21050	7	1
129903-01350	1	34
	15	2
129903-11700	4	3
129903-22050	7	13
129903-22120	7	11
129903-22940	7	27
129903-22950	7	29
129904-01950	10	5
129906-01610	3	2
129906-21520	7	36
129907-21650	7	8
129910-07910	4	2
129916-01790	3	6
129916-01800	2	3
129916-21610	7	10
129916-44740	9	4
129916-49740	9	14
129917-01500	2	1
129917-42010	9	13
129917-42160	9	17
129917-42170	9	18
129917-42300	9	22
129917-42310	9	23
129917-55801	12	1
129917-55810	12	2
129917-55821	12	3
129917-55830	12	4
129917-55840	12	5
129917-55850	12	6
129919-51500	10	10
129930-01710	3	7
129930-07910	4	1
129930-13201	5	13
	15	28
129930-21690	7	40
129930-34800	8	1

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. CYLINDER BLOCK



Remarks
(1) UNDER-SIZED(U.S=0.25)PART.
(2) OVER-SIZED(O.S=0.25)PART.
(3) REPAIR PART.

 1. CYLINDER BLOCK

(A)=4TNE98-BQFLC (D)=
(B)= (E)=
(C)= (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	729903-01560	BLOCK ASSY, CYLINDER	1							
5	2	23876-030000	PLUG PT3/8,SCREW	1							
6	2	171051-01921	PLUG	1							
7	2	129900-02020	BOLT, METAL CAP	10							
10	2	129900-02410	BUSH, CAMSHAFT	1							
11	2	22190-080002	SEAL WASHER 8S	1							
12	2	22351-060012	SPRING PIN 6X12	2							
13	2	23876-030000	PLUG PT3/8,SCREW	1							
14	2	26106-080122	BOLT M 8X 12 PLATED	1							
15	2	129900-01250	PLUG 55	1							
16	2	23876-030000	PLUG PT3/8,SCREW	1							
17	2	27241-300000	PLUG 30	8							
27	2	129900-02931	BEARING ASSY, THRUST	2							
30	1	729900-02801	MAIN BEARING SET	5							3
33	1	129900-01200	BOLT, HEAD	18							
34	1	129903-01350	GASKET, HEAD	1							
35	1	129900-02341	MAIN BEARING US=0.25	5							1
38	1	129900-02941	BEARING,THRUST .25OS	2							2


N:Old ←○ ×→ New, Q:Old ←× ○→ New, R:Old ←○ ○→ New, S:Old ←× ×→ New, W:Add, Z:Discontinued, F:Set Change, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.5. SUCTION & EXHAUST MANIFOLD



Y00W2770 5. SUCTION & EXHAUST MANIFOLD


(A)=4TNE98-BQFLC (D)=
(B)= (E)=
(C)= (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	129900-12050	GASKET, SUC.MANIFOLD	1							
2	1	129900-12100	MANIFOLD,INT	1							
3	1	26106-080452	BOLT M 8X 45 PLATED	9							
4	1	129900-13120	MANIFOLD, EXHAUST	1							
5	1	129900-13150	GASKET	1							
6	1	119802-13610	BOLT M 8X 45 PLATED	6							
7	1	119131-18320	BOLT M 8X 22	4							
8	1	119802-13720	STUD, M8X45	2							
9	1	26306-080002	NUT	2							
10	1	121850-77021	GASKET, (NON-ASB.)	1							
11	1	121959-12140	JOINT	1							
12	1	26106-080352	BOLT M 8X 35 PLATED	4							
13	1	129930-13201	GASKET, SILENCER	1							

N:Old ⇄ New, Q:Old ⇄ New, R:Old ⇄ New, S:Old ⇄ New, W:Add, Z:Discontinued, F:Set Change, K:Q'ty Change

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com
(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

Fig.10. FUEL INJECTION PUMP



10. FUEL INJECTION PUMP

(A)=4TNE98-BQFLC (D)=
(B)= (E)=
(C)= (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
5	1	129904-01950	RETAINER	1							
6	1	129901-01960	STAY, BRACKET	1							
7	1	26106-100142	BOLT M10X 14 PLATED	1							
8	1	26106-100162	BOLT M10X 16 PLATED	1							
9	1	26106-100202	BOLT M10X 20 PLATED	1							
10	1	129919-51500	PUMP ASSY, FUEL OIL	1							
29	2	X1466000800	O RING	1							
34	2	X1466000800	O RING	1							
35	2	X1463104020	COVER	1							
36	2	X1466205000	BOLT	2							
37	2	X1463105100	COVER	1							
38	2	X1466205000	BOLT	2							
114	2	X1466501220	VALVE	1							
115	3	X1466001700	O RING	1							
116	2	X1466584820	WIRE	1							
117	2	X1466214901	NUT	1							
122	2	X1465981000	CAP	1							
123	2	X0299985720	CAP	1							
125	2	X0294704030	WOODRUFF KEY	1							
126	2	X0131214140	NUT	1							
127	2	X0293214050	SPRING WASHER	1							
129	2	X1466214901	NUT	1							
130	2	X1466005000	O RING	1							
131	2	X1466629920	WIRE	1							
135	1	129930-67010	BRACKET, AXEL WIRE	1							
136	1	26450-060252	BOLT M 6X 25	2							

N:Old ⟷ New, Q:Old ⟷ New, R:Old ⟷ New, S:Old ⟷ New, W:Add, Z:Discontinued, F:Set Change, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD and YANMAR AGRICULTURAL EQUIPMENT CO.,LTD.

PREVIEW OF YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 4 of 21 pages

The full manual includes:

- All 21 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TNE98-BQFLC, Forklift Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual