
パーツカタログの見方

1. このパーツカタログに記載されている部品は、必ずしも標準装備部品ではありません。
2. 部品変更は、予告なく行うことがあります。
3. パーツカタログリスト様式



Y00F2161 (1997.09.01)

Fig. 29 燃料噴射ポンプ(ブーコン用)
FUEL INJECTION PUMP (W/BOOST)

A=	4JH-DT	D=	4JH-DTZA
B=	4JH-DTZ	E=	4JH-DTZY
C=	4JH-DTZP	F=	

●見出 REF.No.	レベル LEV.	0	部品番号 PARTS No.	部品名	DESCRIPTION	個数 (Q'ty) A	B	C	D	E	F	I	R
1	•		729595-51390	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
1-1	•		729595-51391	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1		N	1
			(A=E/#00185)(B=E/#00200)										
3	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	9	9	9	9	9			
I 3-1	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	4	4	4	4	4		K	
			(A=E/#00185)(B=E/#00200)(C=E/#00156)(D=E/#00156)(E=E/#00156)										
4	••		129470-51040	カムシャフト	CAMSHAFT	1	1	1	1	1			
5	••		122710-51050	ベアリングコロ-ラ	BEARING, ROLLER	2	2	2	2	2			
6	••		129470-51060	ベアリングオサエ	RETAINER	1	1	1	1	1			

備考	Remarks
(1) ブーストコンペンセータ付き、4JH-DT、4JH-DTZとも E／#00155までは、特別注文仕様とします	(1) BOOST COMPEMSATOR TYPE. OPTIONAL PART, TO E／#00155, (4JH－DT,4JH－DTZ)

① 見出No.(REF.No.)

リスト頁の見出No.とイラスト図番の末尾が一致しない場合があります。

(例) イラスト図番 1 リスト頁の見出No. 1 (変更前) ⟶ 1 −1 (変更後)

互換性記号N、R、Kの場合は新部品のイラストを省略している場合があります。

② レベル (LEV.)

レベル
- • ……表示している • 印の数をレベルと呼び親子の関係を示します。(•は親部品です)
- •• ……は • に含まれる子部品です。
- ••• ……は •• に含まれる子部品 (•から見れば孫部品) です。

注) 非販売部品のイラストは一部展開しておりますが、リストには記載しておりません。

③ 変 更 マ ー ク

前回出版したパーツカタログには無く、今回新規に設計変更が発生した部品について " I " 印が表示されます。

④ 互 換 性 区 分

部分変更が行われた場合、その部品に対して下記の互換性記号が表示されます。

記号	互換性	内容
N	旧 ⟷ 新	新部品は、旧部品に対して互換性有り、その逆は無し。
Q	旧 ⟷ 新	新部品は、旧部品に対して互換性無し、その逆は有り。
R	旧 ⟷ 新	新・旧部品双方に対して互換性有り。
S	旧 ⟷ 新	新・旧部品双方に対して互換性無し。
W		新規追加となった部品。
Z		廃止された部品。
F		単品では、互換性無し。但し関連部品セットにて互換性有り。
K		使用個数のみの変更。

⑤ 実 施 号 機

部品が変更された時には、適用される商品形式の実施号機が (A) ～ (F) 欄毎に表示されます。

商品記号	商品 No.	商品記号	商品 No.
C	クラッチNo. コンプレッサNo.	M	本機No.
D	ドライブNo.	T	トラクタNo.
E	エンジンNo.	注1)※	西暦年月

注1) 記号の後の西暦年月を記載している事もあります。(例) ※1996. 01

注2) 実施号機が×××は、部品変更の予告又は、実施号機が確定できなかった部品です。

注3) (A＝E／#00185)は、A欄の商品形式(＝4JH－DT)の部品変更実施号機は、E／#(＝エンジンNo.)が00185号機以降であることを示します。

⑥ 備考(リマークス)区分

R …… 欄に数字又は、英字 (記号) を表示してあります。

リスト下段に上記の記号と同一記号を表記して当該部品に対するコメント(備考)を表示しています。

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CONTENTS (PC NO.YOOD7500)


コウモクNO. GROUP	コウモク メイ	GROUP NAME	ロケーションヨン LOCATION
1	シリンダ゛ブロック	CYLINDER BLOCK	1A02
2	ギ゛ヤケース	GEAR HOUSING	1A03
3	フライホイルハウシ゛ング゛ & オイルパ゜ン	FLYWHEEL HOUSING & OIL SUMP	1A04
4	シリンダ゛ヘツト゛ & ボ゛ンネツト	CYLINDER HEAD & BONNET	1A05
5	キユウキマニホールト゛ & エアクリーナ	SUCTION MANIFOLD & AIR CLEANER	1A06
6	ハイキマニホールト゛ & サイレンサ	EXHAUST MANIFOLD & SILENCER	1A07
7	カムシヤフト & クト゛ウキ゛ヤ	CAMSHAFT & DRIVING GEAR	1A08
8	クランクシヤフト & ヒ゜ストン	CRANKSHAFT & PISTON	1A09
9	LOシステム	LUB.OIL SYSTEM	1A10
10	CWシステム	COOLING WATER SYSTEM	1A11
11	FOフンシヤホ゜ンフ゜	FUEL INJECTION PUMP	1A12
12	FOフンシヤヘ゛ン	FUEL INJECTION VALVE	1A13
13	FOハ゜イフ゜	FUEL LINE	1A14
14	キカンテイシソウチ	ENGINE STOP DEVICE	1A15
15	スターテイング゛モータ	STARTING MOTOR	1A16
16	ジ゛エネレータ	GENERATOR	1B01
17	ハ゜ツキンセツト	GASKET SET	1B02

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7500
4TNE98-TBL

1 シリンダブロック
CYLINDER BLOCK



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Engine for TL130 4TNE98-TBL
CYLINDER BLOCK


Item ID	Parts Number	部品種類	Qty
1	729902-01560	BLOCK ASSY, CYLINDER	1
5	23876-030000	· PLUG PT3/8,SCREW	1
6	171051-01921	· PLUG	1
7	129900-02020	· BOLT, METAL CAP	10
10	129900-02410	· BUSH, CAMSHAFT	1
11	22351-060012	· SPRING PIN 6X12	2
12	23876-030000	· PLUG PT3/8,SCREW	1
13	129900-01250	· PLUG 55	1
14	23876-030000	· PLUG PT3/8,SCREW	1
15	27241-300000	· PLUG 30	8
16	129900-02800	· BEARING ASSY, MAIN	5
25	129900-02930	· BEARING ASSY, THRUST	2
28	129900-01200	BOLT, HEAD	18
29	129902-01331	GASKET, HEAD	1
30	129900-02340	MAIN BEARING US=0.25	5
33	129900-02940	BEARING,THRUST .250S	2

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7500
4TNE98-TBL

8 クランクシャフト & ピストン
CRANKSHAFT & PISTON




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7500
4TNE98-TBL

10 CWシステム
COOLING WATER SYSTEM




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7500
4TNE98-TBL

13 FOパイプ
FUEL LINE




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7500
4TNE98-TBL

15 スターティングモータ
STARTING MOTOR



PREVIEW.YOUFIXTHIS.COM

Download full manual at youfixthis.com

NUMERICAL INDEX


Part number	Page	Item
101304-59020	13	6
101720-55750	13	57
102103-55520	13	52
103854-59191	13	7
104200-55321	13	48
104200-55330	13	49
104200-55341	13	50
104200-55750	13	58
105010-39140	9	7
105025-59580	13	22
105840-59100	10	47
106500-44810	16	14
110250-55610	13	53
114250-39450	9	19
114250-53080	12	8
114250-53120	12	12
114250-53130	12	13
114250-53140	12	14
114250-53210	12	15
114250-53400	12	16
119000-35140	9	10
119000-55601	13	2
119005-12571	5	10
119100-11330	4	52
119130-44760	10	17
119131-18320	6	8
119140-12680	5	14
119259-44570	10	33
119260-34810	9	2
119266-49350	10	31
119305-59120	12	28
119560-59110	13	20
	13	39
119625-11870	17	5
	4	20
119625-11880	17	6
	4	21
119625-11900	4	22
119640-01640	3	9
119808-12540	5	13
119810-77340	16	15
119836-77201	16	1
119836-77920	16	4
119840-66811	14	6
120130-22301	8	22
121023-01550	2	31
121023-26070	2	13
121250-44901	10	11
121250-49110	13	37
121250-59550	13	26
121254-77402	15	2
121254-77430	15	5
121254-77480	15	9
121254-77521	15	13
121254-77541	15	14
121254-77550	15	15
121254-77571	15	16
121254-77581	15	17
121254-77590	15	18
121254-77600	15	19
121254-77610	15	21
121254-77640	15	23
121254-77681	15	26
121254-77690	15	27
121254-77700	15	28
121254-77730	15	31
121254-77770	15	35
121254-77780	15	40
121254-77790	15	36
121254-77810	15	37
121257-55720	13	54
121257-55731	13	55
121267-44510	10	34
121267-44590	10	37
121400-11340	17	11
	4	17
121450-44530	10	35
121470-44550	10	38
121550-49111	10	18
121750-59890	13	41
121850-21130	8	11
121850-21290	8	5
121850-21680	8	10
121850-21920	8	6
121850-49530	10	22
121850-49540	10	23
	17	18
121850-49550	10	21
	17	16
121850-49800	10	24
121850-77021	17	17
	5	5
121855-59880	13	25
	13	43
	13	45
124060-59380	13	9
124064-55510	13	51
124066-59100	13	17
	13	28
124160-01751	2	29
	4	58
124160-11360	4	45
124411-01780	3	7
124450-44560	10	36
124460-11340	17	4
	4	18
124465-44950	10	10
	17	29
124550-77030	15	43
124722-59050	10	46
124766-59050	13	23
	13	42
	13	46
128300-59910	13	30
128300-77920	16	16
129001-91810	2	26
	2	27
129062-12560	5	11
129100-01580	2	17
	3	1
129100-53100	12	9
129100-77910	5	18
129136-77100	16	13
129150-02450	7	4
129150-11230	4	35
	4	39
129150-11370	4	19
129150-11750	4	37
	4	41
129150-11810	4	9
129150-14200	7	1
129150-25920	7	14
129150-35152	9	9
129150-49080	10	40
129150-49100	10	39
129150-49360	10	30
	17	25
129150-59131	12	31
	12	35
129150-59580	13	44
129150-77340	16	8
129322-77401	13	62
129335-55700	13	47
129335-59090	13	19
	13	40
129400-13201	17	23
	6	7
	6	15
129400-92450	17	30
129467-42290	10	15-1
129470-55610	13	3
129495-59300	13	5
129550-59120	12	32
129566-66880	14	4
129566-66890	14	5
129612-12650	5	15
129612-77260	16	10
129612-77700	16	2
129612-77710	16	3
129612-77730	16	5
129612-77740	16	6
129612-77750	16	7
129795-11180	4	16
129900-01200	1	28
129900-01250	1	13
129900-01500	2	8
129900-01780	2	4
129900-01800	2	7
129900-01950	12	1
129900-02020	1	7
129900-02340	1	30
129900-02410	1	10
129900-02800	1	16
129900-02930	1	25
129900-02940	1	33
129900-11100	4	13
129900-11110	4	14
129900-11120	4	15
129900-11200	4	27
129900-11240	4	28
129900-11280	4	31
129900-11310	17	7
	4	47
129900-11510	4	32
129900-11520	4	33
129900-11530	4	62
129900-11600	4	50
129900-11650	4	34
129900-11660	4	38
129900-12050	17	8
	5	1
129900-12100	5	2
129900-12530	5	12
129900-13200	6	1
129900-13252	17	9
	6	3
129900-14100	7	7
129900-14400	7	2
129900-14580	7	3
129900-21200	8	4

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

How to read this Parts Catalog.

1. Parts mentioned in this Parts Catalog may not necessarily be standard equipping parts.
2. Parts change may be made without prior notice.
3. Form of this Parts Catalog.



Y00F2161 (1997.09.01)

Fig. 29 燃料噴射ポンプ(ブーコン用)
FUEL INJECTION PUMP (W/BOOST)

A= 4JH-DT	D= 4JH-DTZA
B= 4JH-DTZ	E= 4JH-DTZY
C= 4JH-DTZP	F=

見出 REF.No.	レベル LEV.	0	部品番号 PARTS No.	部品名	DESCRIPTION	個数 (Q'ty) A	B	C	D	E	F	I	R
1	•		729595-51390	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
1- 1	•		729595-51391	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			N 1
			(A=E/#00185) (B=E/#00200)										
3	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	9	9	9	9	9			
I 3- 1	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	4	4	4	4	4			K
			(A=E/#00185) (B=E/#00200) (C=E/#00156) (D=E/#00156) (E=E/#00156)										
4	••		129470-51040	カムシャフト	CAMSHAFT	1	1	1	1	1			
5	••		122710-51050	ベアリングキローラ	BEARING, ROLLER	2	2	2	2	2			
6	••		129470-51060	ベアリングオサエ	RETAINER	1	1	1	1	1			

備考
(1) ブーストコンペンセータ付き、4JH-DT、4JH-DTZとも E／# 00155までは、特別注文仕様とします

Remarks
(1) BOOST COMPEMSATOR TYPE. OPTIONAL PART, TO E／# 00155, (4JH－DT,4JH－DTZ)

① Ref. No.

The Ref. No. in the list may not be accord with the Ref. No. on illustration.

(Ex.) Illustration No. 1 — List head No. 1 (Befor change) ⟶ 1 −1 (After change)

When interchangeable symbol N, R, and K, illustrations for new parts are sometimes omitted.

② Lev.(Level)

Indication and Meaning of Level

Level : Hereunder is given the relation among the number of dots(•),the level and the nominal parent- child relationship.

- • ·····Parent parts(Assembly parts)
- •• ·····Child parts included in "•" (Semi- Assembly parts,component parts of Assembly parts.)
- ••• ·····Child parts included in "••", Grand- child parts in terms of "•". (Compornent parts of Semi- Assembly parts.)

Note) A parts of non- sale parts are illustlated but not listed.

③ Change Mark

Change Mark "I" is given to the part for which a desigh change was made at this time.
The design change was not shown in the last published Parts Catalog.

④ Interchangeability Mark

In the case where a part change took place,one of the following interchangeability marks is indicated for that part.

Symbol	interchangeability	Contents note
N	Old ⟷ New	New Part is interchangeable for Old Part but not interchangeable conversely.
Q	Old ⟷ New	New Part is not interchangeable for Old Part but interchangeable conversely.
R	Old ⟷ New	New Part is interchangeable for Old Part and vice versa.
S	Old ⟷ New	New Part is not interchangeable for Old Part and vice versa.
W		Part newly added.
Z		Part discontinued.
F		Not interchangeable single part but interchangeable by set of the related parts.
K		Changed only in quantity used.

⑤ Effective Machine No.

When a part is changed,Effective Machine No. of a Model for which the part is applicable is indication in each column of (A)- (F).

Product Symbol	Product No.	Product Symbol	Product No.
C	Clutch No. Compressor No.	M	Machine No.
D	Drive No.	T	Tractor No.
E	Engine No.	Note1) ※	Date

Note1) Date may follow the symbol in some cases. (Ex.) ※ 1996.01
Note2) As far as engine models shown by "XXX" are concerned, the modification of the parts could not be predicted or the engine models themselves could not be identified.
Note3) (A=E/#00185) means that the design change on the part has been effective for the model at the column (A)(in this case, for 4JH- DT) on and from E/#(Engine Serial Number) 00185.

⑥ Remarks Mark

Figures or alphabets (Symbols) are entered in the remark column.
The comments(remarks)on the pertinent parts are indicated in the lower part of the list by the same symbols as those stated above.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
129900-23600	8	34
129900-23610	8	36
129900-23910	8	32
129900-25110	7	13
129900-26020	7	20
129900-26250	2	64
129900-32030	11	7
	2	37
	21	12
129900-32040	2	38
	21	13
129900-35000	11	8
129900-42020	12	11
	21	14
129900-42461	12	14
129900-49870	12	36
	21	15
129902-01710	3	19
129902-21050	8	2
129906-55700	16	30
129907-01190	1	36
129907-01331	1	35
	21	3
129907-01950	14	1
129907-01960	14	2
129907-03010	4	52
129907-03060	4	53
129907-03070	4	54
129907-07900	4	1
129907-11100	4	25
129907-11110	4	14
129907-11120	4	15
129907-11250	4	30
129907-11260	4	31
129907-11270	4	32
129907-11310	21	7
	4	61
129907-11320	4	51
129907-11341	4	29
129907-11510	4	19
129907-11650	4	34
129907-11660	4	38
129907-11700	4	4
129907-11800	4	9
129907-11910	4	68
129907-11920	4	42
129907-11950	4	48
129907-12100	5	1
129907-12110	21	8
	5	2
129907-14400	7	2
129907-14590	7	4
129907-22050	8	22
129907-22090	8	20
129907-32009	2	26
129907-39061	11	15
129907-42000	12	1
129907-49610	12	43
129907-49620	12	47
129907-49710	12	44
129907-49720	12	48
129907-49730	12	27
129907-49750	12	45
129907-53000	15	2
129907-53100	15	6
129907-59140	16	12
129907-59710	15	35
129907-59810	15	37
129907-59820	15	38
129907-59830	15	39
129907-59840	15	40
129910-07900	4	69
129915-77050	5	7
129916-21650	8	9
129916-44740	12	18
129916-49530	12	24
129930-13200	21	10
	6	15
	6	8
129930-39050	11	40
129935-12520	5	29
129940-42320	12	16
129944-12520	5	26
129944-13520	6	9
129944-13660	6	10
129944-35110	11	26
129944-35150	11	39
129944-44510	13	8
129946-49810	12	23
129950-59221	16	10
129951-34801	11	2
129951-34812	11	4
129953-01620	3	15
129953-21570	8	17
129953-25300	7	23
129953-35110	11	25
129953-39100	11	35
129953-39500	11	28
	11	34
129953-77019	18	1
129953-77660	18	41
129953-77670	18	25
129957-59120	16	6
129960-21640	8	10
129962-01500	2	23
129970-35140	11	30
129972-77330	20	1
129980-59510	16	11
129981-59010	16	8
158563-51150	7	24
171051-01921	1	9
22157-080000	6	11
22190-080002	11	20
	11	22
	11	24
	16	19
	21	24
22190-100002	11	41
22190-220002	21	25
	3	22
22190-300002	11	37
22217-180000	7	25
22252-000300	8	27
22351-060012	1	14
22512-070140	7	9
	8	8
22857-500100	4	63
	4	64
23000-054000	13	22
23387-040800	12	31
23414-080000	12	32
	12	37
	21	19
23857-030000	11	21
23875-030000	12	33
23876-020000	4	11
23876-030000	1	15
	1	16
	1	17
	4	12
23887-100002	11	42
24311-000070	2	41
	21	21
24311-000120	21	22
	4	27
	4	66
24311-000160	16	34
24311-000300	2	67
24311-000320	2	58
	2	63
	21	23
	4	67
24311-240100	11	5
	21	30
24321-000600	11	38
	21	31
24321-000650	16	33
24321-000700	21	32
24321-000850	2	60
	21	27
24341-000280	14	81
24341-000530	21	28
	8	12
24351-030750	2	42
	21	26
26014-080252	20	33
26106-060122	12	34
26106-060142	14	83
26106-060162	15	41
26106-060202	12	35
26106-060302	12	12
	18	38
26106-060452	18	39
26106-080122	11	13
	11	23
	12	38
	3	14
26106-080162	11	6
	14	276
	2	43
	2	44
	2	56
	4	2
	6	12
	7	10
26106-080182	15	42
26106-080202	2	45
	5	25
	6	13
26106-080222	14	277
	14	278
26106-080302	16	3
26106-080352	11	43
	12	22
	5	8
26106-080402	2	46
	2	47
	4	44
26106-080452	2	48
26106-080552	12	13

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 11 of 120 pages

The full manual includes:

- All 120 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TNE98-TBL, 4TNV98-YTBL, TL130 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual