ｼﾘﾝﾀﾞﾌﾞﾛｯｸ　CYLINDER BLOCK


見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	729953-01560	ｼﾘﾝﾀﾞﾌﾞﾛｯｸ ASY	BLOCK ASSY, CYLINDER	1			
7	129900-01250	・ ｻﾗｶﾞﾀﾌﾟﾗｸﾞ 55	・ PLUG 55	1			
8	129953-01920	・ ﾂｷﾞﾃ(ｽｲｵﾝｾﾝｻｰ	・ JOINT	1			
9	129900-02020	・ ﾎﾞﾙﾄ(ﾒﾀﾙｷｬｯﾌﾟ	・ BOLT, METAL CAP	10			
10	129900-02410	・ ｶﾑｼﾞｸﾌﾞﾂｼｭ	・ BUSH, CAMSHAFT	1			
11	22351-060012	・ ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 6.0AX 12	・ SPRING PIN 6X12	2			
12	23876-030000	・ ﾈｼﾞﾌﾟﾗｸﾞPT 3/8	・ PLUG PT3/8,SCREW	1			
13	23876-030000	・ ﾈｼﾞﾌﾟﾗｸﾞPT 3/8	・ PLUG PT3/8,SCREW	1			
14	23876-030000	・ ﾈｼﾞﾌﾟﾗｸﾞPT 3/8	・ PLUG PT3/8,SCREW	1			
15	27241-300000	・ ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 30	・ PLUG 30	8			
16	129900-02800	・ ﾒｲﾝﾒﾀﾙ CMP	・ BEARING ASSY, MAIN	5			
25	129900-02930	・ ｽﾗｽﾄﾒﾀﾙ CMP	・ BEARING ASSY, THRUST	2			
28	129900-01200	ﾍｯﾄﾞﾎﾞﾙﾄ	BOLT, HEAD	18			
29	129902-01331	ﾍｯﾄﾞｶﾞｽｹｯﾄ	GASKET, HEAD	1			
30	129900-02340	ﾒｲﾝﾍﾞｱﾘﾝｸﾞ U.S=0.25	MAIN BEARING US=0.25	5		(1)	ｱﾝﾀﾞｰｻｲｽﾞ(U.S=0.25)ﾌﾞﾋﾝﾃﾞｽ
33	129900-02940	ｽﾗｽﾄﾒﾀﾙ 0.S=0.25	BEARING,THRUST .250S	2		(2)	ｵｰﾊﾞｰｻｲｽﾞ(0.S=0.25)ﾌﾞﾋﾝﾃﾞｽ

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7650
4TNE98-TBW

1 シリンダブロック
1 CYLINDER BLOCK




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7650
4TNE98-TBW

8 クランクシャフト & ピストン
CRANKSHAFT & PISTON




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7650
4TNE98-TBW

9 ユアツポンプ
HYDRAULIC PUMP




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7650
4TNE98-TBW

13 FOフンシャポンプ
FUEL INJECTION PUMP




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7650
4TNE98-TBW

12 CWシステム
COOLING WATER SYSTEM




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7650
4TNE98-TBW

18 スターティングモータ
STARTING MOTOR



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

目次 CONTENTS (PC NO.YOOD7650)

コウモクNO. GROUP	コウモク メイ	GROUP NAME	ロケーションLOCATION
1	シリンダブロック	CYLINDER BLOCK	1A02
2	ギヤケース	GEAR HOUSING	1A03
3	フライホイルハウジング & オイルパン	FLYWHEEL HOUSING & OIL SUMP	1A04
4	シリンダヘツド & ボンネツト	CYLINDER HEAD & BONNET	1A05
5	キユウキマニホールド & エアクリーナ	SUCTION MANIFOLD & AIR CLEANER	1A06
6	ハイキマニホールド & サイレンサ	EXHAUST MANIFOLD & SILENCER	1A07
7	カムシヤフト & クドウギヤ	CAMSHAFT & DRIVING GEAR	1A08
8	クランクシヤフト & ピストン	CRANKSHAFT & PISTON	1A09
9	ユアツポンプ	HYDRAULIC PUMP	1A10
10	オイルクーラ	OIL COOLER	1A11
11	LOシステム	LUB.OIL SYSTEM	1A12
12	CWシステム	COOLING WATER SYSTEM	1A13
13	FOフンシヤポンプ	FUEL INJECTION PUMP	1A14
14	ガバナ	GOVERNOR	1A16
15	フイードポンプ	FEED PUMP	1B02
16	FOフンシヤベン	FUEL INJECTION VALVE	1B03
17	FOパイプ	FUEL LINE	1B04
18	スターテイングモータ	STARTING MOTOR	1B05
19	ジエネレータ	GENERATOR	1B06
20	コウグ & パツキンセツト	TOOL & GASKET SET	1B07

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 94 pages

The full manual includes:

- All 94 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TNE98-TBW, 4TNV98-XTBW, TB175W Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual