
シリンダブロック　CYLINDER BLOCK

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	Y729602-01560	BLOCK ASSY, CYLINDER	1			
4	Y124060-01050	· PLUG PT1/8	1			
5	Y129001-01250	· PLUG 50	1			
6	Y124160-01910	· PLUG PT1/4	2			
7	Y124160-01910	· PLUG PT1/4	1			
8	Y171051-01921	· PLUG	1			
9	Y129150-02020	· BOLT, METAL CAP	10			
12	Y129795-02412	· BUSH, CAMSHAFT	1			
13	Y27241-120000	· PLUG 12	2			
14	Y27241-300000	· PLUG 30	8			
24	Y129150-02931	· METAL, THRUST	2			
27	Y129150-01200	STUD, CYL. HEAD	18			
28	Y129407-01340	GASKET,CYL.HEAD	1			
29	Y129001-02931	MAIN BEARING SET	5		(1)	REPAIR PART.
32	Y129150-02871	MAIN METAL US=0.25	5		(2)	UNDER-SIZED(U.S=0.25)PART.
35	Y129150-02941	METAL,THRUST.25(4PIE	1		(3)	OVER-SIZED(O.S=0.25)PART.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


CYLINDER BLOCK



PREVIEW: YOUFIXTHIS.COM


Download full manual at youfixthis.com

GEAR HOUSING




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com



PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

Page	Index
FIG01	CYLINDER BLOCK
FIG02	GEAR HOUSING
FIG03	FLYWHEEL HOUSING & OIL SUMP
FIG04	CYLINDER HEAD & BONNET
FIG05	SUCTION MANIFOLD & AIR CLEANER
FIG06	EXHAUST MANIFOLD
FIG07	CAMSHAFT & DRIVING GEAR
FIG08	CRANKSHAFT & PISTON
FIG09	LUB.OIL SYSTEM
FIG10	COOLING WATER SYSTEM
FIG11	FUEL INJECTION PUMP
FIG12	GOVERNOR
FIG13	FUEL INJECTION VALVE
FIG14	FUEL LINE
FIG15	STARTING MOTOR
FIG16	GENERATOR
FIG17	GASKET SET

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

キュウキマニホールド & エアクリーナ SUCTION MANIFOLD & AIR CLEANER

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	Y129601-03080	PIPE,BREATHER	1			
2	Y129410-03990	· CLAMP 22	2			
3	Y129601-12100	MANIFOLD,INT	1			
4	Y129407-12110	GASKET,INT.MANOFOLD	1			
5	Y26106-080202	BOLT M 8X 20 PLATED	6			
6	Y26106-080802	BOLT M 8X 80 PLATED	1			
7	Y119910-12210	PIPE,INTAKE	1			
8	Y119802-12560	BRACKET,AIRCLEANER	1			
9	Y129612-12682	CLEANER ASSY, AIR	1			
10	Y129619-12520	· ELEMENT, OUTER	1			
11	Y119866-12530	· COVER ASSY	1			
12	Y129418-12530	· MARK	2			
13	Y119808-12540	· VALVE, UNLOADER	1			
14	Y129612-12560	· ELBOW, AIR INTAKE	1			
16	Y129612-12590	· · ELBOW,AIR INTAKE	1			
17	Y129259-12570	· RING	1			
18	Y129953-12620	· INDICATOR ASSY	1			
21	Y23000-060000	· CLAMP 60	1			
22	Y23000-060000	CLAMP 60	2			
23	Y26013-080222	BOLT M 8X 22	4			
24	Y26013-080222	BOLT M 8X 22	2			
25	Y129150-77511	GASKET, (NON-ASB.)	1			
26	Y119803-77520	BEND	1			
27	Y26106-080202	BOLT M 8X 20 PLATED	2			
28	Y26106-080802	BOLT M 8X 80 PLATED	2			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FOﾌﾝｼｬﾎﾟﾝﾌﾟ FUEL INJECTION PUMP

REF NO.	PARTS NO.	Description	Q'ty	I R	Remarks
1	Y729630-51340	INJECTION PUMP ASSY	1	(1)	GOVERNOR ASSY(FIG.NO.12) ISINCORPORATED IN THIS FUELINJECTION PUMP ASSY(REF.NO.1).
7	Y119802-51090	· KEY,WOODRUFF 4X16	1		
32	Y158600-51270	· STOPPER	1		
33	Y158563-51281	· O-RING	1		
34	Y158563-51281	· O-RING	1		
35	Y129008-51300	· VALVE ASSY, DILEVERY	4		
43	Y158563-51330	· SPRING	4		
44	Y129008-51340	· HOLDER, DELIVERY	4		
51	Y158601-51550	· PLUG	1		
52	Y119802-51560	· BARREL PLUG	1		
53	Y158552-51570	· PK(BARREL PLUG	3		
54	Y158552-51570	· PK(BARREL PLUG	1		
55	Y158557-51570	· PLUG	1		
56	Y158601-51570	· PLUG,WATER PUMP	1		
57	Y158552-51580	· LIFTER	1		
58	Y119802-51590	· TIMER SET	1		
59	Y119802-51600	· · TIMER CMP	1		
62	Y158553-51670	· · O-RING, 1011	1		
63	Y119802-51680	· · BACKUP RING	1		
64	Y119802-51690	· · O RING	1		
65	Y24356-010200	· · PACKING, 1020	1		
66	Y24372-000150	· · RING, BACKUP T2 P 15	1		
67	Y158552-51600	· PACKING, HEAD	1		
68	Y158553-51630	· SPRING,TIMER	1		
70	Y158553-51640	· ELEMENT, THERMO	1		
71	Y158553-51660	· O-RING,P14	1		
72	Y158553-51680	· PACKING,TIMER	1		
92	Y158601-51770	· PISTON	1		
93	Y158552-51781	· DAMPER ASSY	1		
94	Y158601-51790	· PLUG	1		
95	Y22190-120002	· SEAL WASHER 12	1		
96	Y22190-180002	· SEAL WASHER 18	1		
97	Y23887-120002	· PLUG M12,HEX.	1		
99	Y158553-51770	· BOLT	4		
100	Y158552-52310	· O-RING	1		
101	Y158552-52400	· O-RING 4E S42	1		
102	Y22190-120002	· SEAL WASHER 12	2		
103	Y22190-180002	· SEAL WASHER 18	2		
104	Y22217-140000	· SPRING WASHER 14	1		
105	Y22312-050140	· PARALLEL PIN 5X14	2		
106	Y22351-050010	· SPRING PIN 5X10	2		
108	Y24311-000070	· O-RING 1A P-7.0	1		
109	Y24356-010180	· O-RING	1		
110	Y24356-010200	· PACKING, 1020	1		
111	Y26106-060102	· BOLT 6X 10 PLATED	1		
115	Y26450-080452	· BOLT M 8X 45	4		
116	Y26776-140002	· LOCK NUT M14 PLATED	1		
119	Y158553-51551	· JOINT, COOLING WATER	1		
120	Y158601-51650	· JOINT	1		
121	Y158552-51670	· JOINT	1		
123	Y158552-52100	· PUMP ASSY,FEED	1		
124	Y158552-52500	· · O-RING(FEED P INNER	1		
125	Y119934-59910	· JOINT,PIPE	1		
126	Y22190-120002	· SEAL WASHER 12	1		
128	Y129601-51250	SUPPORT,FIP	1		
129	Y26106-080162	BOLT M 8X 16 PLATED	1		
130	Y26106-080202	BOLT M 8X 20 PLATED	1		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 42 pages

The full manual includes:

- All 42 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TNV88-BPTBZ, TB153FR Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual