
パーツカタログの見方

1. このパーツカタログに記載されている部品は、必ずしも標準装備部品ではありません。
2. 部品変更は、予告なく行うことがあります。
3. パーツカタログリスト様式



Y00F2161 (1997.09.01)

Fig.29 燃料噴射ポンプ(ブーコン用)
FUEL INJECTION PUMP (W/BOOST)

A=	4JH-DT	D=	4JH-DTZA
B=	4JH-DTZ	E=	4JH-DTZY
C=	4JH-DTZP	F=	

●見出 REF.No.	レベル LEV.	0	部品番号 PARTS No.	部品名	DESCRIPTION	個数 (Q'ty) A	B	C	D	E	F	I	R
1	•		729595-51390	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
1-1	•		729595-51391	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1		I	1
	(A=E/#00185)(B=E/#00200)												
3	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	9	9	9	9	9			
I 3-1	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	4	4	4	4	4		K	
	(A=E/#00185)(B=E/#00200)(C=E/#00156)(D=E/#00156)(E=E/#00156)												
4	••		129470-51040	カムシャフト	CAMSHAFT	1	1	1	1	1			
5	••		122710-51050	ベアリングコロ	BEARING, ROLLER	2	2	2	2	2			
6	••		129470-51060	ベアリングオサエ	RETAINER	1	1	1	1	1			

備考	Remarks
(1) ブーストコンペンセータ付き、4JH-DT、4JH-DTZとも E／#00155までは、特別注文仕様とします	(1) BOOST COMPEMSATOR TYPE. OPTIONAL PART, TO E／#00155, (4JH－DT,4JH－DTZ)

① 見出No.(REF.No.)

リスト頁の見出No.とイラスト図番の末尾が一致しない場合があります。

(例) イラスト図番　　リスト頁の見出No.

1　　1　　(変更前) ⟶ 1 [－1] (変更後)

互換性記号N、R、Kの場合は新部品のイラストを省略している場合があります。

② レベル (LEV.)

レベル
- • ……表示している • 印の数をレベルと呼び親子の関係を示します。(•は親部品です)
- •• ……は • に含まれる子部品です。
- ••• ……は •• に含まれる子部品 (•から見れば孫部品) です。

注) 非販売部品のイラストは一部展開しておりますが、リストには記載しておりません。

③ 変更マーク

前回出版したパーツカタログには無く、今回新規に設計変更が発生した部品について"Ⅰ"印が表示されます。

④ 互換性区分

部分変更が行われた場合、その部品に対して下記の互換性記号が表示されます。

記号	互換性	内容
N	旧 ⟵ 新	新部品は、旧部品に対して互換性有り、その逆は無し。
Q	旧 ⟵ 新	新部品は、旧部品に対して互換性無し、その逆は有り。
R	旧 ⟵ 新	新・旧部品双方に対して互換性有り。
S	旧 ⟵ 新	新・旧部品双方に対して互換性無し。
W		新規追加となった部品。
Z		廃止された部品。
F		単品では、互換性無し。但し関連部品セットにて互換性有り。
K		使用個数のみの変更。

⑤ 実施号機

部品が変更された時には、適用される商品形式の実施号機が (A) ～ (F) 欄毎に表示されます。

商品記号	商品 No.	商品記号	商品 No.
C	クラッチNo. コンプレッサNo.	M	本機No.
D	ドライブNo.	T	トラクタNo.
E	エンジンNo.	注1)※	西暦年月

注1) 記号の後の西暦年月を記載している事もあります。(例) ※1996. 01

注2) 実施号機が×××は、部品変更の予告又は、実施号機が確定できなかった部品です。

注3) (A＝E／#00185)は、A欄の商品形式(＝4JH－DT)の部品変更実施号機は、E／#(＝エンジンNo.)が00185号機以降であることを示します。

⑥ 備考(リマークス)区分

R …… 欄に数字又は、英字 (記号) を表示してあります。

リスト下段に上記の記号と同一記号を表記して当該部品に対するコメント(備考)を表示しています。


PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

TITLE	Fig.
CYLINDER BLOCK	Fig. 1
GEAR HOUSING	Fig. 2
FLYWHEEL HOUSING & OIL SUMP	Fig. 3
CYLINDER HEAD & BONNET	Fig. 4
SUCTION MANIFOLD	Fig. 5
EXHAUST MANIFOLD	Fig. 6
DIESEL PARTICULATE FILTER (DPF)	Fig. 7
CAMSHAFT & DRIVING GEAR	Fig. 8
TURBINE	Fig. 9
CRANKSHAFT & PISTON	Fig. 10
LUB.OIL SYSTEM	Fig. 11
LUB.OIL LINE	Fig. 12
COOLING WATER SYSTEM	Fig. 13
FUEL SUPPLY PUMP	Fig. 14
FUEL INJECTION VALVE	Fig. 15
FUEL LINE	Fig. 16
STARTING MOTOR	Fig. 17
GENERATOR	Fig. 18
ELECTRONIC CONTROL UNIT (ECU)	Fig. 19
ELECTRIC PARTS	Fig. 20
GASKET SET	Fig. 21

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER BLOCK



0CD11-M18700	1. CYLINDER BLOCK				
4TNV98CT-WTB/-WTBZ	1 : 2013. 07	2 :	3 :	4 :	

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


シリンダブロック　CYLINDER BLOCK

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	**Y129E32-01560**	BLOCK ASSY, CYLINDER	1			
4	**Y129900-01250**	· PLUG, 55	1			
5	**Y171051-01921**	· PLUG, NPTF1	1			
6	**Y129900-02020**	· BOLT, METAL CAP	10			
9	**Y129900-02410**	· BUSH, CAMSHAFT	1			
10	**Y27241-300000**	· PLUG 30	8			
11	**Y22351-060012**	· PIN, SPRING 6.0X12	2			
12	**Y23876-030000**	· PLUG, RO3	1			
13	**Y23876-030000**	· PLUG, RO3	1			
14	**Y23876-030000**	· PLUG, RO3	1			
24	**Y129900-02931**	· BEARING, THRUST	2			
27	**Y129900-01200**	BOLT, HEAD	18			
28	**Y129E00-01330**	GASKET, CYL. HEAD	1			
29	**Y729900-02801**	BEARING, MAIN	5		(1)	Spare parts.
32	**Y129900-02341**	BEARING, 0.25 US	5		(2)	Under-sized(U.S.=0.25)part
35	**Y129900-02941**	BEARING, THRUST 0.25	2		(3)	Over-sized(O.S.=0.25)part.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CAMSHAFT & DRIVING GEAR




PREVIEW - YOUFIXTHIS.COM

0CD11-M18700	8. CAMSHAFT & DRIVING GEAR			
4TNV98CT-WTB/-WTBZ	1:2013.07	2:	3:	4:

Download full manual at youfixthis.com


FUEL INJECTION VALVE



0CD11-M18700	16. FUEL INJECTION VALVE			
4TNV98CT-WTB/-WTBZ	1:2013.07	2:	3:	4:

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

STARTING MOTOR




0CD11-M18700	18. STARTING MOTOR				
4TNV98CT-WTB/-WTBZ	1 : 2013. 07	2 :	3 :	4 :	

PREVIEW BY YOUFIXTHIS.COM

Download full manual at youfixthis.com

COOLING WATER SYSTEM



0CD11-M18700	14. COOLING WATER SYSTEM			
4TNV98CT-WTB/-WTBZ	1:2013.07	2:	3:	4:

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 50 pages

The full manual includes:

- All 50 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 4TNV98CT-WTBZ, P-TB280FR_FEOA, 4JH-DT, 4JH-DTZ, 4JH-DTZP, 4JH-DTZA, 4JH-DTZY, 0CD11-M18700 Parts Catalog



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual