YANMAR

PARTS CATALOG

PREVIEW - YOUFIXTHIS.COM

0CR10-M45603EN

Last update Sep., 2014

Download full manual at youfixthis.com

Contents

Fig. No. Fig. Name

6LYA-STP/-STE/-UTE

1. CYLINDER BLOCK
2. GEAR HOUSING
3. FLYWHEEL HOUSING & ENGINE BRACKET
4. LUB. OIL SUMP & LUB. OIL PUMP
5. BREATHER
6. CYLINDER HEAD
7. SUCTION MANIFOLD & AIR CLEANER
8. TURBOCHARGER & EXHAUST MANIFOLD
9. TURBOCHARGER COMPONENT PARTS(TO APR. 1997)
10. TURBOCHARGER COMPONENT PARTS(TO APR. 1999)
11. TURBOCHARGER COMPONENT PARTS(FROM MAY 1999)
12. CAMSHAFT & CRANKSHAFT
13. AIR COOLER
14. PISTON & CONNECTING ROD
15. LUB.OIL COOLER & LUB.OIL STRAINER
16. LUB. OIL PIPE & NOZZLE
17. LUB. OIL PIPE(TURBOCHARGER)
53. (17A)REMOTE LUB.OIL STRAINER(OPTIONAL)
18. BILGE PUMP(STD)(OPTIONAL)(TO DEC. 1996)
19. BILGE PUMP(DX)(OPTIONAL))(TO DEC. 1996)
56. (19A)BILGE PUMP(OPTIONAL)(FROM JAN. 1997)
20. COOLING FRESH WATER PUMP & THERMOSTAT
21. COOLING SEA WATER PUMP
22. COOLING FRESH WATER COOLER & SUB TANK


Fig. No. Fig. Name

23. COOLING WATER PIPE
24. COOLING FRESH WATER PIPE(TURBOCHARGER)
25. FUEL INJECTION PUMP
26. GOVERNOR
27. FUEL FEED PUMP
28. TIMER
29. FUEL INJECTION VALVE & FUEL INJECTION PIPE
30. FUEL PIPE & FUEL STRAINER
31. ENGINE STOP DEVICE
32. CLUTCH(OPTIONAL)
33. STARTING MOTOR
34. GENERATOR(TO MAY 1997)
35. GENERATOR(FROM JUN. 19971)
55. (35A)GENERATOR(BOSCH)
36. WIRE HARNESS & SENSOR
37. INSTRUMENT PANEL-B(OPTIONAL)
38. INSTRUMENT PANEL-C(OPTIONAL)
39. INSTRUMENT PANEL-E(OPTIONAL)
40. INSTRUMENT PANEL-E2(OPTIONAL)
41. INSTRUMENT PANEL-D(OPTIONAL)
42. INSTRUMENT PANEL-B(OPTIONAL)(TO JUL. 1999)
43. INSTRUMENT PANEL-B(OPTIONAL)(FROM AUG. 1999)
44. INSTRUMENT PANEL-C(OPTIONAL)(TO APR. 1998)
45. INSTRUMENT PANEL-C(OPTIONAL)(TO JUL. 1999)
46. INSTRUMENT PANEL-C(OPTIONAL)(TO SEP. 1999)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. CYLINDER BLOCK



(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	719593-01560	BLOCK ASSY, CYLINDER		1	1					
1-1	1	719593-01561	BLOCK ASSY, CYLINDER	1	1	1				S	
		(B=E50388)	(C=*1997.12)								
1-2	1	719593-01562	BLOCK ASSY, CYLINDER	1						S	
	(A=*2004.03)										
4	3	119000-02410	BUSH, CAMSHAFT	1	1	1					
5	3	119593-02420	BUSH, CAMSHAFT	3	3	3					
6	3	27231-650000	PLUG, 65	1	1	1					
7	3	27241-160000	PLUG, 16	2	2	2					
8	3	27241-350000	PLUG, 35		4	4					
8-1	3	119593-01880	PLUG	4	4	4				N	
		(B=E50223)	(C=E40223)								
8-2	3	119285-11990	PLUG, 35	4	4	4				N	
	(A=E51628)	(B=E51386)	(C=E40849)								
9	3	119593-01870	PLUG	8	8	8					
9-1	3	119885-01990	PLUG, 40	8	8	8				N	
	(A=E51628)	(B=E51386)	(C=E40849)								
10	2	119000-01840	PLUG, RUBBER	5	5	5					
11	2	22312-080160	PIN, PARALLEL M8X16		2	2					
11-1	2	129100-01580	PIN, 8X16	2	2	2				R	
		(B=E50206)	(C=E40216)								
12	2	22312-080160	PIN, PARALLEL M8X16		2	2					
12-1	2	129100-01580	PIN, 8X16	2	2	2				R	
		(B=E50206)	(C=E40216)								
13	2	22312-080160	PIN, PARALLEL M8X16		4	4					
13-1	2	129100-01580	PIN, 8X16	4	4	4				R	
		(B=E50206)	(C=E40216)								
14	2	22351-080016	PIN, SPRING 8.0X16	2	2	2					
15	2	22351-040010	PIN, SPRING 4.0X10	6	6	6					
16	2	119593-02070	BOLT, METAL CAP	14	14	14					
17	2	719593-02800	BEARING, MAIN	7	7	7					
20	2	719593-02590	BEARING, THRUST	2	2	2					
26	1	119171-01101	LINER, CYLINDER	6	6	6					
27	1	119593-01200	BOLT, HEAD	26	26	26					
28	1	119593-01342	GASKET, HEAD T=1.3	1	1	1					
29	1	119593-01801	RETAINER, PUMP	1	1	1					
30	1	119593-01811	RETAINER, PUMP	1	1	1					
31	1	124411-28400	PIN	2	2	2					
32	1	26106-080162	BOLT, M8X 16 PLATED	2	2	2					
32-1	1	26106-080202	BOLT, M8X 20 PLATED	4						N	
	(A=*2003.04)										
33	1	26106-080202	BOLT, M8X 20 PLATED	2	2	2					
33-1	1	26106-100252	BOLT, M10X 25 PLATED	2						N	
	(A=*2003.04)										
34	1	26106-100802	BOLT, M10X 80 PLATED	2	2	2					
35	1	119593-01751	COVER	1	1	1					
36	1	26106-080182	BOLT, M8X 18 PLATED	2	2	2					
37	1	26106-080302	BOLT, M8X 30 PLATED	10	10	10					
38	1	26106-080452	BOLT, M8X 45 PLATED	2	2	2					
39	1	26106-080502	BOLT, M8X 50 PLATED	1	1	1					
40	1	119593-25051	SHAFT, IDLE GEAR	1	1	1					

Remarks
(1)Under-sized (U.S.=0.25) parts.
(2)Under-sized (U.S.=0.50) parts.
(3)Over-sized (O.S.=0.25) parts.
(4)Over-sized (O.S.=0.50) parts.
(5)Under sized(U.S.=1.00)cannot be sold.
(6)Over-sized (O.S.=1.00)cannot be sold.

N:Old ⇄(Yes/No) New, Q:Old ⇄(No/Yes) New, R:Old ⇄(Yes/Yes) New, S:Old ⇄(No/No) New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.6. CYLINDER HEAD



(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	719593-11700	HEAD ASSY, CYLINDER	1	1						
1-1	1	719574-11700	HEAD ASSY, CYLINDER	1						S	
	(A=*2002.07)										
1-2	1	719574-11701	HEAD ASSY, CYLINDER	1						N	
	(A=*2003.04)										
1A	1	719573-11700	HEAD ASSY, CYLINDER			1					
5	3	119173-11080	SEAT, INTAKE VALVE	6	6	6					
6	3	119173-11090	SEAT, EXHAUST VALVE	6	6	6					
6-1	3	119173-11091	SEAT, VALVE	6						N	
	(A=*2003.04)										
9	3	123385-82200	PLUG, 1/16		1	1					
9-1	3	23876-005000	PLUG, R005	1	1	1				N	
		(B=E50835)	(C=E40472)								
10	3	23871-030000	PLUG, R03		1	1					
10-1	3	23875-030000	PLUG, R03	1	1	1				R	
		(B=E50835)	(C=E40472)								
11	3	119593-01860	PLUG	6	6	6					
12	3	27241-280000	PLUG, 28	5	5	5					
13	3	27241-400000	PLUG, 40	2	2	2					
14	2	119173-11101	VALVE, INTAKE	6	6	6					
15	2	119173-11110	VALVE, EXHAUST			6					
15A	2	119593-11110	VALVE, EXHAUST	6	6						
16	2	124617-11120	SPRING, VALVE OUTER	12	12	12					
17	2	124617-11130	SPRING, VALVE INNER	12	12	12					
18	2	119171-11150	SEAL, VALVE STEM	6	6	6					
19	2	121850-11150	SEAL, VALVE STEM	6	6	6					
20	2	124411-11180	RETAINER, SPRING	12	12	12					
21	2	27310-090001	COTTER, 9	12	12	12					
22	2	119593-11300	STUD, M8X80	4	4	4					
22-1	2	119593-11301	STUD, M8X80	4						R	
	(A=*2003.03)										
23	2	119171-11370	CAP, VALVE	12	12	12					
24	2	119593-11910	BOLT		12	12					
24-1	2	119593-11911	BOLT	12	12	12				N	
		(B=E50405)	(C=*1998.01)								
25	2	26366-060002	NUT, M6	12	12	12					
26	2	26366-080002	NUT, M8		4	4					
26-1	2	26306-080002	NUT, M8	4	4	4				N	
		(B=E51386)	(C=E40890)								
27	1	119593-11240	SHAFT ASSY, ROCKER	1	1	1					
28	2	719593-11650	ARM ASSY, ROCKER	12	12	12					
30	3	119000-11230	SCREW, VALVE ADJUST	12	12	12					
31	3	129150-11750	NUT, M8	12	12	12					
32	2	119593-11250	SHAFT, ROCKER ARM	1	1	1					
33	2	119000-11260	SUPPORT, ROCKER ARM	1	1	1					
34	2	119000-11270	SUPPORT, ROCKER ARM	5	5	5					
35	2	119000-11280	SPRING	5	5	5					
36	2	119000-11290	BOLT	1	1	1					
37	2	22242-000180	RING, 18	2	2	2					
38	2	27241-100000	PLUG, 10	2	2	2					
39	1	119593-11870	INSULATOR	6	6	6					

Remarks
(1)Interchangeable by simultanous replacement with No.51-1, 55 & Fig.5 No.10, 11, 12, 13, 14 & Fig.8 No.3-1.
(2)Spare parts.


N:Old ⇄ New, Q:Old ⇄ New, R:Old ⇄ New, S:Old ⇄ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.25. FUEL INJECTION PUMP



(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	719573-51303	PUMP ASSY, INJECTION			1					
1A	1	719574-51311	PUMP ASSY, INJECTION	1	1						
4	3	119593-51030	CAMSHAFT			1					
4A	3	119594-51030	CAMSHAFT		1						
4A-1	3	119595-51030	CAMSHAFT	1	1					S	
		(B=E50256)									
5	3	122710-51050	BEARING, HR30203J			1					
5A	3	124410-51050	BEARING	1	1						
6	3	119000-51060	SUPPORT, BEARING A			1					
6A	3	119594-51061	SUPPORT, BEARING A		1						
6A-1	3	119595-51060	RETAINER, BEARING A	1	1					S	
		(B=E50256)									
7	3	119593-51080	COVER	1	1	1					
8	3	119593-51090	GASKET	1	1	1					
9	3	144626-51090	KEY, 5X19	1	1	1					
10	3	119593-51100	PLUNGER ASSY			6					
10A	3	119594-51100	PLUNGER ASSY	6	6						
16	3	119000-51161	SPRING, PLUNGER	6	6	6					
17	3	119000-51170	SEAT, SPRING A	6	6	6					
18	3	119000-51181	SEAT, SPRING B	6	6	6					
19	3	119573-51200	TAPPET ASSY			6					
19A	3	119594-51200	TAPPET ASSY	6	6						
19A-1	3	119574-51200	TAPPET ASSY	6	6					R	
	(A=E51623)		(B=E51386)								
19A-2	3	119578-51201	TAPPET ASSY	6						R	
	(A=*2005.12)										
24A	4	119594-51240	TAPPET	6	6						
26	3	129155-51270	STOPPER, TAPPET	6	6	6					
26-1	3	158600-51270	STOPPER, TAPPET	6						R	
	(A=*2009.09)										
27	3	129155-51280	O-RING, S6	6	6	6					
28	3	119593-51300	VALVE ASSY, DELIVERY			6					
28A	3	119594-51301	VALVE ASSY, DELIVERY	6	6						
31	3	119000-51330	SPRING, DELIVERY	6	6	6					
32	3	119175-51340	VALVE ASSY, DELIVERY			6					
32A	3	119594-51341	VALVE ASSY, DELIVERY	6	6						
40	3	122710-51350	GASKET			6					
40A	3	119594-51290	GASKET	6	6						
41	3	119000-51410	O-RING, S18	12	12	12					
41-1	3	119000-51411	O-RING	12						N	
	(A=*2005.11)										
42	3	119000-51450	SHIM SET, CAMSHAFT			1					
42A	3	119594-51451	SHIM SET, CAMSHAFT	1	1						
48	3	129155-51410	BOLT	2	2						
48-1	3	158600-51410	PLUG, DEFLECTOR	1						R	
	(A=*2006.10)										
49	3	119593-51500	RACK, CONTROL	1	1	1					
50	3	119000-51510	SLEEVE, CONTROL			6					
50-1	3	119000-51511	SLEEVE, CONTROL	6	6	6				R	
		(B=E50723)	(C=E40442)								
51	3	119593-51520	WASHER	1	1	1					


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\rightleftarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\rightleftarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIX-THIS.COM
Download full manual at youfixthis.com

Fig.36. WIRE HARNESS & SENSOR



Remarks
(1)Optional parts.
(2)Optional parts. 12v
(3)VDO spec.(Optional parts)
(4)Interchangeable by simultaneous replacement with No.2-2, 7-1, 63, 64, 65.
(5)GENERATOR : spec. of HITACHI.
(6)GENERATOR : spec. of BOSCH.

(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	119573-77813	HARNESS, WIRE		1	1					
1-1	1	119573-77814	HARNESS, WIRE		1	1				N	
		(B=E50556)	(C=E40388)								
1-2	1	119574-77810	HARNESS, WIRE	1	1	1				N	
		(B=E50905)	(C=E40492)								
1-3	1	119574-77811	HARNESS, WIRE	1	1	1				N	5
	(A=E51735)	(B=E51386)	(C=E40938)								
1-4	1	119574-77812	HARNESS, WIRE	1						S	6
	(A=E00782)										
2	1	129100-77910	RELAY, MAGNETIC		1	1					
2-1	1	129490-77910	RELAY, STARTER	1	1	1				N	
		(B=E50626)	(C=E40408)								
2-2	1	119575-77510	RELAY, STARTER	1	1	1				F	4
	(A=*2004.06)	(B=*2004.06)	(C=*2004.06)								
2-3	1	119575-77511	RELAY, STARTER	1						N	
	(A=*2008.06)										
3	1	124770-49310	RETAINER	1	1	1					
4	1	105430-67110	CLAMP, CORD	1	1	1					
4-1	1	105430-67110	CLAMP, CORD	5	5	5				K	
	(A=E51735)	(B=E51386)	(C=E40938)								
5	1	123682-77710	PROTECTOR	1	1	1					
6	1	119171-77850	HARNESS, WIRE	1	1	1					
7	1	26106-060122	BOLT, M6X 12 PLATED	2	2	2					
7-1	1	26106-060202	BOLT, M6X 20 PLATED	2	2	2				F	4
	(A=*2004.06)	(B=*2004.06)	(C=*2004.06)								
8	1	26106-080162	BOLT, M8X 16 PLATED	1	1	1					
9	1	128170-91160	SENSOR	1	1	1					
10	1	127610-91350	SWITCH, 95	1	1	1					
11	1	144626-91570	SENDER UNIT	1	1	1					
12	1	124060-39451	SWITCH, 0.2KG		1	1					
12-1	1	124060-39452	SWITCH, 0.2KG	1	1	1				N	
		(B=E50965)	(C=E40589)								
13	1	26106-080202	BOLT, M8X 20 PLATED	3	3	3					
14	1	127687-91300	SENSOR		1	1					
14-1	1	119773-91300	SENSOR	1	1	1				N	
		(B=E51263)	(C=E40708)								
14-2	1	119773-91301	SENSOR	1	1	1				N	
	(A=E51623)	(B=E51386)	(C=E40795)								
15	1	144626-91560	SENSOR		1	1					
15-1	1	119773-91500	SENDER		1	1				N	
		(B=*1997.09)	(C=*1997.05)								
15-2	1	119773-91501	SENSOR	1	1	1				N	
		(B=E51263)	(C=E40708)								
16	1	129574-91560	SENSOR	1	1	1					1
16-1	1	129574-91561	SENSOR	1	1	1				R	1
	(A=E51655)	(B=E51386)	(C=E40890)								
17	1	129574-91570	SENSOR	1	1	1					1
18	1	124617-91850	RELAY		1	1					1
18-1	1	119773-91850	RELAY	1	1	1				R	1
		(B=E50965)	(C=E40589)								
19	1	46150-507600	HARNESS, WIRE	1	1	1					1


N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.37. INSTRUMENT PANEL-B(OPTIONAL)



(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	127675-91100	PANNEL ASSY	1	1	1					
2	2	124411-91010	BODY, PANEL	1	1	1					
3	2	104271-91352	BUZZER 12V	1	1	1					
4	2	128170-91310	SWITCH	1	1	1					
5	2	129470-91190	SWITCH, STOP	1	1	1					
6	2	121575-91250	SWITCH, KEY	1	1	1					
7	2	128170-91020	GASKET	1	1	1					
8	2	124617-91920	BULB, 12V-3W	4	4	4					
9	2	127675-91660	HARNESS, WIRE	1	1	1					
10	2	128170-91810	SCREW, M5X35	6	6	6					
11	2	128170-91820	WASHER, 5	6	6	6					
12	2	128170-91830	NUT, M5	6	6	6					
13	2	127675-91650	TACHOMETER	1	1	1					
14	1	129574-77860	HARNESS, WIRE	1	1	1					


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.52. TOOL & LABEL



(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	177040-09050	WRENCH	1	1	1					1
2	1	28170-001500	PLIER	1	1	1					1
3	1	104200-92350	DRIVER, SCREW	1	1	1					1
4	1	122210-92600	BOX, TOOL	1	1	1					1
5	1	127610-92750	WRENCH, FILTER	1	1	1					1
6	1	28110-100130	SPANNER, 10X13	1	1	1					1
7	1	28110-120140	SPANNER, 12X14	1	1	1					1
8	1	28110-170190	SPANNER, 17X19	1	1	1					1
9	1	28110-220240	SPANNER, 22X24	1	1	1					1
10	1	28120-002000	WRENCH, 200	1	1	1					1
11	1	28230-120300	HANDLE, TURN 12X300	1	1	1					1
12	1	123682-07851	LABEL, CAUTION	1	1	1					
12-1	1	123682-07852	LABEL, CAUTION	1						N	
	(A=*2002.05)										
13	1	128296-07260	LABEL, DANGER	1	1	1					
14	1	128296-07350	LABEL, DANGER	1	1	1					
15	1	128296-07300	LABEL, DANGER	1	1	1					
16	1	120324-07240	LABEL, DANGER	1	1	1					
17	1	128171-07150	LABEL	1	1	1					
18	1	119574-07400	LABEL	5	5	5					
21A	1	128296-07190	LABEL,LOOSE PARTS	1	1	1				W	
			(B=E50966) (C=E40622)								
22	2	128296-07450	LABEL, DANGER	1	1	1				W	
			(B=E50966) (C=E40622)								
23	2	128296-07460	LABEL, DANGER	1	1	1				W	
			(B=E50966) (C=E40622)								
24	2	128296-07420	LABEL, DANGER	1	1	1				W	
			(B=E50966) (C=E40622)								
25	2	128296-07400	LABEL, DANGER	1	1	1				W	
			(B=E50966) (C=E40622)								
26	1	119574-07450	LABEL	1	1	1				W	
			(B=FROM 1ST) (C=FROM 1ST)								
27	1	119773-07280	LABEL, DANGER	1	1	1				W	
			(B=E50369) (C=*1997.11)								
28	1	196630-12980	LABEL, CAUTION	1	1	1				W	
			(B=E50966) (C=E40622)								
32	1	119175-07260	LABEL,CAUTION	1						W	
	(A=*2013.05)										

Remarks
(1)Optional parts.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Parts No. Index

Parts No.	Fig. No.	Ref. No.
101304-59020	36	28
104200-92350	52	3
	57	2
104200-92600	57	3
104264-59030	8	39
104271-91352	37	3
	42	12
	44	15
	45	15
	46	15
	47	15
	48	18
	49	18
	50	18
	51	18
105100-55501	36	26
105100-55540	36	27
	54	21
105430-67110	36	4
		4 -1
106100-55800	28	30
	34	21
	35	31
	55	9
114250-53080	29	36
114250-53130	29	38
114250-53140	29	39
114250-53210	29	13
		41
114250-53400	29	14
		46
114780-61090	26	89 -1
119000-01740	2	3
119000-01771	2	4
119000-01840	1	10
119000-02410	1	4
119000-02450	12	2
119000-11180	6	49
119000-11230	6	30
119000-11260	6	33
119000-11270	6	34
119000-11280	6	35
119000-11290	6	36
119000-14100	12	4
119000-14200	12	6
119000-25060	1	44 -1
119000-25100	1	42 -1
119000-25920	28	26
119000-34030	15	11
119000-51050	25	76
119000-51060	25	6
119000-51161	25	16
119000-51170	25	17
119000-51181	25	18
119000-51330	25	31
119000-51410	25	41
119000-51411	25	41 -1
119000-51450	25	42
119000-51510	25	50
119000-51511	25	50 -1
119000-51550	25	53
119000-51570	25	54
119000-51580	25	55
119000-51590	25	56
119000-51650	25	57
119000-51800	25	71
119000-51900	25	73
119000-61051	26	86
119000-61052	26	86 -1
119000-61120	26	6
119000-61170	26	7
119000-61180	26	91
119000-61470	26	109
119000-61490	26	18
119000-61630	26	39
119100-26200	21	22
119129-77210	33	21
119129-77250	35	14
119129-77260	35	15
119129-77320	35	3
119129-77890	35	21
119129-77900	35	22
119129-77930	35	19
119129-77940	34	12
	35	12
119171-01101	1	26
119171-11150	6	18
119171-11370	6	23
119171-14400	12	7
119171-34820	4	23
119171-77850	36	6
119172-48130	7	10 -1
	8	40 -1
	30	18 -4
	36	32 -1
119172-48190	30	19 -2
		64 -1
119172-48280	5	8 -1
	17	9 -1
	24	8 -1
119172-48350	5	14 -1
119172-48480	8	20 -1
		57
		58
	23	5 -1
		17 -1
		20 -1
		28
119172-48540	23	13 -1
		18 -1
119173-03030	5	3
119173-11080	6	5
119173-11090	6	6
119173-11091	6	6 -1
119173-11101	6	14
119173-11110	6	15
119173-22300	14	9
119173-61200	26	92
119173-61400	26	9
119173-61650	26	134
119173-61651	26	134 -1
119173-61660	26	135
119174-61500	26	19
119175-07260	52	32
119175-42620	21	20
119175-51070	25	88 A-1
119175-51340	25	32
119175-53000	29	3 A
119175-77500	33	46
119175-77800	33	47
119175-91510	54	2
119175-91560	54	3
119175-91600	54	4
119175-91630	54	5
119175-91640	54	6
119175-91650	54	7
119181-59950	30	17
119187-59562	30	14 -1
119187-61071	26	87
119187-61190	26	8
119187-61300	26	99
119187-61911	26	28
119187-61920	26	29
119187-61930	26	30
119189-91260	44	8 -1
	48	8 -1
119189-91261	45	8
	49	8
119189-91262	46	8
	47	8
119189-91262	50	8
	51	8
119192-54860	28	17
119192-54870	28	18
119192-54880	28	19
119192-54890	28	20
119192-54910	28	21
119195-53000	29	3
119285-11990	1	8 -2
119573-08200	3	17
		17 -1
119573-51200	25	19
119573-59710	29	24
119573-59720	29	25
119573-59730	29	26
119573-59740	29	27
119573-59750	29	28
119573-59760	29	29
119573-61010	26	4
119573-61030	26	4 -1
119573-61551	26	110
119573-77200	34	1
119573-77201	35	1
		1 -1
119573-77250	34	30
	35	32
119573-77260	34	31
	35	33
119573-77270	34	32
	35	34
119573-77813	36	1
119573-77814	36	1 -1
119573-77850	32	9
119573-91130	42	1
119573-91200	42	2
	43	2
	44	2
	45	2
	46	2
	47	2
	48	2
	49	2
	50	2
	51	2
119574-03060	5	15
119574-03070	5	16
119574-03080	5	17
119574-03090	5	4
119574-03120	5	11 -1
119574-03130	5	12 -1

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM


Contents

Fig. No.	Fig. Name	Fig. No.	Fig. Name
47.	INSTRUMENT PANEL-C(OPTIONAL)(FROM OCT. 1999)		
48.	INSTRUMENT PANEL-D(OPTIONAL)(TO APR. 1998)		
49.	INSTRUMENT PANEL-D)(OPTIONAL)(TO JUL. 1999)		
50.	INSTRUMENT PANEL-D(OPTIONAL)(TO SEP. 1999)		
51.	INSTRUMENT PANEL-D(OPTIONAL)(FROM OCT. 1999)		
52.	TOOL & LABEL		
57.	(52A)TOOL(STANDARD)		
54.	TURN OVER SWITCH(SOLAS)(OPTIONAL)		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.20. COOLING FRESH WATER PUMP & THERMOSTAT



(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=


No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	119593-42010	PUMP ASSY, WATER	1	1	1					
2	2	XKWPY642021	GASKET	1	1	1					
3	2	XKWPY642101	GASKET		1	1					
3-1	2	119593-42130	GASKET	1	1	1					R
		(B=FROM 1ST) (C=FROM 1ST)									
3-2	2	119578-42130	GASKET	1							R
	(A=*2005.11)										
4	2	23871-030000	PLUG, R03	2	2	2					
4A	2	119593-42120	FLANGE	1	1	1					W
		(B=FROM 1ST) (C=FROM 1ST)									
5	1	119593-42021	GASKET, WATER PUMP	1	1	1					
6	1	119593-42300	V-PULLEY	1	1	1					
7	1	24321-000450	O-RING, 1AG45.0	1	1	1					
8	1	26106-080182	BOLT, M8X 18 PLATED	4	4	4					
9	1	26106-080302	BOLT, M8X 30 PLATED	1	1	1					
10	1	26106-080802	BOLT, M8X 80 PLATED	2	2	2					
11	1	26106-080952	BOLT, M8X 95 PLATED	2	2	2					
12	1	119593-49291	GASKET, THERMOSTAT	1	1	1					
13	1	119593-49530	COVER, THERMOSTAT	1	1	1					
14	1	119593-49550	THERMOSTAT, 76.5	1	1	1					
15	1	26106-080252	BOLT, M8X 25 PLATED	3	3	3					
16	1	26106-080452	BOLT, M8X 45 PLATED	1	1	1					
17	1	119593-42280	V-BELT, A53	1	1	1					

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.36. WIRE HARNESS & SENSOR



Remarks
(1)Optional parts.
(2)Optional parts. 12v
(3)VDO spec.(Optional parts)
(4)Interchangeable by simultaneous replacement with No.2-2, 7-1, 63, 64, 65.
(5)GENERATOR : spec. of HITACHI.
(6)GENERATOR : spec. of BOSCH.

(A)=6LYA-STP (D)=
(B)=6LYA-STE (E)=
(C)=6LYA-UTE (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
40	1	22217-050000	WASHER, SPRING 5	1	1	1				W	
		(B=E50957)	(C=E40533)								
41	1	26557-050082	SCREW, M5X 8	1	1	1				W	
		(B=E50957)	(C=E40533)								
42	1	121750-59890	BAND, 140	4		4				W	
	(A=E51735)		(C=E40938)								
43	1	194250-51660	BAND, NYLON	2		2				W	
	(A=E51735)		(C=E40938)								
44	1	119574-39770	JOINT	1	1	1				W	
		(B=E50474)	(C=E40348)								
45	1	23414-120000	GASKET, 12X1.0	1	1	1				W	3
		(B=E51263)	(C=E40708)								
46	1	23871-020000	PLUG, R02	1	1	1				W	3
		(B=E51263)	(C=E40708)								
47	1	23871-030000	PLUG, R03	1	1	1				W	3
		(B=E51263)	(C=E40708)								
48	1	23887-120002	PLUG, 12	1	1	1				W	3
		(B=E51263)	(C=E40708)								
49	1	119773-91600	SENDER	1	1	1				W	3
		(B=E51263)	(C=E40708)								
50	1	119773-91650	SENSOR	1	1	1				W	3
		(B=E51263)	(C=E40708)								
51	1	119773-91700	SENDER	1	1	1				W	3
		(B=E51263)	(C=E40708)								
52	1	119575-77050	PLUG	2	2	2				W	
		(B=E50905)	(C=E40492)								
53	1	119575-77060	RELAY, HEATER	1	1	1				W	
		(B=E50905)	(C=E40492)								
54	1	119575-77071	CONTROLLER	1	1	1				W	
		(B=E50905)	(C=E40492)								
55	1	119575-77551	BRACKET	1	1	1				W	
		(B=E50905)	(C=E40492)								
56	1	119575-77910	HARNESS, WIRE	1	1	1				W	
		(B=E50905)	(C=E40492)								
56-1	1	119575-77911	HARNESS,HEATER RELAY	1						N	
	(A=*2012.08)										
57	1	124616-91370	SWITCH, 42	1	1	1				W	
		(B=E50905)	(C=E40492)								
58	1	23414-200000	GASKET, 20X1.0	2	2	2				W	
		(B=E50905)	(C=E40492)								
59	1	26106-060122	BOLT, M6X 12 PLATED	2	2	2				W	
		(B=E50905)	(C=E40492)								
60	1	26106-080142	BOLT, M8X 14 PLATED	5	5	5				W	
		(B=E50905)	(C=E40492)								
61	1	29622-250001	BAND, RF250	2	2	2				W	
		(B=E50905)	(C=E40492)								
62	1	26366-060002	NUT, M6	2	2	2				W	
		(B=E50206)	(C=E40216)								
63	1	183350-55130	WASHER	2	2	2				W	4
	(A=*2004.06)	(B=*2004.06)	(C=*2004.06)								
64	1	119575-77200	BRACKET, RELAY	1	1	1				W	4

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrow}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrow}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrow}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrow}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 101 pages

The full manual includes:

- All 101 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar 6LYA-STP, 6LYA-STE, 6LYA-UTE Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual