PREFACE

1. This parts catalog carries Yanmar wheel excavator B50W & B50W - 1.

2. Parts catalog history

	Parts catalog No.	Published	Remarks
1st edition	000Y00S3380	1994/ 7	Scrap old edition
1st revised	000Y00S3381	1998/11	

3. Model name

SECTION	Column	Model name	Remarks
I (Vehicle)	(A)	B50W(- 1)	
II (Engine)	(A)	4TN84TL - RBS	for B50W
III (Engine)	(A)	4TNE84T - BS	for B50W - 1

4. Your understanding is asking that this parts catalog is not a technical data manual setting forth as servicing procedures, This parts catalog is using simplified illustration. Be sure to use Yanmar Genuine Parts in your maintenance servicing of Yanmar products. Be careful not to use the simple parts available in the market ; otherwise their use in repairing causes such as an early breakage, for instance.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

```
0,Y00S3381
1,001,,"VEHICLE B50W-1"
2,1,,LABEL(ENGLISH),B50W(-1),,,
2,2,,"REAR VIEW MIRROR",B50W(-1),,,
2,3,,"ENGINE CONTROL SYSTEM(1/2)",B50W(-1),,,
2,4,,"ENGINE CONTROL SYSTEM (2/2)",B50W(-1),,,
2,5,,"ENGINE MOUNTING",B50W(-1),,,
2,6,,"INTAKE & EXHAUST SYSTEM",B50W(-1),,,
2,7,,"COOLING SYSTEM",B50W(-1),,,
2,8,,"FUEL TANK",B50W(-1),,,
2,9,,"FUEL LINE",B50W(-1),,,
2,10,,"BATTERY INSTALL",B50W(-1),,,
2,11,,"ELECTRICAL SYSTEM",B50W(-1),,,
2,12,,"INSTRUMENT PANEL",B50W(-1),,,
2,13,,"CONTROL BOX(1/2)",B50W(-1),,,
2,14,,"CONTROL BOX (2/2)",B50W(-1),,,
2,15,,"HEATER & DEFROST MOUNTING",B50W(-1),,,
2,16,,"POWER TRAIN INSTALL",B50W(-1),,,
2,17,,"TRANSFER GEAR BOX CASE",B50W(-1),,,
2,18,,"GEAR BOX MOTOR & PUMP",B50W(-1),,,
2,19,,"FRONT AXLE HOUSING",B50W(-1),,,
2,20,,"FRONT DIFFERENTIAL CARRIER",B50W(-1),,,
2,21,,"FRONT AXLE CASE",B50W(-1),,,
2,22,,"FRONT BRAKE DISC",B50W(-1),,,
2,23,,"STEERING CYLINDER",B50W(-1),,,
2,24,,"REAR AXLE HOUSING",B50W(-1),,,
2,25,,"REAR DIFFERENTIAL CARRIER",B50W(-1),,,
2,26,,"REAR AXLE CASE",B50W(-1),,,
2,27,,"REAR BRAKE DISC",B50W(-1),,,
2,28,,"WHEEL RIM & TIRE",B50W(-1),,,
2,29,,"TRANSMISSION CONTROL",B50W(-1),,,
2,30,,"CONTROL LINK INSTALL(1/2)",B50W(-1),,,
2,31,,"CONTROL LINK INSTALL(2/2)",B50W(-1),,,
2,32,,"STEERING WHEEL & COLUMN",B50W(-1),,,
2,33,,"STEERING UNIT (1/2)",B50W(-1),,,
2,34,,"STEERING UNIT (2/2)",B50W(-1),,,
2,35,,"UPPER & LOWER FRAME",B50W(-1),,,
2,36,,"SWING SYSTEM",B50W(-1),,,
2,37,,"FLOOR & BOTTOM PLATE",B50W(-1),,,
2,38,,"BOTTOM COVER",B50W(-1),,,
2,39,,"BONNET INSTALL",B50W(-1),,,
2,40,,"CABIN INSTALL (1/3)",B50W(-1),,,
2,41,,"CABIN INSTALL (2/3)",B50W(-1),,,
2,42,,"CABIN INSTALL (3/3)",B50W(-1),,,
2,43,,"CABIN ELECTRICAL",B50W(-1),,,
2,44,,"PUMP MOUNTING",B50W(-1),,,
2,45,,"MAIN PUMP ASSY(INC.PUMP,HORN T",B50W(-1),,,
2,46,,"SWING CYLINDER ASSEMBLY",B50W(-1),,,
2,47,,"BUCKET CYLINDER ASSEMBLY",B50W(-1),,,
2,48,,"ARM CYLINDER ASSEMBLY",B50W(-1),,,
2,49,,"BLADE CYLINDER ASSEMBLY",B50W(-1),,,
2,50,,"BOOM CYLINDER ASSEMBLY",B50W(-1),,,
2,51,,"AXLE LOCKING CYLINDER ASSEMBLY",B50W(-1),,,
2,52,,"BRAKE CYLINDER ASSEMBLY",B50W(-1),,,
2,53,,"TRAVEL MOTOR ASSEMBLY",B50W(-1),,,
2,54,,"ROTARY GROUP(TRAVEL MOTOR ASSY",B50W(-1),,,
2,55,,"CONTROL(TRAVEL MOTOR ASSEMBLY)",B50W(-1),,,
2,56,,"SWING MOTOR",B50W(-1),,,
2,57,,"TURNING JOINT",B50W(-1),,,
2,58,,"MAIN CONTROL VALVE",B50W(-1),,,
2,59,,"3RD VALVE",B50W(-1),,,
2,60,,"HYDRAULIC TANK INSTALL",B50W(-1),,,
2,61,,"ATTACHMENT PIPING(1/2)",B50W(-1),,,
```

PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

1,1,,E109203922,,"DECAL KIT",1,,,,,,,,,,,,,,,
2,2,,E109203930,,NAME-MODEL(LH),1,,,,,,,,,,,,,,,
3,2,,E109203940,,NAME-MODEL(RH),1,,,,,,,,,,,,,,,
4,2,,E109203950,,"MARK-TRADE BOOM",2,,,,,,,,,,,,,,,
5,2,,E109203960,,"MARK-TRADE COWL",1,,,,,,,,,,,,,,,
6,2,,E109204000,,"DECAL,DANGER",1,,,,,,,,,,,,,,,
7,2,,E109204041,,"DECAL,BONNET",1,,,,,,,,,,,,,,,
8,2,,E109204020,,"GREASING,MAIN",1,,,,,,,,,,,,,,,
9,2,,E109204030,,"DECAL,SERVICE",1,,,,,,,,,,,,,,,
9-1,2,,E109204031,,"DECAL,SERV.LUB.",1,,,,,S,,*,"M/# 0060-",,,,,,,
10,2,,E109204100,,"DECAL,OIL LUB.",1,,,,,,,,,,,,,,,
11,2,,E109204110,,"DECAL,FUEL LUB.",1,,,,,,,,,,,,,,,
12,2,,E109203980,,"PLATE,NAME",1,,,,,,,,,,,,,,,
13,2,,E109204381,,"IDEOGRAM,WORKING",1,,,,,,,,,,,,,,,
14,2,,E109204561,,"DECAL,WARNING",1,,,,,,,,,,,,,,,
15,2,,E109204081,,"DECAL,RESTART",1,,,,,,,,,,,,,,,
16,2,,E109204531,,"DECAL,TRAVEL",1,,,,,,,,,,,,,,,
17,2,,E109204270,,"DECAL,ACC.",1,,,,,,,,,,,,,,,
18,2,,E109204050,,"DECAL,T/AIR PRE.",1,,,,,,,,,,,,,,,
19,2,,E109204570,,"DECAL,SPEED",3,,,,,,,,,,,,,,,
20,2,,E109204070,,GREASING,1,,,,,,,,,,,,,,,
21,2,,E109204300,,"IDEOGRAM,PARKING",1,,,,,,,,,,,,,,,
22,2,,E109204490,,"DECAL,SUB TANK",1,,,,,,,,,,,,,,,
23,2,,E109204390,,"MAT,NON SLIP",1,,,,,,,,,,,,,,,
24,2,,E109204310,,PLATE-NAME,1,,,,,,,,,,,,,,,
25,2,,EP4100152,,RIVET,4,,,,,,,,,,,,,,,
26,2,,E109204500,,"PLATE,NAME",1,,,,,,,,,,,,,,,
27,2,,E109204260,,"DECAL,PTO.",1,,,,,,,,,,,,,,,
28,2,,E109204161,,"DECAL,CYL.STOP",1,,,,,,,,,,,,,,,
29,2,,E109204170,,"DECAL,MANUAL",1,,,,,,,,,,,,,,,
30,2,,E109204181,,"DECAL,CONTACT",1,,,,,,,,,,,,,,,
31,2,,E109204191,,"DECAL,RESERVER",1,,,,,,,,,,,,,,,
32,2,,E109204200,,"DECAL,TRANSPORT",1,,,,,,,,,,,,,,,
33,2,,E109204220,,"DECAL,BOOSTER",1,,,,,,,,,,,,,,,
34,2,,E109204241,,"DECAL,NEUTRAL",1,,,,,,,,,,,,,,,
35,2,,E109204281,,"DECAL,RADIATOR",1,,,,,,,,,,,,,,,
36,2,,E109204291,,"DECAL,ENG.ROOM",1,,,,,,,,,,,,,,,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Fig. 5 ENGINE MOUNTING



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig. 16 POWER TRAIN INSTALL




PREVIEW - YOUFIXTHIS.COM


Download full manual at youfixthis.com

Fig. 34 STEERING UNIT 2/2


1 inc. Fig. 33 REF.NO. 2～21
Fig. 34 REF.NO. 2～18

2 inc. 3～18






SECTION A-A




SECTION B—B



SECTION C—C

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com


Fig. 12 INSTRUMENT PANEL



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Fig. **44** PUMP MOUNTING



REVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig. 82 BOOM ASSEMBLY




PREVIEW: YOUFIXTHIS.COM
Download full manual at youfixthis.com

```
1,1,,E106607942,,"SUPPORT,MIRROR",1,,,,,,,,,,,,,,,
2,1,,E106609160,,"MIRROR,BACK",1,,,,,,,,,,,,,,,
3,1,,E901110805,,"BOLT,HEX.HD.M 8X 25",2,,,,,,,,,,,,,,,
4,1,,E921308000,,"WASHER,SPRING  8",2,,,,,,,,,,,,,,,
5,1,,E921108000,,"WASHER,PLAIN  8",4,,,,,,,,,,,,,,,
6,1,,E911110800,,"NUT,HEX.HD.M 8",2,,,,,,,,,,,,,,,
7,1,,E106609940,,"RAIL, GLOVE",1,,,,,,,,,,,,,,,
8,1,,E901111004,,"BOLT,HEX.HD.M10X 20",8,,,,,,,,,,,,,,,
9,1,,E921310000,,"WASHER,SPRING 10",8,,,,,,,,,,,,,,,
```

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig. 30 CONTROL LINK INSTALL 1/2



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

1,1,,E107401680,,"VALVE ASSY.,3RD",1,,,,,,,,,,,,,,,
2,2,,E17214174790,,PLATE,1,,,,,,,,,,,,,,,
3,2,,E17214174820,,PLATE,1,,,,,,,,,,,,,,,
4,2,,E17214174830,,COVER,1,,,,,,,,,,,,,,,
5,2,,E17214174840,,SPRING,1,,,,,,,,,,,,,,,
6,2,,E17214174850,,RETAINER,1,,,,,,,,,,,,,,,
7,2,,E17214174860,,SLEEVE,1,,,,,,,,,,,,,,,
8,2,,E17214174870,,"KIT,SEAL",1,,,,,,,,,,,,,,,
9,2,,E17214174890,,WASHER,1,,,,,,,,,,,,,,,
10,2,,E17214174900,,GUIDE,1,,,,,,,,,,,,,,,
11,2,,E17214174910,,SPACER,1,,,,,,,,,,,,,,,
12,2,,E17214174920,,"VALVE,RELIEF",1,,,,,,,,,,,,,,,
13,2,,E17214174930,,STUD,2,,,,,,,,,,,,,,,
14,2,,E17214174950,,PLUG,3,,,,,,,,,,,,,,,
15,2,,E24190050002,,BALL,2,,,,,,,,,,,,,,,
16,2,,E26450060162,,BOLT,1,,,,,,,,,,,,,,,
17,2,,E26450060202,,BOLT,7,,,,,,,,,,,,,,,
18,2,,E26557080502,,BOLT,1,,,,,,,,,,,,,,,

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 178 pages

The full manual includes:

- All 178 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar B50W, B50W-1, 4TN84TL-RBS, 4TNE84T-BS Parts Catalog



Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual