
Fig.1. CYLINDER BLOCK



(A)=L70N5AJ8T2AAWK (D)=
(B)= (E)=
(C)= (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	114210-01020	BLOCK ASSY, CYLINDER	1							
5	1	114395-01341	GASKET, HEAD 0.5	1							
6	1	114399-01380	O-RING	1							
7	1	114299-01800	SHIM SET	1							
18	1	114299-01830	COVER	1							
19	1	114250-01841	GASKET	1							
20	1	22312-040080	PIN, PARALLEL M4X 8	2							
21	1	23875-020000	PLUG, R02	1							
22	1	114299-01600	PIN, 8X12	2							
23	1	26226-060182	STUD, M6X 18	1							
24	1	26226-060222	STUD, M6X 22	2							
25	1	26366-060002	NUT, M6	3							
26	1	114399-01410	GASKET, CRANK CASE	1							
27	1	114210-01450	COVER(E-D,CRANK CASE	1							
30	2	114350-02100	BEARING, MAIN	1							1
32	1	114299-35150	PIPE, OIL INLET	1							
33	1	26106-080352	BOLT, M8X 35 PLATED	15							
34	1	114299-01690	PLUG M16	2							
35	1	114699-01760	CAP ASSY	2							
37	2	114299-01950	O-RING, 18	2							
38	1	22190-160002	WASHER, SEAL 16	2							
39	1	114299-02030	RETAINER, BEARING	1							
40	1	114350-02113	BEARING, B35-135G3C3	1							
41	1	160110-02220	SEAL, OIL	1							
42	1	160110-02220	SEAL, OIL	1							
43	1	24162-152116	BEARING, 152116	1							
44	1	26106-080122	BOLT, M8X 12 PLATED	1							
45	1	114350-02200	BEARING, 0.25 US	1							2
46	1	114350-02210	BEARING, 0.50 US	1							3
47	1	23876-010000	PLUG, R01	1							

Remarks
(1)Repair parts.
(2)Under sized(U.S.=0.25)parts.
(3)Under sized(U.S.=0.50)parts.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Parts No. Index

Parts No.	Fig. No.	Ref. No.
105010-11490	2	28
105546-51020	8	2
105546-51330	8	8
114210-01020	1	1
114210-01200	2	1
114210-01210	2	2
114210-01450	1	27
114210-03590	2	38
114210-11120	2	10
114210-11180	2	11
114210-11310	2	35
	11	24
114210-11901	2	30
114210-11930	2	12
114210-11950	2	36
114210-12210	3	16
	11	25
114210-12560	3	8
114210-12590	3	9
114210-12600	3	12
114210-14200	5	6
114210-14300	5	7
114210-14400	5	12
114210-23600	5	43
114210-23610	5	63
114210-23620	5	65
114210-45350	7	12
114210-45360	7	13
114210-55210	9	10
114210-55230	9	11
114210-55810	9	14
114210-59800	9	28
114210-59850	9	34
114210-61290	6	27
114210-66060	6	37
114210-66100	6	41
114211-61500	6	15
114211-66600	6	52
11421C-11100	2	8
11421C-11110	2	9
11421C-11250	2	14
11421C-11260	2	15
11421C-11650	2	17
11421C-11660	2	21
11421C-45100	7	17
11421C-45260	7	8
11421C-45270	7	9
11421C-45300	7	4
11421C-45310	7	5
11421C-55710	9	1

Parts No.	Fig. No.	Ref. No.
114220-07100	11	4
114220-07110	11	5
114220-07120	7	2
114220-07130	11	7
114220-07160	11	8
114220-11020	2	3
114220-12510	3	1
114220-12910	3	3
114220-66010	6	50
114220-92600	11	10
11422C-45200	7	1
114239-12520	3	2
114239-12900	4	1
114239-12950	4	4
114239-51400	8	11
114239-53050	8	23
114239-55120	9	8
114239-59300	9	22
114250-01841	1	19
	11	20
114250-11240	2	19
		23
114250-32010	6	1
114250-51080	8	3
114250-51160	8	4
114250-51340	8	9
114250-51600	8	18
114250-51640	8	19
114250-51650	8	20
114250-53080	8	26
114250-53120	8	32
114250-53130	8	33
114250-53140	8	34
114250-53210	8	35
114250-53400	8	36
114250-55201	9	7
114250-55301	9	12
114268-13700	3	22
114299-01600	1	22
114299-01690	1	34
114299-01800	1	7
114299-01830	1	18
114299-01950	1	37
	11	19
114299-02030	1	39
114299-03640	2	41
114299-07100	11	2
114299-07110	11	3
114299-07160	11	6
114299-11600	2	29

Parts No.	Fig. No.	Ref. No.
114299-12210	11	32
114299-12300	3	15
114299-12920	11	33
114299-13200	3	19
	11	26
114299-13800	3	14
114299-21220	5	21
114299-21550	5	22
114299-32070	6	7
114299-32570	6	8
	11	27
114299-35110	6	11
114299-35150	1	32
114299-45220	7	7
114299-45301	7	18
114299-45310	7	19
114299-45331	7	20
114299-45350	7	21
114299-55040	9	5
114299-55080	9	3
114299-55100	9	6
114299-61190	6	35
114299-61600	6	33
114299-66200	6	51
114299-66250	6	47
114299-66440	6	42
114299-67080	6	43
		60
114339-11451	2	26
114339-11551	2	27
114339-53100	8	27
114339-53130	8	28
114350-02100	1	30
114350-02113	1	40
114350-02200	1	45
114350-02210	1	46
114350-11340	2	25
	11	22
114350-45340	7	6
114351-77520	10	35
114362-77011	10	1
114368-13501	3	20
114371-77160	10	7
114371-77170	10	13
114371-77180	10	14
114371-79040	10	8
114371-79050	10	9
114371-79060	10	10
114371-79070	10	17
114380-23100	5	41

Parts No.	Fig. No.	Ref. No.
114381-77110	10	2
114381-77130	10	5
114381-77140	10	6
114381-77151	10	12
114395-01330	11	11
114395-01341	1	5
114399-01380	1	6
	11	17
114399-01410	1	26
	11	18
114399-21590	5	23
114399-21600	5	26
114399-21980	11	34
114399-22300	5	36
114399-45320	7	10
114399-45340	7	11
114399-76251	7	23
114399-76510	7	24
114399-76521	7	25
114399-76531	7	27
114399-76540	7	28
114399-76550	7	29
114399-76560	7	30
114399-76570	7	31
114399-76580	7	32
114399-76590	7	35
114399-76620	7	33
114399-76630	7	34
114399-77410	10	29
114399-77560	10	28
114399-77720	10	30
114399-78000	10	31
114399-78280	10	21
114399-78770	10	22
114399-78780	10	23
114650-51300	8	5
114650-59060	9	24
114652-59310	9	26
114699-01760	1	35
114770-61520	6	32
114770-61610	6	34
114771-11461	11	23
114780-59010	9	19
114780-59060	9	20
114780-61090	6	58
118200-23200	5	42
121750-59890	9	27
124066-59100	9	25
124195-77770	10	16
124298-77020	10	15

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Contents

Fig. No.	Fig. Name	Fig. No.	Fig. Name

L70N5AJ8T2AAWK

1. CYLINDER BLOCK
2. CYLINDER HEAD & BONNET
3. AIR CLEANER & MUFFLER
4. PRE CLEANER
5. CRANKSHAFT, PISTON & CAMSHAFT
6. LUB.OIL PUMP & GOVERNOR
7. COOLING & STARTING DEVICE
8. F.I.PUMP & F.I.VALVE
9. FUEL TANK & FUEL PIPE
10. STARTING MOTOR & DYNAMO
11. TOOL,LABEL & GASKET SET

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.3. AIR CLEANER & MUFFLER




Fig. 2

(A)=L70N5AJ8T2AAWK (D)=
(B)= (E)=
(C)= (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	114220-12510	CLEANER ASSY, AIR	1							
2	2	114239-12520	COVER, AIR CLEANER	1							
3	2	114220-12910	CLEANER ASSY(SUB,AIR	1							
8	3	114210-12560	NUT, WING	1							
9	3	114210-12590	ELEMENT ASSY	1							
12	3	114210-12600	LOCKING KNOB	1							
13	1	26366-080002	NUT, M8	2							
14	1	114299-13800	EXTENSION ASSY	1							
15	1	114299-12300	NUT	3							
16	1	114210-12210	GASKET, AIR CLEANER	1							
17	1	26106-060202	BOLT, M6X 20 PLATED	1							
18	1	26226-060302	STUD, M6X 30	3							
19	1	114299-13200	GASKET, MUFFLER	1							
20	1	114368-13501	MUFFLER ASSY	1							
22	2	114268-13700	COVER, SILENCER	1							
23	2	26106-060082	BOLT, M6X 8 PLATED	6							
24	1	26106-060142	BOLT, M6X 14 PLATED	2							
25	1	26216-080182	STUD, M8X 18	2							


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.6. LUB.OIL PUMP & GOVERNOR



(A)=L70N5AJ8T2AAWK
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	114250-32010	PUMP ASSY, OIL	1							
7	1	114299-32070	COVER	1							
8	1	114299-32570	O-RING	1							
9	1	22312-030160	PIN, PARALLEL M3X16	1							
10	1	26106-060122	BOLT, M6X 12 PLATED	3							
11	1	114299-35110	FILTER ASSY, OIL	1							
13	2	24341-000224	O-RING, 1AS22.4	1							
14	1	26106-060162	BOLT, M6X 16 PLATED	1							
15	1	114211-61500	LEVER ASSY, GOVERNOR	1							1
24	2	22322-030200	PIN, TAPER 3X20	1							
26	1	714210-61701	GOVERNOR ASSY	1							
27	2	114210-61290	WEIGHT ASSY,GOVERNOR	1							
32	1	114770-61520	BEARING, NEEDLE	2							
33	1	114299-61600	SEAL, OIL	1							
34	1	114770-61610	WASHER, THRUST	1							
35	1	114299-61190	WASHER	1							
36	1	714210-66100	SPEED CTRL, THAI	1							
37	2	114210-66060	HANDLE ASY,REGULATOR	1							
40	3	26117-050089	BOLT, M5X 8 PLATED	1							
41	2	114210-66100	BRACKET, REGULATOR	1							
42	2	114299-66440	BOLT, ADJUSTING	1							
43	2	114299-67080	BOLT, ADJUSTING	1							
44	2	160725-78350	KNOB	1							
45	2	26347-060002	NUT, M6	1							
46	2	26757-060002	NUT, LOCK M6	2							
47	1	114299-66250	SPRING, RETURN	1							
48	1	26106-060142	BOLT, M6X 14 PLATED	1							
49	1	26106-060202	BOLT, M6X 20 PLATED	1							
50	1	114220-66010	SPRING, REGULATOR	1							
51	1	114299-66200	SPRING, RETURN	1							
52	1	114211-66600	LIMITER ASSY, FUEL	1							
57	1	26776-100002	NUT, LOCK M10	1							
58	1	114780-61090	TIN	2							
59	1	22451-060000	WIRE, 0.6	2							
60	1	114299-67080	BOLT, ADJUSTING	1							
61	1	160120-76940	WASHER	2							
62	1	26757-060002	NUT, LOCK M6	2							

Remarks
(1)On a guarantee of quality
component parts shall not be sold.

N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 5 of 17 pages

The full manual includes:

- All 17 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar L70N5AJ8T2AAWK, VIBRATING MACHINE Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual