Contents

Fig. No. Fig. Name

MAIN LOADER COMPONENT

1. CHASSIS
2. CHASSIS(HVAC COMPLETING)
3. CHASSIS(HVAC COMPLETING)
4. CHASSIS(HEATER-ONLY COMPLETING)
5. GRILLE AND ENGINE COVER
6. ROPS/FOPS STRUCTURE
7. ROPS/FOPS STRUCTURE(NON-HVAC ASSEMBLY)
8. ROPS/FOPS STRUCTURE(HVAC ASSEMBLY)
9. ROPS/FOPS STRUCTURE(HEATER-ONLY ASSEMBLY)
10. RESTRAINT BAR
11. SEATS - STANDARD, NON-SUSPENSION AND SUSPENSION(NON-SUSPENSION SEAT)
12. SEATS - STANDARD, NON-SUSPENSION AND SUSPENSION(STANDARD AND AIR SUSPENSION SEAT)
13. SEATS - STANDARD, NON-SUSPENSION AND SUSPENSION(SEATS SERVICE PARTS)
14. SEATS - SEAT BELT OPTION
15. SEATS - THREE-POINT RESTRAINT SEAT BELT OPTION
16. LIFT ARM
17. ATTACHMENT BRACKET(MANUAL QUICK COUPLER)
18. ATTACHMENT BRACKET(ACTUATOR GROUP)
19. ATTACHMENT BRACKET(HYDRAULIC QUICK COUPLER COMPONENTS)
20. WHEEL DRIVES
21. WHEEL DRIVES(AXLE ASSEMBLY)
22. ENGINE
23. AIR CLEANER AND EXHAUST
24. RADIATOR/COOLER


Fig. No. Fig. Name

25. HYDROSTATIC SYSTEM - WHEEL DRIVES(SINGLE-SPEED(DUAL JOYSTICK AND HAND/FOOT CONTROLS))
26. HYDROSTATIC SYSTEM - WHEEL DRIVES(TWO-SPEED(DUAL JOYSTICK AND HAND/FOOT CONTROLS))
27. HYDRAULICS - CHASSIS
28. HYDRAULICS - CHASSIS(RIDE CONTROL ASSEMBLY)
29. HYDRAULICS - CHASSIS(HYDRAULIC QUICK COUPLER HYDRAULICS)
30. HYDRAULICS - CHASSIS(STANDARD AUXILIARY HYDRAULICS(HAND/FOOT AND DUAL JOYSTICK CONTROLS))
31. HYDRAULICS - CHASSIS(HIGH-FLOW AUXILIARY HYDRAULICS(DUAL JOYSTICK AND HAND/FOOT CONTROLS))
32. HYDRAULICS - CHASSIS(HAND/FOOT AND DUAL JOYSTICK CONTROLS WITH SELF-LEVELING VALVE)
33. HYDRAULICS - CHASSIS(HAND/FOOT AND DUAL JOYSTICK CONTROLS WITHOUT SELF-LEVELING)
34. HYDRAULICS - LIFT ARM(STANDARD HYDRAULICS)
35. HYDRAULICS - LIFT ARM(HIGH-FLOW HYDRAULICS)
36. CONTROLS - LIFT/TILT AND TRACTION(HAND/FOOT CONTROLS)
37. CONTROLS - LIFT/TILT AND TRACTION(DUAL JOYSTICK CONTROLS)
38. CONTROLS - ENGINE(DUAL JOYSTICK CONTROLS)
39. CONTROLS - ENGINE(HIGH FLOW CONTROL)
40. ELECTRICAL - CHASSIS
41. ELECTRICAL - CHASSIS(RIDE CONTROL/TWO-SPEED ASSEMBLY)
42. ELECTRICAL - ROPS/FOPS
43. ELECTRICAL - ROPS/FOPS(STANDARD LIGHT HARNESS)
44. ELECTRICAL - ROPS/FOPS(STANDARD LIGHT HARNESS WITH SELF-LEVELING)
45. ELECTRICAL - LIGHTS
46. ELECTRICAL - ENGINE
47. TIRES
48. FOUR-POINT LIFT ASSEMBLY
49. SOUND SUPPRESSION(STANDARD)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. CHASSIS



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-05930	BOLT	14							
2	1	172551-00290	NUT	2							
3	1	172216-00210	GASKET, FUEL SENDER	1							
4	1	172551-00610	SCREW	8							
5	1	172551-00650	CLAMP	2							
6	1	172215-00480	TIE, CABLE	3							
7	1	172215-00510	SCREW	6							
8	1	172215-00620	PLUG	4							
9	1	172216-01240	STRAINER, FUEL FILL	1							
10	1	172215-00710	NUT	14							
11	1	172216-01770	WASHER	14							
12	1	172216-02040	WASHER	8							
13	1	172216-02110	NUT	4							
14	1	172217-00300	COVER ASSY	2							
15	1	172551-02190	PLUG	2							
16	1	172215-01560	CLAMP	2							
17	1	172215-01720	STOP, DOWN	2							
18	1	172216-05270	PLUG, HOLE	4							
19	1	172216-05820	LATCH, SWELL	4							
20	1	172216-06260	STRIP, FOAM	2							
21	1	172216-06810	SCREW	4							
22	1	172215-06620	NUT	8							
23	1	172215-07170	BREATHER	2							
24	1	172218-00860	FENDER, T-LINK R	1							
25	1	172218-00870	FENDER, T-LINK L	1							
26	1	172218-00890	PLUG, PASS THROUGH	2							
27	1	172218-01140	FILLER, ROPS RIGHT	1							
28	1	172218-01150	FILLER, ROPS LEFT	1							
29	1	172218-01340	BELLY PAN	2							
30	1	172218-02540	COVER, CLEAN-OUT	1							
31	1	172218-04500	SEAL, BULB 90	2							
32	1	172218-04880	SEAL, FILLER PLATE	2							
33	1	172215-07710	SCREW	2							
34	1	172215-08690	SHIM	6							
35	1	172218-06650	CASE, SIDE COVER L	1							
36	1	172216-12630	COVER, SIDE R	1							
37	1	172216-12650	COVER, LOWER LEFT	1							
38	1	172216-12660	COVER, LOWER RIGHT	1							
39	1	172218-06660	WELDMENT, CHASSIS	1							
40	1	172216-12740	STEP	1							
41	1	172218-06670	TANK, FUEL	1							
42	1	172218-06680	HOSE	1							
43	1	172218-06690	PICK UP ASSY, FUEL	1							
44	1	172218-06700	GROMMET, TANK	1							
45	1	172218-06710	FITTING	1							
46	1	172218-06720	FITTING	1							
47	1	172218-06730	SENDER, FUEL	1							
48	1	172218-06740	TUBE, FUEL VENT	1							
49	1	172218-06750	BRACE,REAR FUEL TANK	2							
50	1	172215-02820	BOLT	2							
51	1	172216-09500	SCREW	28							

Remarks
(1) Back side.

N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.6. ROPS/FOPS STRUCTURE



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00130	WASHER	4							
2	1	172216-00150	NUT	2							
3	1	172551-00250	NUT	1							
4	1	172216-00220	ISOLATOR, ROPS	2							
5	1	172551-01110	TAG, RIP-CORD	1							
6	1	172215-00650	RING	1							
8	1	172218-00250	NUT	4							
9	1	172216-13130	SPACER	2							
11	1	172551-02430	PLUG	1							
12	1	172218-00680	WINDOW	1							
13	1	172551-02870	WEATHER STRIP	1							
14	1	172218-00820	SEAL, BULB	1							
15	1	172218-01080	PAD, ACOUSTIC R DECK	1							
16	1	172218-01260	SEAL, FOAM BOTTOM	1							1
17	1	172218-01280	MOUNT, ISOLATOR	2							
18	1	172218-01310	SEAL, ROPS	1							
19	1	172551-02940	RIPCORD	1							
20	1	172218-01480	TRIM, EDGE	1							
21	1	172218-01600	COVER, B-PILLAR ,R	1							
22	1	172218-01740	COVER, B-PILLAR LEFT	1							
23	1	172218-02020	CONSOLE, SIDE RIGHT	1							
24	1	172218-02030	PANEL, ACCESS	2							
25	1	172218-02040	CONSOLE, FRONT RIGHT	1							
26	1	172218-02050	CONSOLE, FRONT LEFT	1							
27	1	172551-03140	WINDOW	1							
28	1	172218-03960	LOUVER, SNAP-IN	2							
29	1	172216-13150	CANOPY, ROPS&FOPS	1							
30	1	172216-13160	SCREW	4							
31	1	172216-13170	PIN	2							
32	1	172218-05750	CONSOLE LEFT SIDE	1							
33	1	172216-13180	LOCK, ROPS	1							
34	1	172216-13190	RETAINING	1							
35	1	172216-13200	MOUNT, GAS SPRING	2							
36	1	172216-13210	SCREW	2							
37	1	172216-13220	FLIPPER, ROPS LOCK	1							
38	1	172216-13230	SCREW	2							
39	1	172551-09450	SCREW	1							
40	1	172551-09830	BOLT	4							
41	1	172218-05040	SCREW	2							
42	1	172215-03110	SCREW	8							
43	1	172551-10010	SCREW	18							
44	1	172218-05090	WASHER	4							
45	1	172218-05180	SCREW	4							
46	1	172215-03240	NUT	2							
47	1	172551-10380	WASHER	4							1
48	1	172551-10410	PIN, COTTER	2							
49	1	172216-13240	WASHER	2							
50	1	172216-17380	SCREW	2							

Remarks
(1) Not shown in illustration.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.16. LIFT ARM



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00180	NUT	8							
2	1	172216-00410	PAD, ARM BRACE	2							
3	1	172218-00730	PIN, PIVOT	2							
4	1	172218-00750	PIN, PIVOT	2							
5	1	172218-01030	PIN, PIVOT	2							
6	1	172218-01090	LINK, TIMING	2							
7	1	172218-02210	KNOB, CLAMPING	1							
8	1	172218-02940	LOCK, LIFT ARM	1							
9	1	172218-05740	PIN	2							
10	1	172218-06880	ARM, LIFT	1							
11	1	172218-06890	LINK, REAR	2							
12	1	172551-09410	FITTING	2							
13	1	172215-02650	ZERK	2							
14	1	172551-09780	SCREW	4							
15	1	172216-09400	SCREW	4							
16	1	172216-00440	BUSHING	2							
17	1	172218-00280	BUSHING	4							
18	1	172218-00320	BUSHING	8							


N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.20. WHEEL DRIVES



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172216-00360	NUT	32							
2	1	172217-00130	CHAIN	2							
3	1	172217-00030	LINK, CONNECTING	1							1
4	1	172218-00060	CHAIN	2							
5	1	172217-00030	LINK, CONNECTING	1							1
6	1	172217-00280	SPROCKET ASSY	4							
7	1	172217-02421	AXLE ASSY	4							
8	1	172216-02530	BOLT	32							1
9	1	172218-06920	O-RING	32							
10	1	172216-13790	NUT	32							
11	1	172218-06930	BOLT	32							
12	1	172216-09640	WASHER	32							

Remarks
(1) Not shown in illustration.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.22. ENGINE



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00140	CLAMP	11							
2	1	172215-00120	FITTING	1							
3	1	172215-00190	FITTING	1							
4	1	172551-00230	NUT	2							
5	1	172216-00180	NUT	1							
6	1	172551-00250	NUT	2							
7	1	172551-00320	CONNECTOR	1							
8	1	172551-00440	SCREW	2							
9	1	172551-01060	NUT	1							
10	1	172216-01470	WASHER	16							
11	1	172551-01240	WASHER	8							
12	1	172551-01270	CLAMP	6							
13	1	172551-01310	ISOLATOR	2							
14	1	172216-17470	WASHER	2							
15	1	172216-04700	ISOLATOR	2							
16	1	172217-01370	MOUNT, ENGINE	1							
17	1	172217-01390	MOUNT, ENGINE	1							
18	1	172551-02510	BRACKET, ALTERNATOR	1							
19	1	172551-02540	MOUNT, FILTER	1							
20	1	172551-02550	ADAPTOR, FILTER	1							
21	1	172216-11900	O-RING 230 N70	1							1
22	1	172551-02600	DIPSTICK ASSY	1							
23	1	172215-06620	NUT	9							
24	1	172551-02780	CONNECTOR	3							
25	1	172216-07390	HOSE ASSY	1							
26	1	172551-02920	ALTERNATOR	1							
27	1	172551-02950	SPACER	1							
28	1	172551-02960	SPACER	1							
29	1	172216-07880	BOLT	2							
30	1	172218-01490	BOLT	2							
31	1	172551-02980	SPACER	1							
32	1	172216-14020	PLUG	1							
33	1	172217-03590	MOUNT, ENGINE	1							
34	1	172216-08330	COUPLER, FLEX	1							
35	1	172216-08490	HOSE, FUEL	1							
36	1	172216-08590	HOUSING, FLYWHEEL	1							
37	1	172216-14030	FITTING	1							
38	1	172216-13850	COOLER, FUEL	1							
39	1	172216-13860	BRKT, WATERSEPARATOR	1							
40	1	172216-13870	BRKT ASSY, FO COOLER	1							
41	1	172216-13900	HOSE	1							
42	1	172216-13910	HOSE	2							
43	1	172216-14050	BRKT, OIL DIPSTICK	1							
44	1	172216-13970	SLEEVE, NYLON	1							
45	1	172216-13980	SLEEVE, NYLON	2							
46	1	172216-14060	TUBE, EOC RETURN	1							
47	1	172216-14070	HOSE	1							
48	1	172216-14080	FITTING	1							
49	1	172216-14090	HOSE	1							
50	1	172216-14100	VALVE, INLINE CHECK	1							
51	1	172216-14110	HOSE	1							

Remarks
(1) Not shown in illustration.

N:Old ⇔ New (Yes/No), Q:Old ⇔ New (No/Yes), R:Old ⇔ New (Yes/Yes), S:Old ⇔ New (No/No), W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.57. LIFT CYLINDER



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-07220	CYLINDER/LIFT	1							
2	2	172218-07210	TUBE, LIFT CYLINDER	1							
3	2	172218-03680	PISTON	1							
4	2	172218-03690	HEAD GLAND	1							
5	2	172218-07200	ROD, CYLINDER	1							
6	2	172218-00320	BUSHING	4							
7	2	172218-06490	NUT	1							
8	2	172218-06230	ZERK	2							
9	2	172218-03701	SEAL KIT	1							
10	3	172216-16420	INSERT	2							

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Parts No. Index

Parts No.	Fig. No.	Ref. No.
172215-00030	30	1
	31	1
172215-00040	46	1
172215-00080	31	5
172215-00120	22	2
172215-00190	22	3
	32	2
172215-00200	24	4
	27	6
172215-00250	25	3
	26	4
	27	8
172215-00300	42	11
172215-00320	2	3
	3	3
	27	9
	84	41
	85	41
	86	41
172215-00340	34	4
172215-00390	32	6
	33	4
172215-00400	14	1
	15	1
172215-00480	1	6
	40	8
172215-00510	1	7
172215-00540	25	8
	26	9
	91	4
172215-00550	5	10
	81	2
	89	7
172215-00620	1	8
172215-00650	6	6
	50	5
172215-00700	5	13
	10	6
	40	12
	46	4
172215-00710	1	10
	5	14
	48	2
	101	3
172215-00740	2	12
	3	12
	4	6
	84	7
	85	7
	86	7

Parts No.	Fig. No.	Ref. No.
172215-00800	52	1
172215-00850	30	12
	36	12
172215-01410	5	19
172215-01560	1	16
172215-01720	1	17
172215-01960	47	3
		6
		9
		12
		15
		18
		21
172215-02110	10	9
172215-02140	42	10
172215-02650	16	13
172215-02700	5	34
	10	26
	25	41
	26	45
172215-02710	25	42
	26	46
172215-02760	10	28
172215-02790	10	31
	42	30
172215-02820	1	50
	27	32
	29	15
	30	35
	31	40
	36	59
	37	49
	40	41
	98	20
172215-02850	11	5
	14	5
	15	6
172215-02870	17	18
172215-02890	19	28
	96	35
	97	35
172215-02930	24	20
172215-02950	100	11
172215-03000	5	39
172215-03110	2	94
	3	94
	4	50
	6	42
	42	34
	75	23

Parts No.	Fig. No.	Ref. No.
172215-03110	75	41
	84	51
	85	51
	86	51
	88	17
172215-03120	90	22
172215-03150	1	54
	19	32
	24	21
	36	58
		60
	37	48
		50
		56
	40	44
	94	12
	96	39
	97	39
172215-03160	94	13
172215-03200	31	44
	32	29
	33	20
172215-03220	83	18
172215-03230	81	55
172215-03240	6	46
	19	34
	96	41
	97	41
172215-03260	100	13
172215-03310	30	39
	31	45
172215-03340	11	6
	14	6
	15	7
	89	34
172215-03360	2	98
	3	98
172215-03380	2	99
	3	99
	23	16
172215-03790	5	1
172215-04030	5	2
172215-04530	36	6
172215-05310	27	18
172215-06610	5	24
	29	4
	36	27
	37	24
	40	18
	90	10

Parts No.	Fig. No.	Ref. No.
172215-06610	98	7
172215-06620	1	22
		57
	2	33
	3	33
	4	15
	12	1
	22	23
	27	19
	29	5
	30	18
	31	19
	36	28
	38	10
	40	19
	82	4
	84	16
	85	16
	86	16
	93	3
	94	5
	98	8
172215-06940	5	25
172215-07170	1	23
172215-07650	90	14
172215-07710	1	33
172215-08550	21	8
172215-08690	1	34
172215-08920	34	18
172215-09280	5	28
172215-11520	52	8
172215-11550	50	10
172216-00020	38	1
172216-00060	43	2
172216-00070	38	2
172216-00080	27	3
	42	2
172216-00130	24	2
172216-00140	42	3
172216-00150	6	2
172216-00160	10	2
	36	2
	37	3
172216-00180	22	5
172216-00210	1	3
172216-00220	6	4
172216-00240	50	1
172216-00280	38	3
172216-00290	30	8
	31	11

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Contents

Fig. No. Fig. Name

50. LABEL(1)
51. LABEL(2)
52. LABEL(3)
53. LABEL(4)
54. LABEL(5)
55. LABEL(6)
56. LABEL(7)

HYDRAULIC COMPONENTS

57. LIFT CYLINDER
58. TILT CYLINDER
59. DRIVE MOTORS(SINGLE-SPEED)
60. DRIVE MOTORS(TWO-SPEED)
61. TANDEM PUMP(HAND/FOOT AND DUAL JOYSTICK PUMP)
62. TANDEM PUMP(HAND/FOOT AND DUAL JOYSTICK TANDEM PUMP / ENGINE END)
63. TANDEM PUMP(HAND/FOOT AND DUAL JOYSTICK TANDEM PUMP / GEAR PUMP END)
64. GEAR PUMP - SINGLE(STANDARD AUXILIARY)
65. GEAR PUMP - DOUBLE(HIGH-FLOW AUXILIARY)
66. SELF-LEVELING VALVE
67. LIFT AND TILT SOLENOID VALVE(VALVE)
68. LIFT AND TILT SOLENOID VALVE(VALVE)
69. SOLENOID VALVES - BRAKE, JOYSTICK SUPPLY AND BRAKE RELEASE(SINGLE-SPEED)
70. SOLENOID VALVES - BRAKE, JOYSTICK SUPPLY AND BRAKE RELEASE(TWO-SPEED)
71. SOLENOID VALVES - BRAKE, JOYSTICK SUPPLY AND BRAKE RELEASE(JOYSTICK SUPPLY)
72. MAIN CONTROL VALVE(STANDARD CONTROL VALVE - HAND/FOOT AND DUAL JOYSTICK CONTROLS)

Fig. No. Fig. Name

73. MAIN CONTROL VALVE(HIGH-FLOW CONTROL VALVE - HAND/FOOT AND DUAL JOYSTICK CONTROLS)
74. RIDE CONTROL MANIFOLD
75. HEATER HOUSING AND HVAC HOUSING ASSEMBLY
76. CONDENSOR ASSEMBLY
77. FOOT VALVE

KITS AND ACCESSORIES


78. BACKUP ALARM KIT
79. SIDE WINDOW KIT
80. REARVIEW MIRROR KIT
81. CAB DOOR KIT
82. CAB DOOR KIT(DOOR COMPLETING PACKAGE)
83. AM/FM RADIO KIT
84. HEATER KIT
85. HEATER KIT
86. HEATER KIT
87. HEATER KIT(COMPLETING PARTS)
88. HEATER KIT(HOUSING SERVICE PARTS)
89. IMPACT-RESISTANT DOOR KIT
90. ELECTRICAL - 14-PIN AUXILIARY CONNECTOR
91. BRAKE RELEASE
92. WARNING LAMP KIT
93. REAR WIPER KIT
94. FLASHER KIT
95. AUXILIARY COUPLER SERVICE KITS

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.25. HYDROSTATIC SYSTEM - WHEEL DRIVES(SINGLE-SPEED(DUAL JOYSTICK AND HAND/FOOT CONTROLS))

(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=



No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00040	FITTING	4							
2	1	172551-00060	FITTING	1							
3	1	172215-00250	FITTING	1							
4	1	172551-00490	CONNECTOR, TEE-RUN	1							
5	1	172216-00380	CAP	3							
6	1	172216-00400	FITTING	1							
7	1	172551-00700	CONNECTOR	2							
8	1	172215-00540	FITTING	1							
9	1	172216-00560	FITTING	1							
10	1	172551-01060	NUT	2							
11	1	172216-02040	WASHER	12							
12	1	172218-00170	HOSE	1							
13	1	172551-02090	MANIFOLD, RIDE CNTRL	1							1
14	1	172551-02130	ACCUMULATOR	1							
15	1	172216-03850	PLATE, SPACER	1							
16	1	172217-01340	TUBE, RIDE CONTROL	1							
17	1	172217-01350	TUBE, RIDE CONTROL	1							
18	1	172217-01850	TUBE ASSY, MOTOR L	1							
19	1	172217-01890	HOSE	1							
20	1	172217-02080	HOSE	1							
21	1	172217-02410	FITTING	1							
22	1	172217-02500	MOTOR, SINGLESPEED R	1							2
23	1	172217-02510	MOTOR, SINGLESPEED L	1							2
24	1	172216-10890	FITTING	1							
25	1	172216-10890	FITTING	2							
26	1	172218-00690	VALVE, BRAKE	1							
27	1	172218-02270	TUBE, CHARGE	1							
28	1	172216-14360	FITTING	7							
29	1	172552-16730	CONNECTOR	1							
30	1	172216-14370	FITTING	1							
31	1	172216-14390	PUMP, TANDEM	1							3
32	1	172216-14510	TUBE, BRAKE LEFT	1							
33	1	172216-14520	TUBE, BRAKE RIGHT	1							
34	1	172216-14530	TUBE, BRAKE LEFT	1							
35	1	172216-14540	HOSE	1							
36	1	172218-07010	HOSE	1							
37	1	172218-07020	HOSE	1							
38	1	172218-07030	TUBE, DRAIN	1							
39	1	172216-17480	TUBE, DRAIN	1							
40	1	172218-07040	HOSE	1							
41	1	172215-02700	SCREW	2							
42	1	172215-02710	SCREW	2							
43	1	172216-09650	SCREW	12							
44	1	172551-10160	BOLT	2							
45	1	172216-11190	WASHER	2							
46	1	172551-00340	FITTING	1							
47	1	172216-05470	PORT, TEST	1							

Remarks
(1) For breakdown see Fig.No.74.
(2) For breakdown see Fig.No.59.
(3) For breakdown see Fig.No.61.


N:Old ◂Yes/No▸ New, Q:Old ◂No/Yes▸ New, R:Old ◂Yes/Yes▸ New, S:Old ◂No/No▸ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.


PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.54. LABEL(5)


(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=




1



2




3, 4, 5




6, 7, 8

3, 4, 5



6, 7, 8



No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-02400	LABEL, WARNING	1							
2	1	172551-02070	LABEL., LOCK	1							
3	1	172218-07580	LABEL, DUAL HAND R	1							1
4	1	172216-17370	DECAL, HAND&FOOT R	1							2
5	1	172216-17360	DECAL,JOYSTICK RIGHT	1							3
6	1	172218-07570	LABEL, DUAL HAND L	1							1
7	1	172217-02470	LABEL, HAND&FOOT L	1							2
8	1	172216-03730	LABEL, JOYSTICK LEFT	1							3


Remarks
(1) DH
(2) H/F
(3) DJS

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.83. AM/FM RADIO KIT



(A)=S270V-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-05321	RADIO KIT	1							
2	2	172551-00250	NUT	4							
3	2	172551-00620	NUT	3							
4	2	172218-06640	RADIO MNT ASSY	1							
5	2	172218-02090	HOUSING, SPEAKER RH	1							
6	2	172218-02100	HOUSING, SPEAKER LH	1							
7	2	172218-03600	MOUNT, SPEAKER	2							
8	2	172216-16870	PACKAGE, RADIO	1							
9	3	172218-01780	TEMPLATE, RADIO MNT	1							1
10	3	172218-01880	HARNESS, WIRE RADIO	1							
11	3	172551-02140	SPEAKER, RADIO	2							
12	3	172551-02150	ANTENNA, RADIO	1							
13	3	172551-02440	RADIO	1							
14	3	172551-04210	SPEAKER GRILLE	2							
15	2	172216-16880	SEAL, FOAM	1							
16	2	172551-09660	WASHER	3							
17	2	172551-10170	SCREW	8							
18	2	172215-03220	NUT	8							
19	2	172551-10360	WASHER	4							

Remarks
(1) Not shown in illustration.

N:Old Yes/No New, Q:Old No/Yes New, R:Old Yes/Yes New, S:Old No/No New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change
Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 129 pages

The full manual includes:

- All 129 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar S270V-1 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual