YANMAR

PARTS CATALOG

0CS10-M56800EN

Last update Sep., 2014

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Contents

Fig. No. Fig. Name

MAIN LOADER COMPONEN

1. CHASSIS
2. CHASSIS(HVAC COMPLETING)
3. CHASSIS(HEATER-ONLY COMPLETING)
4. GRILLE AND ENGINE COVER
5. ROPS/FOPS STRUCTURE
6. ROPS/FOPS STRUCTURE(NON-HVAC ASSEMBLY)
7. ROPS/FOPS STRUCTURE(HVAC ASSEMBLY)
8. ROPS/FOPS STRUCTURE(CAB DOOR ASSEMBLY)
9. ROPS/FOPS STRUCTURE(CAB DOOR ASSEMBLY, DOOR COMPLETING PACKAGE)
10. RESTRAINT BAR
11. SEATS - STANDARD AND SUSPENSION(STANDARD AND AIR SUSPENSION SEAT)
12. SEATS - SEAT BELT OPTION
13. SEATS - THREE-POINT RESTRAINT SEAT BELT OPTION
14. LIFT ARM
15. ATTACHMENT BRACKET(MANUAL QUICK COUPLER)
16. ATTACHMENT BRACKET(ACTUATOR GROUP)
17. ATTACHMENT BRACKET(HYDRAULIC QUICK COUPLER, CHASSIS COMPONENTS)
18. ATTACHMENT BRACKET(HYDRAULIC QUICK COUPLER, LIFT ARM COMPONENTS)
19. WHEEL DRIVES
20. WHEEL DRIVES(AXLE ASSEMBLY)
21. ENGINE
22. AIR CLEANER AND EXHAUST
23. RADIATOR/COOLER
24. HYDROSTATIC SYSTEM - WHEEL DRIVES(SINGLE-SPEED)


Fig. No. Fig. Name

25. HYDROSTATIC SYSTEM - WHEEL DRIVES(TWO-SPEED)
26. HYDRAULICS - CHASSIS
27. HYDRAULICS - CHASSIS(STANDARD AUXILIARY HYDRAULICS)
28. HYDRAULICS - CHASSIS(HIGH-FLOW AUXILIARY HYDRAULICS)
29. HYDRAULICS - LIFT ARM(STANDARD HYDRAULICS)
30. HYDRAULICS - LIFT ARM(HIGH-FLOW HYDRAULICS)
31. CONTROLS - LIFT/TILT AND TRACTION(DUAL JOYSTICK CONTROLS)
32. CONTROLS - LIFT/TILT AND TRACTION(HAND/FOOT CONTROLS)
33. CONTROLS - ENGINE(DUAL JOYSTICK CONTROLS)
34. ELECTRICAL - CHASSIS
35. ELECTRICAL - CHASSIS (REAR LIGHT POWER DISTRIBUTION)
36. ELECTRICAL - ROPS/FOPS(ROPS/FOPS LIGHTING HARNESS, STANDARD)
37. ELECTRICAL - ROPS/FOPS
38. ELECTRICAL - LIGHTS
39. ELECTRICAL - ENGINE
40. ELECTRICAL - ENGINE(HIGH-FLOW)
41. TIRES
42. FOUR-POINT LIFT ASSEMBLY
43. DECALS(1)
44. DECALS(2)
45. DECALS(3)
46. DECALS(4)
47. DECALS(5)
48. DECALS(6)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. CHASSIS



(A)=S270V
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-05930	BOLT	14							
2	1	172215-00110	CLAMP	2							
3	1	172551-00140	CLAMP	2							
4	1	172551-00290	NUT	2							
5	1	172216-00210	GASKET, FUEL SENDER	1							
6	1	172551-00610	SCREW	8							
7	1	172215-00480	TIE, CABLE	2							
8	1	172218-05950	SENDER, FUEL	1							
9	1	172215-00620	PLUG	4							
10	1	172216-01240	STRAINER, FUEL FILL	1							
11	1	172215-00710	NUT	14							
12	1	172216-01770	WASHER	12							
13	1	172216-02040	WASHER	8							
14	1	172216-02110	NUT	4							
15	1	172217-00300	COVER ASSY	2							
16	1	172218-00310	STEP	1							
17	1	172551-02190	PLUG	2							
18	1	172217-00570	FITTING	1							
19	1	172215-01720	STOP, DOWN	2							
20	1	172218-00470	VALVE, FUEL SHUT OFF	1							
21	1	172216-04870	SPACER	3							
22	1	172216-05820	LATCH, SWELL	4							
23	1	172216-06260	STRIP, FOAM	2							
24	1	172216-06810	SCREW	4							
25	1	172215-06620	NUT	6							
26	1	172218-00800	TANK, FUEL	1							
27	1	172218-00860	FENDER, T-LINK R	1							
28	1	172218-00870	FENDER, T-LINK L	1							
29	1	172218-00890	PLUG, PASS THROUGH	2							
30	1	172218-00950	COVER, CROSSMEMBER	1							
31	1	172218-01050	BASE, JOYSTICK	2							
32	1	172218-01100	COVER, CROSSMEMBER	1							
33	1	172218-01140	FILLER, ROPS RIGHT	1							
34	1	172218-01150	FILLER, ROPS LEFT	1							
35	1	172218-01340	BELLY PAN	2							
36	1	172218-01430	COVER, RIGHT	1							
37	1	172218-01720	COVER, PANEL RIGHT	1							
38	1	172218-01750	COVER, PANEL LEFT	1							
39	1	172218-02240	SEAL	2							
40	1	172218-02540	COVER, CLEAN-OUT	1							
41	1	172218-02600	PLATE, RETAINER	2							
42	1	172218-02840	HOSE, FILL	1							
43	1	172218-04500	SEAL, BULB 90	2							
44	1	172218-04600	CHASSIS	1							
45	1	172218-04610	COVER, FUEL	1							
46	1	172216-01250	CAP, FUEL TANK	1							1
47	1	172218-04880	SEAL, FILLER PLATE	2							
48	1	172215-07710	SCREW	2							
49	1	172215-08690	SHIM	6							
50	1	172215-09600	HOSE, FUEL	1							
51	1	172218-05670	FITTING	1							

Remarks
(1) Not shown in illustration.

N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.21. ENGINE



(A)=S270V (D)=
(B)= (E)=
(C)= (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-05920	BOLT	1							
2	1	172551-00040	FITTING	2							
3	1	172216-00080	CLAMP	1							
4	1	172551-00150	NUT	1							
5	1	172551-00180	NUT	3							
6	1	172551-00240	NUT	1							
7	1	172216-00180	NUT	1							
8	1	172551-00250	NUT	2							
9	1	172551-00320	CONNECTOR	2							
10	1	172215-00530	SPACER	1							
11	1	172551-00990	CLAMP	3							
12	1	172551-01060	NUT	1							
13	1	172216-01470	WASHER	16							
14	1	172551-01240	WASHER	8							
15	1	172551-01270	CLAMP	1							
16	1	172551-01310	ISOLATOR	2							
17	1	119225-52102	PUMP ASSY, FUEL FEED	1							
18	1	172216-04700	ISOLATOR	2							
19	1	172551-02460	COUPLER	1							
20	1	129907-55801	FILTER, FUEL	1							
21	1	172217-01370	MOUNT, ENGINE	1							
22	1	172217-01390	MOUNT, ENGINE	1							
23	1	172551-02510	BRACKET, ALTERNATOR	1							
24	1	172217-00840	HOSE, FUEL	1							
25	1	172551-02540	MOUNT, FILTER	1							
26	1	172551-02550	ADAPTOR, FILTER	1							
27	1	172216-11900	O-RING 230 N70	1							1
28	1	172551-02560	CLAMP	1							
29	1	129940-77011	STARTER	1							
30	1	129242-55711	SEPARATOR ASSY	1							
31	1	129242-55730	ELEMENT	1							1
32	1	172217-04910	HOSE 1/2 X 30	1							
33	1	172551-02600	DIPSTICK ASSY	1							
34	1	172551-02610	BRACKET, DIPSTICK	1							
35	1	129150-35153	FILTER	1							
36	1	172215-06620	NUT	3							
37	1	172216-07390	HOSE ASSY	1							
38	1	172218-01160	HOSE, FUEL	2							
39	1	172218-01170	HOSE, FUEL	1							
40	1	172551-02920	ALTERNATOR	1							
41	1	129940-42240	V-BELT, B44	1							
42	1	172551-02950	SPACER	1							
43	1	172551-02960	SPACER	1							
44	1	172218-01490	BOLT	4							
45	1	172551-02980	SPACER	1							
46	1	172217-03590	MOUNT, ENGINE	1							
47	1	172216-08590	HOUSING, FLYWHEEL	1							
49	1	172217-04270	CLAMP	8							
50	1	172216-09250	WASHER	2							
51	1	172551-09510	SCREW	1							
52	1	172551-09810	BOLT	3							

Remarks
(1) Not shown in illustration.

N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.53. TANDEM PUMP(PUMP)



(A)=S270V
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172216-08800	PUMP, TANDEM	1							
2	2	172216-07230	ROTARY GROUP, R ROT.	1							
3	2	172216-07240	ROTARY GROUP, L ROT.	1							
4	2	172216-07250	CONTROL, HYDRAULIC	2							
5	2	172216-05130	CARTRIDGE	1							
6	2	172216-07280	VALVE, RELIEF	4							
7	2	172216-05140	VALVE, RELIEF	1							
8	2	172216-05150	PUMP, GEAR/INTERNAL	1							
9	2	172216-05160	COUPLING, DRIVE	1							
12	2	172216-05170	BEARING, ROLLER	2							
13	2	172216-05200	RING, SHAFT SEAL	1							
14	2	172216-05220	SEAL KIT	1							1

Remarks
(1) KIT includes Ref.No.13 and parts with *.
Not shown in illustration.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.8. ROPS/FOPS STRUCTURE(CAB DOOR ASSEMBLY)



(A)=S270V (D)=
(B)= (E)=
(C)= (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172215-00550	STUD, BALL	2							
2	1	172218-06440	BACKER, HINGE	1							
3	1	172218-06430	HINGE, DOOR	1							
4	1	172218-03000	LATCH, DOOR	1							
5	1	172218-03010	COVER, LATCH	1							
6	1	172218-03020	STRIKER	1							
7	1	172218-03040	COVER, WIPER MOTOR	1							
8	1	172218-03050	PLATE, PANTOGRAPH	1							
9	1	172218-03060	ARM, WIPER	1							
10	1	172218-03070	BLADE, WIPER ASSY	1							
11	1	172218-03080	SPRING, GAS	1							
12	1	172218-03090	CLIP, WIPER HOSE	1							
13	1	172218-03100	GROMMET, WASHER HOSE	1							
14	1	172218-03110	ELBOW, WASHER HOSE	1							
15	1	172218-03120	HOSE, WASHER	1							
16	1	172551-03100	HEAD, SPRITZER	1							
17	1	172218-03130	SEAL, RAIN, WIPER	1							
18	1	172218-03150	GROMMET, DRIVE SHAFT	1							
19	1	172218-03160	WASHER	1							
20	1	172218-03170	BUSHING	5							
21	1	172218-03180	WASHER	5							
22	1	172218-03190	WASHER	5							
23	1	172218-03200	ELBOW, WASHER HOSE	1							
24	1	172218-03210	SEAL, BULB	1							
25	1	172218-03250	SCREW	5							
26	1	172218-03270	WASHER	10							
27	1	172218-03280	LOCK NUT	5							
28	1	172218-03310	SCREW	6							
29	1	172218-03320	WASHER	5							
30	1	172218-03330	SCREW	2							
31	1	172218-03340	SCREW	1							
32	1	172218-03350	NUT	1							
33	1	172218-03360	NUT	1							
34	1	172218-03370	NUT	1							
35	1	172218-03380	WASHER	1							
36	1	172218-03390	NUT	1							
37	1	172218-03400	WASHER	1							
38	1	172218-03490	GASKET SET	1							
39	1	172218-03500	BUSHING, BRONZE	2							
40	1	172218-03510	BUSHING	4							
41	1	172218-03520	BUSHING	2							
42	1	172218-04140	BARCKET, MOUNTING	1							
43	1	172218-04150	SCREW	1							
44	1	172218-04160	SCREW	2							
45	1	172218-04380	PLATE, MOUNT	1							
46	1	172218-06420	HINGE, CABSIDE	2							
47	1	172218-04400	SCREW	2							
48	1	172218-04410	GASKET, MOUNT	1							
49	1	172218-04420	PLUG	2							
50	1	172218-04430	GLASS KIT, FR DOOR	1							
51	1	172218-04440	PULL HAND KIT, DOOR	1							

N:Old <-Yes/No-> New, Q:Old <-No/Yes-> New, R:Old <-Yes/Yes-> New, S:Old <-No/No-> New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.19. WHEEL DRIVES



(A)=S270V
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172216-00360	NUT	32							
2	1	172217-00130	CHAIN	2							
3	1	172217-00030	LINK, CONNECTING	1							1
4	1	172218-00060	CHAIN	2							
5	1	172217-00030	LINK, CONNECTING	1							1
6	1	172216-01120	NUT	32							
7	1	172216-02300	BOLT	32							
8	1	172217-00280	SPROCKET ASSY	4							
9	1	172217-02420	AXLE ASSY	4							
10	1	172216-02530	BOLT	32							1
11	1	172216-09640	WASHER	32							

Remarks
(1) Not shown in illustration.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.14. LIFT ARM



(A)=S270V
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00180	NUT	8							
2	1	172216-00410	PAD, ARM BRACE	2							
3	1	172218-05740	PIN	2							
4	1	172218-00720	LINK, REAR	2							
5	1	172218-00730	PIN, PIVOT	2							
6	1	172218-00750	PIN, PIVOT	2							
7	1	172218-01030	PIN, PIVOT	2							
8	1	172218-01090	LINK, TIMING	2							
9	1	172218-01440	ARM, LIFT	1							
10	1	172218-00280	BUSHING	4							1
11	1	172218-00320	BUSHING	8							1
12	1	172216-00440	BUSHING	2							1
13	1	172218-02210	KNOB, CLAMPING	1							
14	1	172218-02940	LOCK, LIFT ARM	1							
15	1	172551-09410	FITTING	2							
16	1	172215-02650	ZERK	2							
17	1	172551-09770	SCREW	4							
18	1	172216-09400	SCREW	4							

Remarks
(1) Not shown in illustration.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.34. ELECTRICAL - CHASSIS



(A)=S270V (D)=
(B)= (E)=
(C)= (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00120	TIE, CABLE	10							
2	1	172551-00150	NUT	4							
3	1	172551-00230	NUT	2							
4	1	172551-00250	NUT	12							
5	1	172218-00010	ROD, BATTERY	1							
6	1	172215-00480	TIE, CABLE	2							
7	1	172551-00720	NUT	2							
8	1	172551-00750	CLAMP	2							
10	1	172551-01060	NUT	7							
11	1	172551-01590	FLANGE	4							
12	1	172551-01980	HORN	1							
13	1	172218-00350	SPACER	1							
14	1	172551-02160	HOSE, CLAMP	1							
15	1	172218-00480	ANGLE, BATTERY	1							
16	1	172217-01820	CABLE, FEED +	1							
17	1	172216-06000	SOLENOID	2							
18	1	172216-07150	COVER, ELECTRICAL	2							
19	1	172216-07430	COVER, WIRE HARNESS	1							
20	1	172216-07710	MODULE, 2-SPEED	1							
21	1	172217-03100	FOAM, COVER, FUSE	1							
22	1	172217-03110	FOAM, COVER, ELEC	1							
23	1	172218-01420	HARNESS, CHASSIS	1							
24	1	172218-01840	BRACKET, MOUNTING	1							
25	1	172218-01950	BRACKET, MODULE	1							
26	1	172218-02140	PLATE, ELECTRIC ASSY	1							
27	1	172218-04130	SPACER	2							
28	1	172218-04510	TRAY, BATTERY	1							
29	1	172218-04940	SCREW	2							
30	1	172551-09720	BOLT	4							
31	1	172551-09750	BOLT	2							
32	1	172551-09810	BOLT	3							
33	1	172215-03150	SCREW	2							
34	1	172218-05140	SCREW	1							
35	1	172215-03230	NUT	4							
36	1	172551-10370	WASHER	4							

N:Old ⇄ New (Yes/No), Q:Old ⇄ New (No/Yes), R:Old ⇄ New (Yes/Yes), S:Old ⇄ New (No/No), W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.31. CONTROLS - LIFT/TILT AND TRACTION(DUAL JOYSTICK CONTROLS)

(A)=S270V
(B)=
(C)=
(D)=
(E)=
(F)=



No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00070	FITTING	7							
2	1	172551-00120	TIE, CABLE	1							
3	1	172216-00160	RING, RETAINING	4							
4	1	172217-02410	FITTING	2							
5	1	172551-00610	SCREW	6							
6	1	172216-00900	BUSHING, PIVOT	4							
7	1	172218-00160	HOSE	1							
8	1	172215-00850	FITTING	4							
9	1	172216-03290	JOYSTICK, DRIVE	1							
10	1	172216-03520	PLUG, 4-PIN	1							
11	1	172216-03530	WEDGE, 4-PIN	1							
12	1	172216-04490	HANDLE, RATCHET	2							
13	1	172218-00460	HOSE	2							1
14	1	172216-04590	ADAPTOR	10							
15	1	172216-04600	ADAPTOR	2							
16	1	172218-00450	HOSE	1							1
17	1	172218-00440	HOSE	2							1
18	1	172216-04830	JOYSTICK	1							
19	1	172216-06310	GRIP	1							
20	1	172217-02770	HOSE	2							1
21	1	172218-00600	PIN, TILT CONSOLE	2							
22	1	172218-00610	SEAL, BULB	2							
23	1	172218-00620	GROMMET, PILOT HOSES	2							
24	1	172216-07120	HARNESS, THROTTLE	1							
25	1	172215-06610	NUT	2							
26	1	172218-06360	VALVE, JOYSTICK	1							2
27	1	172218-00880	MAT, FLOOR	1							
28	1	172218-01060	TOWER, JOYSTICK	2							
29	1	172218-01350	COVR, FLOORPLATE R	2							
30	1	172218-01730	COVER, TOWER	2							
31	1	172218-02300	BOOT, CONTROL VALVE	1							
32	1	172218-02320	BOOT, CONTROL VALVE	1							
33	1	172218-02440	BRACKET,RETAINER	2							
34	1	172218-02460	BRACKET, FLOOR PLATE	1							
35	1	172218-02530	SEAL, FLOOR	1							
36	1	172218-02540	COVER, CLEAN-OUT	1							
37	1	172218-02550	PLATE, FLOOR	1							
38	1	172218-03760	HOSE	1							1
39	1	172218-03750	HOSE	1							3
40	1	172218-03740	HOSE	2							1
41	1	172218-03730	HOSE	1							3
42	1	172215-02820	BOLT	2							
43	1	172218-05050	SCREW	4							
44	1	172551-10010	SCREW	4							
45	1	172215-03040	SCREW	7							
46	1	172216-09710	SCREW	7							
47	1	172551-10370	WASHER	2							

Remarks
(1) Include Ref.No.14.
(2) For breakdown see Fig.No.53.
(3) Include Ref.No.15.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.43. DECALS(1)



(A)=S270V (D)=
(B)= (E)=
(C)= (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172216-00550	STRIP	3							
2	1	172216-00240	STRIP	1							
3	1	172551-01840	LABEL, FLAG	1							
4	1	172218-02400	LABEL, WARNING	1							
5	1	172551-01110	TAG, RIP-CORD	1							
6	1	172215-00650	RING	1							
7	1	172551-01520	LABEL, NO RIDERS	2							
8	1	172551-01560	LABEL, TIEDOWN POINT	4							
9	1	172215-11550	LABEL, 627 MM	2							
10	1	172218-06300	LABEL, S270V LEFT	1							
11	1	172216-11930	PLATE, SERIAL	1							
12	1	172218-06310	LABEL, S270V RIGHT	1							
13	1	172551-01510	LABEL, KEEP OUT	1							
14	1	172215-11550	LABEL, 627 MM	2							
15	1	172215-11520	PLATE, CAPACITY	1							


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\rightleftarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\rightleftarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW ONLY YOUFIXTHIS.COM

Fig.75. BACKUP ALARM KIT



(A)=S270V
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172218-05290	BACKUP ALARM KIT	1							
2	2	172551-00340	FITTING	2							
3	2	172216-01590	NUT	2							
4	2	172216-02870	ALARM, BACK UP	1							
5	2	172216-04270	SWITCH, PRESSURE	2							
6	2	172551-09830	BOLT	2							

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 122 pages

The full manual includes:

- All 122 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar S270V Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual