YANMAR

PARTS CATALOG

PREVIEW - YOUFIXTHIS.COM

0CK50-M00110EN

Last update Oct., 2014

Download full manual at youfixthis.com

Contents

Fig. No. Fig. Name

MAINTENANCE KITS

1. FILTERS/BELTS

CAB

2. STANDARD CAB
3. CAB DOOR-SWING-OUT-(OPTION)
4. CAB DOOR-LATCHES (OPTIONAL SWING-OUT DOOR)
5. SIDE WINDOWS (OPTION)
6. WINDOW WASHER (OPTION)
7. CAB TILT AND REAR WINDOW
8. INTERIOR COVERS
9. FLOOR PAN / FOOT THROTTLE
10. HEADLINER-HEAT-A/C DUCTS (OPTION)
11. CONSOLE CONTROLS-LEFT SIDE
12. CONSOLE CONTROLS-RIGHT SIDE
13. CONSOLE-RIGHT SIDE
14. CONSOLE-LEFT SIDE
15. SEAT
16. MIRROR (OPTION)
17. RADIO (OPTION)
18. HEATER HOSE CIRCUIT (OPTION)
19. HEATER/AIR CONDITIONING BLOWER (OPTION)
20. AIR CONDITIONING CIRCUIT (OPTION)

Fig. No. Fig. Name

CHASSIS

21. FRAME-FRONT/UNDER
22. COUNTER WEIGHTS/CENTER FRAME
23. REAR DOOR
24. REAR ACCESS DOORS
25. REAR HOOD
26. REAR HOOD-AIR CONDITIONING CONDENSER ASSEMBLY (OPTION)

ELECTRICAL

27. CHASSIS WIRE HARNESS/COMPONENTS
28. FUSE BOXES/FUSES/RELAYS
29. BATTERY CIRCUIT/ENGINE WIRE HARNESS
30. OPERATOR WIRE HARNESS-CAB
31. WORK LIGHTS CAB/ROPS WIRE HARNESS

ENGINE

32. EXTERNAL COMPONENTS-LEFT SIDE
33. EXTERNAL COMPONENTS-RIGHT SIDE
34. FUEL CIRCUIT
35. FUEL TANK
36. AIR INTAKE/EXHAUST
37. AIR CONDITIONING COMPRESSOR (OPTION)


ENGINE / HYDRAULICS

38. RADIATOR/HYDRAULIC COOLER

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. FILTERS/BELTS



(A)=T175-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00380	FILTER, HYDRAULIC	1							1
2	1	172551-03830	BELT, A/C COMPRESSOR	1							
3	1	172217-05140	FILTER, MAIN	1							
4	1	172217-05150	FILTER, SECONDARY	1							
5	1	172551-03090	FILTER, AIR	2							1
6	1	172551-00010	FILTER, FRESH AIR	1							1
7	1	172552-15230	CABLE	1							

Remarks
(1)Used when equipped with air conditioning.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.2. STANDARD CAB



(A)=T175-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172552-15280	WELDMENT, ROPS	1							
2	1	172551-00130	WASHER	2							
3	1	172551-09570	SCREW	2							
4	1	172551-08530	COVER, POST	1							
5	1	172551-08490	COVER, POST	1							1
6	1	172551-08510	COVER, POST	1							2
7	1	172551-08540	COVER, POST	1							
8	1	172552-15310	COVER, POST R	1							1
9	1	172552-15300	COVER, POST R	1							3
10	1	172551-08520	COVER, POST	1							4
11	1	172551-10180	SCREW	8							
12	1	172551-03040	GROMMET	2							
13	1	172551-03470	WINDOW, TOP	1							
14	1	172551-09880	SCREW	6							
15	1	172551-01430	WASHER	6							
16	1	172551-03960	SEAL	2							
17	1	172551-01210	WASHER	5							
18	1	172551-09520	SCREW	4							
19	1	172551-11210	WELDMENT	1							5
20	1	172551-10370	WASHER	2							
21	1	172551-09500	SCREW	2							
22	1	172551-05880	SEAL	1							
23	1	172551-11220	WELDMENT	1							6
24	1	172551-00010	FILTER, FRESH AIR	1							6
25	1	172551-06390	COVER,FILTER	1							6
26	1	172551-06400	PAD	1							
27	1	172551-06420	PAD	1							
28	1	172551-06410	PAD	1							
29	1	172551-10400	WASHER	4							
30	1	172551-10180	SCREW	7							
31	1	172215-02840	WASHER	7							7
32	1	172551-08280	COVER, DOOR HEADER	1							
33	1	172551-02430	PLUG	2							
34	1	172551-09620	SCREW	2							
35	1	172551-09030	SPACER	2							
36	1	172551-09220	SPACER	2							
37	1	172551-05970	ISOLATOR	2							
38	1	172551-09340	SEAL	1							
39	1	172551-09330	SEAL	2							
40	1	172551-08960	GASKET	1							8
41	1	172551-09020	GROMMET	1							
42	1	172551-11230	SEAL	1							
43	1	172551-09530	SCREW	5							
44	1	172551-02760	NUT	1							
45	1	172552-15270	BUSHING	1							
46	1	172552-15290	WASHER	1							
47	1	172215-03800	BOLT	1							
48	1	172552-15260	WELDMENT, CAB	1							
49	1	172215-02950	SCREW	1							
50	1	172552-15240	SPRING	1							
51	1	172552-15250	SPACER	1							

Remarks
(1)Swing-Out Door - w/ heater.(Option) Show in Fig.3.
(2)Swing-Out Door -no/ heater.(Option) Show in Fig.3.
(3)Swing-Out Door -no/ heater.(Option) Late-style latch. Show in Fig.3.
(4)Swing-Out Door -no/ heater.(Option) Early-style latch. Show in Fig.3.
(5)Machines not equipped with optional heater or A/C.
(6)Machines equipped with optional heater or A/C.
(7)Not shown in illustration. (8)A/C heater.

N:Old ⇔(Yes/No) New, Q:Old ⇔(No/Yes) New, R:Old ⇔(Yes/Yes) New, S:Old ⇔(No/No) New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

++ CONTINUE ++


Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.21. FRAME-FRONT/UNDER

(A)=T175-1
(B)=
(C)=
(D)=
(E)=
(F)=



No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00600	SCREW	4							
2	1	172551-04910	BLOCK,CYLINDER STOP	2							
3	1	172551-00350	SCREW	6							
4	1	172551-08870	SHIM	2							
5	1	172552-15770	PLATE, COVER	3							


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.32. EXTERNAL COMPONENTS-LEFT SIDE



(A)=T175-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-02600	DIPSTICK ASSY	1							1
2	1	172551-01060	NUT	2							
3	1	172218-05150	SCREW	2							
4	1	172551-01270	CLAMP	1							
5	1	172551-02610	BRACKET, DIPSTICK	1							
6	1	172551-03930	SCREW	1							
7	1	172551-01240	WASHER	1							
8	1	172551-01310	ISOLATOR	1							
9	1	172551-08340	SCREW	4							
10	1	172551-02720	MOUNT, ENGINE	1							2
11	1	172551-02560	CLAMP	2							
12	1	172551-00280	NUT	2							
13	1	172551-03950	SCREW	1							
14	1	172551-09530	SCREW	1							
15	1	172551-04380	WASHER, SNUBBING	1							
16	1	172551-02730	ISOLATOR	1							
17	1	172551-08370	SCREW	4							
18	1	172551-09540	SCREW	1							
19	1	172551-02700	MOUNT, ENGINE	1							3
20	1	172551-02460	COUPLER	1							
21	1	172551-06860	SCREW	8							
22	1	172551-04280	HOUSING,FLYWHEEL	1							
23	1	172551-06840	SCREW	2							
24	1	172551-06850	SCREW	10							
25	1	172551-00720	NUT	1							
26	1	172218-04900	CLAMP	1							
27	1	172551-00440	SCREW	1							
28	1	172552-16090	BRACKET, FLYWHEEL	1							
29	1	172216-09850	WASHER	3							
30	1	172217-04060	SCREW	3							
31	1	172551-02550	ADAPTOR, FILTER	1							
32	1	172216-11900	O-RING 230 N70	1							4
33	1	172551-00460	FITTING	1							
34	1	172552-16100	CONNECTOR	1							
35	1	172552-16120	HOSE	1							
36	1	172552-16110	HOSE	1							
37	1	172215-00020	FITTING	1							
38	1	172551-00320	CONNECTOR	1							
39	1	172551-00270	NUT	3							
40	1	172215-02720	SCREW	3							
41	1	172551-06750	SCREW	2							
42	1	172552-16150	BRACKET, OIL FILTER	1							
43	1	172551-02540	MOUNT, FILTER	1							

Remarks
(1)Includes dipstick and tube.
(2)Rear.
(3)Front left.
(4)Not shown in illustration.
*.Refer to PREFACE : Engine parts catalog No.


N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.39. TRACK ASSEMBLY



(A)=T175-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-05980	TRACK	2							
2	1	172551-03890	PLATE, SERVICE COVER	2							
3	1	172551-00350	SCREW	8							
4	1	172551-04470	STOP,TENSION CYLINDE	1							1
5	1	172551-03491	IDLER ASSY,FRONT	2							
6	1	172551-10100	SCREW	2							
7	1	172551-03741	CYLINDER, TENSION	2							
8	1	172551-04610	STOP,CYLINDER	2							
9	1	172551-08190	SCREW	2							
10	1	172551-03380	SPROCKET, DRIVE	2							
11	1	172551-04761	MOTOR, DRIVE	2							
12	1	172551-02790	PLUG	4							
13	1	172551-00180	NUT	2							
14	1	172551-04460	STOP,TENSION CYLINDE	1							2
15	1	172551-03511	WHEEL ASSY,BOGIE	6							
16	1	172551-05700	SCREW	20							
17	1	172551-06371	IDLER ASSY	2							3
18	1	172551-05520	HOSE	1							
19	1	172551-11310	HOSE	1							
20	1	172551-05490	HOSE	1							
21	1	172551-05490	HOSE	1							

Remarks
(1)Right (2)Left (3)Rear
*.The following four Figs(from Fig.40 to Fig.43)contain detailed component information for the bogie wheels, front and rear idlers, and the track drive motors and sprockets.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.45. BOLT-ON COMPONENTS



(A)=T175-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-09410	FITTING	2							
2	1	172551-04980	BUSHING, SPRING	8							1
3	1	172551-15250	BOLT	2							
4	1	172551-05070	PIN, HEAT TREATED	2							
5	1	172551-00200	NUT	2							
6	1	172551-00160	SCREW	8							
7	1	172551-04930	SHIELD	1							
8	1	172551-09650	SCREW	2							
9	1	172216-15211	BLOCK, COUPLER	1							
10	1	172551-05690	SPACER	1							
11	1	172551-04550	WELDMENT, HANDLE	1							
12	1	172551-15240	WELDMENT, LOADER ARM	1							
13	1	172551-04560	WELDMENT, HANDLE	1							
14	1	172551-09910	SCREW	2							
15	1	172551-05020	COVER, LOADER ARM	1							
16	1	172551-06700	STEP	1							
17	1	172551-09830	BOLT	4							
18	1	172551-00250	NUT	4							4
19	1	172551-06640	PLATE	1							2
20	1	172551-01300	COUPLER	1							2
21	1	172551-01080	COUPLER	1							2
22	1	172551-01290	COUPLER	1							2
23	1	172551-00450	SCREW	2							2
24	1	172551-00160	SCREW	4							2
25	2	172551-06680	SHIELD	1							2
26	2	172552-16480	CHANNEL, SAFETY BAR	1							3
27	2	172552-16460	KNOB	1							
28	2	172551-10300	NUT	1							5
29	2	172551-00280	NUT	1							4
30	1	172551-09710	SCREW	2							
31	1	172552-16450	ISOLATOR	3							
32	1	172552-16470	TETHER	1							
33	1	172551-00260	NUT	1							
34	1	172551-09820	BOLT	1							
35	1	172551-01510	LABEL, KEEP OUT	1							

Remarks
(1)Refer to "Attachment Bracket" (located on Fig.46) for attachment bracket pins and related parts information.
(2)Used when machine is equipped with high-flow hydraulics option.
(3)IMPORTANT: When ordering this part, be sure to also order and affix the warning label as shown in the illustration in Fig.77 Ref.8.
(4)Not shown in illustration.
(5)Against knob-not shown.

N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 95 pages

The full manual includes:

- All 95 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar T175-1 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual