YANMAR

PARTS CATALOG

0CK50-M00120EN

Last update Oct., 2014

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Contents

Fig. No. Fig. Name

MAINTENANCE KITS

1. FILTERS / BELTS

CAB

2. STANDARD CAB
3. CAB DOOR - SWING-OUT (OPTION)
4. CAB DOOR - LATCHES - (OPTIONAL SWING-OUT DOOR)
5. SIDE WINDOWS (OPTION)
6. WINDOW WASHER (OPTION)
7. CAB TILT AND REAR WINDOW
8. INTERIOR COVERS
9. FLOOR POD / FOOT THROTTLE
10. HEADLINER - HEAT-A/C DUCTS
11. CONSOLE CONTROLS - LEFT SIDE
12. CONSOLE CONTROLS - RIGHT SIDE
13. CONSOLE - RIGHT SIDE
14. CONSOLE - LEFT SIDE
15. SEAT
16. MIRROR (OPTION)
17. RADIO (OPTION)
18. HEATER HOSE CIRCUIT (OPTION)
19. HEATER / AIR CONDITIONING BLOWER (OPTION)
20. AIR CONDITIONING CIRCUIT (OPTION)

Fig. No. Fig. Name

CHASSIS

21. FRAME - FRONT / UNDER
22. COUNTERWEIGHTS / CENTER FRAME
23. REAR DOOR
24. REAR ACCESS DOORS
25. REAR HOOD
26. REAR HOOD - AIR CONDITIONING CONDENSER ASSEMBLY (OPTION)

ELECTRICAL

27. CHASSIS WIRE HARNESS / COMPONENTS
28. FUSE BOXES / FUSES / RELAYS
29. BATTERY CIRCUIT / ENGINE WIRE HARNESS
30. OPERATOR WIRE HARNESS
31. WORK LIGHTS CAB / ROPS WIRE HARNESS


ENGINE

32. EXTERNAL COMPONENTS - LEFT SIDE
33. EXTERNAL COMPONENTS - REMOTE OIL FILTER (STANDARD)
34. EXTERNAL COMPONENTS - REMOTE OIL FILTER (HIGH-FLOW HYDRAULICS - OPTION)
35. EXTERNAL COMPONENTS - RIGHT SIDE
36. FUEL CIRCUIT
37. FUEL TANK
38. AIR INTAKE / EXHAUST
39. AIR CONDITIONING COMPRESSOR (OPTION)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. FILTERS / BELTS



(A)=T210-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00380	FILTER, HYDRAULIC	1							
2	1	172551-03830	BELT, A/C COMPRESSOR	1							1
3	1	172217-05140	FILTER, MAIN	1							
4	1	172217-05150	FILTER, SECONDARY	1							
5	1	172551-03090	FILTER, AIR	2							1
6	1	172551-00010	FILTER, FRESH AIR	1							1
7	1	172552-15230	CABLE	1							2

Remarks
(1)Used when equipped with air conditioning.
(2)Used for Yanmar engine diagnostics.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.2. STANDARD CAB



(A)=T210-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172552-15280	WELDMENT, ROPS	1							
2	1	172551-00130	WASHER	2							
3	1	172551-09570	SCREW	2							
4	1	172551-08530	COVER, POST	1							
5	1	172551-08490	COVER, POST	1							1
6	1	172551-08510	COVER, POST	1							2
7	1	172551-08540	COVER, POST	1							
8	1	172552-15310	COVER, POST R	1							1
9	1	172552-15300	COVER, POST R	1							3
10	1	172551-08520	COVER, POST	1							4
11	1	172551-10180	SCREW	8							
12	1	172551-03040	GROMMET	2							
13	1	172551-03470	WINDOW, TOP	1							
14	1	172551-09880	SCREW	6							
15	1	172551-01430	WASHER	6							
16	1	172551-03960	SEAL	2							
17	1	172551-01210	WASHER	5							
18	1	172551-09520	SCREW	4							
19	1	172551-11210	WELDMENT	1							5
20	1	172551-10370	WASHER	2							
21	1	172551-09500	SCREW	2							
22	1	172551-05880	SEAL	1							
23	1	172551-11220	WELDMENT	1							6
24	1	172551-00010	FILTER, FRESH AIR	1							6
25	1	172551-06390	COVER,FILTER	1							6
26	1	172551-06400	PAD	1							
27	1	172551-06420	PAD	1							
28	1	172551-06410	PAD	1							
29	1	172551-10400	WASHER	4							
30	1	172551-10180	SCREW	7							
31	1	172215-02840	WASHER	7							7
32	1	172551-08280	COVER, DOOR HEADER	1							
33	1	172551-02430	PLUG	2							
34	1	172551-09620	SCREW	2							
35	1	172551-09030	SPACER	2							
36	1	172551-09220	SPACER	2							
37	1	172551-05970	ISOLATOR	2							
38	1	172551-09340	SEAL	1							
39	1	172551-09330	SEAL	2							
40	1	172551-08960	GASKET	1							8
41	1	172551-09020	GROMMET	1							
42	1	172551-11230	SEAL	1							
43	1	172551-09530	SCREW	5							
44	1	172551-02760	NUT	1							
45	1	172552-15270	BUSHING	1							
46	1	172552-15290	WASHER	1							
47	1	172215-03800	BOLT	1							
48	1	172552-15260	WELDMENT, CAB	1							
49	1	172215-02950	SCREW	1							
50	1	172552-15240	SPRING	1							
51	1	172552-15250	SPACER	1							

Remarks
(1)Swing-Out Door - w/ heater.(Option) Show in Fig.3.
(2)Swing-Out Door -no/ heater.(Option) Show in Fig.3.
(3)Swing-Out Door -no/ heater.(Option) Late-style latch. Show in Fig.3.
(4)Swing-Out Door -no/ heater.(Option) Early-style latch. Show in Fig.3.
(5)Machines not equipped with optional heater or A/C.
(6)Machines equipped with optional heater or A/C.
(7)Not shown in illustration. (8)A/C heater.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.21. FRAME - FRONT / UNDER



(A)=T210-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-00600	SCREW	4							
2	1	172551-04910	BLOCK,CYLINDER STOP	2							
3	1	172551-00350	SCREW	6							
4	1	172551-08870	SHIM	2							
5	1	172552-15770	PLATE, COVER	3							


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.32. EXTERNAL COMPONENTS - LEFT SIDE



(A)=T210-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-02600	DIPSTICK ASSY	1							1
2	1	172551-01060	NUT	2							
3	1	172218-05150	SCREW	2							
4	1	172551-01270	CLAMP	1							
5	1	172551-02610	BRACKET, DIPSTICK	1							
6	1	172551-03930	SCREW	1							
7	1	172551-01240	WASHER	1							
8	1	172551-01310	ISOLATOR	1							
9	1	172551-08340	SCREW	4							
10	1	172551-02720	MOUNT, ENGINE	1							2
11	1	172551-02560	CLAMP	2							
12	1	172551-00280	NUT	2							
13	1	172551-03950	SCREW	1							
14	1	172551-09530	SCREW	1							
15	1	172551-04380	WASHER, SNUBBING	1							
16	1	172551-02730	ISOLATOR	1							
17	1	172551-08370	SCREW	4							
18	1	172551-09540	SCREW	1							
19	1	172551-02700	MOUNT, ENGINE	1							3
20	1	172551-02460	COUPLER	1							
21	1	172551-06860	SCREW	8							
22	1	172551-04280	HOUSING,FLYWHEEL	1							
23	1	172551-06840	SCREW	2							
24	1	172551-06850	SCREW	10							
25	1	172551-00720	NUT	1							
26	1	172218-04900	CLAMP	1							
27	1	172551-00440	SCREW	1							
28	1	172552-16090	BRACKET, FLYWHEEL	1							
29	1	172216-09850	WASHER	3							
30	1	172217-04060	SCREW	3							

Remarks
(1)Includes dipstick and tube.
(2)Rear.
(3)Front left.
*.Refer to PREFACE : Engine parts catalog No.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.41. TRACK ASSEMBLY



(A)=T210-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172552-00230	TRACK	2							
2	1	172551-03890	PLATE, SERVICE COVER	2							
3	1	172551-00350	SCREW	8							
4	1	172551-04470	STOP,TENSION CYLINDE	1							
5	1	172551-03491	IDLER ASSY,FRONT	2							
6	1	172551-10100	SCREW	2							
7	1	172551-03741	CYLINDER, TENSION	2							
8	1	172551-04610	STOP,CYLINDER	2							
9	1	172551-08190	SCREW	2							
10	1	172551-03380	SPROCKET, DRIVE	2							
11	1	172552-00311	MOTOR, DRIVE	2							
12	1	172551-02790	PLUG	4							
13	1	172551-00180	NUT	2							
14	1	172551-04460	STOP,TENSION CYLINDE	1							
15	1	172551-03511	WHEEL ASSY,BOGIE	8							
16	1	172551-05700	SCREW	20							
17	1	172551-06371	IDLER ASSY	2							
18	1	172551-05520	HOSE	1							
19	1	172551-11310	HOSE	1							
20	1	172551-05490	HOSE	1							
21	1	172551-05490	HOSE	1							


Remarks
*1. Quantities shown are for both sides of the machine.
*2. The following four Figs contain detailed component information for the bogie wheels, front and rear idlers, and the track drive motors and sprockets.

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.47. BOLT-ON COMPONENTS



(A)=T210-1
(B)=
(C)=
(D)=
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172551-09410	FITTING	2							
2	1	172551-04980	BUSHING, SPRING	8							1
3	1	172552-16500	BOLT	2							
4	1	172552-00170	PIN	2							
5	1	172551-00200	NUT	2							
6	1	172551-00160	SCREW	8							
7	1	172551-04930	SHIELD	1							
8	1	172551-09650	SCREW	2							
9	1	172216-15211	BLOCK, COUPLER	1							
10	1	172551-05690	SPACER	1							
11	1	172551-04550	WELDMENT, HANDLE	1							2
12	1	172552-16490	WELDMENT, LOADER ARM	1							
13	1	172551-04560	WELDMENT, HANDLE	1							3
14	1	172551-09910	SCREW	2							
15	1	172551-05020	COVER, LOADER ARM	1							
16	1	172551-06700	STEP	1							
17	1	172551-09830	BOLT	4							
18	1	172551-00250	NUT	4							4
19	1	172551-06640	PLATE	1							5
20	1	172551-01300	COUPLER	1							5
21	1	172551-01080	COUPLER	1							5
22	1	172551-01290	COUPLER	1							5
23	1	172551-00450	SCREW	2							5
24	1	172551-00160	SCREW	4							5
25	1	172551-06680	SHIELD	1							5
26	1	172552-16480	CHANNEL, SAFETY BAR	1							6
27	1	172552-16460	KNOB	1							7
28	1	172551-10300	NUT	1							8
29	1	172551-00280	NUT	1							4
30	1	172551-09710	SCREW	2							
31	1	172552-16450	ISOLATOR	3							
32	1	172552-16470	TETHER	1							
33	1	172551-00260	NUT	1							
34	1	172551-09820	BOLT	1							
35	1	172551-01510	LABEL, KEEP OUT	1							

Remarks
(1)Refer to "Attachment Bracket" (located in the Fig.48) for attachment bracket pins and related parts information.
(2)Left. (3)Right. (4)Not shown in illustration.
(5)Used when machine is equipped with high-flow hydraulics option.
(6)IMPORTANT: When ordering this part, be sure to also order and affix the warning Label (172551-01510) as shown in the illustration in Fig.79; RefNo.8.
(7)Does not include nuts. (8)Against knob-Not shown in illustration.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2014 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 97 pages

The full manual includes:

- All 97 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar T210-1, T210 Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual