
パーツカタログの見方

1. このパーツカタログに記載されている部品は、必ずしも標準装備部品ではありません。
2. 部品変更は、予告なく行うことがあります。
3. パーツカタログリスト様式



Y00F2161 (1997.09.01)

Fig.29 燃料噴射ポンプ(ブーコン用)
FUEL INJECTION PUMP (W/BOOST)

A=	4JH-DT	D=	4JH-DTZA
B=	4JH-DTZ	E=	4JH-DTZY
C=	4JH-DTZP	F=	

●見出 REF.No.	レベル LEV.	0	部品番号 PARTS No.	部品名	DESCRIPTION	個数 (Q'ty) A	B	C	D	E	F	I	R
1	•		729595-51390	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1			1
1-1	•		729595-51391	FOポンプ ASY(ブーコンツキ	FULE INJECTION PUMP	1	1	1	1	1		M	1
	(A=E/#00185)(B=E/#00200)												
3	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	9	9	9	9	9			
I 3-1	••		26022-060162	ナベコネジ M 6X 16	SCREW M 6X 16	4	4	4	4	4		K	
	(A=E/#00185)(B=E/#00200)(C=E/#00156)(D=E/#00156)(E=E/#00156)												
4	••		129470-51040	カムシャフト	CAMSHAFT	1	1	1	1	1			
5	••		122710-51050	ベアリングコロ	BEARING, ROLLER	2	2	2	2	2			
6	••		129470-51060	ベアリングオサエ	RETAINER	1	1	1	1	1			

備考	Remarks
(1) ブーストコンペンセータ付き、4JH-DT、4JH-DTZとも E／#00155までは、特別注文仕様とします	(1) BOOST COMPEMSATOR TYPE. OPTIONAL PART, TO E／#00155, (4JH－DT,4JH－DTZ)

① 見出No.(REF.No.)

リスト頁の見出No.とイラスト図番の末尾が一致しない場合があります。

(例) イラスト図番　　リスト頁の見出No.

1　　1　　(変更前) ⟶ 1 [－1] (変更後)

互換性記号N、R、Kの場合は新部品のイラストを省略している場合があります。

② レベル (LEV.)

レベル
- • ……表示している • 印の数をレベルと呼び親子の関係を示します。(•は親部品です)
- •• ……は • に含まれる子部品です。
- ••• ……は •• に含まれる子部品 (•から見れば孫部品) です。

注) 非販売部品のイラストは一部展開しておりますが、リストには記載しておりません。

③ 変更マーク

前回出版したパーツカタログには無く、今回新規に設計変更が発生した部品について " I " 印が表示されます。

④ 互換性区分

部分変更が行われた場合、その部品に対して下記の互換性記号が表示されます。

記号	互換性	内容
N	旧 ⟵ 新	新部品は、旧部品に対して互換性有り、その逆は無し。
Q	旧 ⟵ 新	新部品は、旧部品に対して互換性無し、その逆は有り。
R	旧 ⟵ 新	新・旧部品双方に対して互換性有り。
S	旧 ⟵ 新	新・旧部品双方に対して互換性無し。
W		新規追加となった部品。
Z		廃止された部品。
F		単品では、互換性無し。但し関連部品セットにて互換性有り。
K		使用個数のみの変更。

⑤ 実施号機

部品が変更された時には、適用される商品形式の実施号機が (A) ～ (F) 欄毎に表示されます。

商品記号	商品 No.	商品記号	商品 No.
C	クラッチNo. コンプレッサNo.	M	本機No.
D	ドライブNo.	T	トラクタNo.
E	エンジンNo.	注1)※	西暦年月

注1) 記号の後の西暦年月を記載している事もあります。(例) ※1996. 01

注2) 実施号機が×××は、部品変更の予告又は、実施号機が確定できなかった部品です。

注3) (A＝E／#00185)は、A欄の商品形式(＝4JH－DT)の部品変更実施号機は、E／#(＝エンジンNo.)が00185号機以降であることを示します。

⑥ 備考(リマークス)区分

R …… 欄に数字又は、英字 (記号) を表示してあります。

リスト下段に上記の記号と同一記号を表記して当該部品に対するコメント(備考)を表示しています。

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

TITLE	Fig.
CYLINDER BLOCK	Fig. 1
GEAR HOUSING	Fig. 2
FLYWHEEL HOUSING & OIL SUMP	Fig. 3
CYLINDER HEAD & BONNET	Fig. 4
SUCTION MANIFOLD & AIR CLEANER	Fig. 5
EXHAUST MANIFOLD & SILENCER	Fig. 6
CAMSHAFT & DRIVING GEAR	Fig. 7
CRANKSHAFT & PISTON	Fig. 8
LUB.OIL SYSTEM	Fig. 9
COOLING WATER SYSTEM	Fig. 10
FUEL INJECTION PUMP	Fig. 11
FUEL INJECTION PUMP (INNER PARTS)	Fig. 11-1
GOVERNOR (INNER PARTS)	Fig. 11-2
FUEL INJECTION VALVE	Fig. 12
FUEL LINE	Fig. 13
STARTING MOTOR	Fig. 14
GENERATOR	Fig. 15
GASKET SET	Fig. 16

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

NUMERICAL INDEX

Part number	Page	Item
Y104200-92350	16	33
Y105025-59530	13	9
Y105325-59570	13	6
Y114250-39450	9	12
Y114250-53080	12	5
Y114250-53120	12	10
Y114250-53130	12	11
Y114250-53140	12	12
Y114250-53210	12	13
Y114250-53400	12	14
Y119032-77910	15	36
Y119131-18320	6	5
Y119233-77932	11	132
	11-2	96
Y119255-44660	10	57
Y119266-49350	10	43
Y119593-59580	12	58
Y119609-32040	16	25
	2	17
Y119620-01750	3	3
Y119620-77380	15	4
Y119620-77421	15	7
Y119620-77440	15	12
Y119620-77461	15	13
Y119620-77471	15	14
Y119620-77490	15	24
Y119620-79200	15	8
Y119620-79210	15	9
Y119620-79220	15	10
Y119620-79230	15	11
Y119620-79250	15	6
Y119620-79260	15	15
Y119620-79290	15	17
Y119620-79300	15	18
Y119620-79310	15	19
Y119620-79320	15	20
Y119620-79330	15	21
Y119620-79340	15	22
Y119620-79350	15	23
Y119620-79360	15	25
Y119625-11880	16	6
	4	20
Y119640-92750	16	34
Y119646-77900	15	35
Y119740-77250	15	29
Y119802-01520	2	12
Y119802-01560	2	13
Y119802-03110	4	41
Y119802-03120	4	42
Y119802-03130	4	43
Y119802-03140	4	44
Y119802-11260	4	26
Y119802-11270	4	27
Y119802-11870	16	5
	4	19
Y119802-12560	5	15
Y119802-21201	8	5
Y119802-21650	8	9
Y119802-25051	7	9
Y119802-25070	7	13
Y119802-25100	7	10
Y119802-25901	7	15
Y119802-32070	2	8
Y119802-32100	2	7
Y119802-32111	2	18
Y119802-32120	2	19
Y119802-32130	2	20
Y119802-39450	9	14
Y119802-49113	10	10
Y119802-49730	10	35
Y119802-51560	11-1	67
Y119802-51590	11-1	73
Y119802-51600	11-1	74
Y119802-51680	11-1	78
Y119802-51690	11-1	79
Y119802-53100	12	6
Y119802-55710	13	15
Y119802-55800	13	2
Y119802-59550	12	52
Y119802-59560	12	54
Y119802-77200	15	34
Y119802-77340	15	30
Y119807-61420	11-2	22
Y119808-12520	5	19
Y119808-12540	5	20
Y119865-21600	8	16
Y119866-12541	5	21
Y119910-12210	5	14
Y119910-12510	5	18
Y119934-01800	2	6
Y119940-59130	9	29
Y119940-77270	15	32
Y119940-77330	15	1
Y120130-11860	4	5
Y120270-54410	4	23
Y121023-01550	2	27
Y121111-21501	8	12
Y121250-44901	10	31
Y121256-44600	10	52
Y121267-44760	10	40
Y121400-11340	16	10
	4	16
Y121450-44531	10	47
Y121470-44581	10	49
Y121520-34810	9	2
Y121550-23200	8	30
Y121550-49111	10	23
Y121850-21680	8	11
Y121850-42410	10	8
Y121850-51960	16	3
	2	21
Y123900-13610	6	6
Y123900-13630	6	4
Y124060-01050	1	10
Y124060-77680	12	59
Y124160-01751	2	14
	4	50
Y124160-01910	1	15
	1	5
Y124160-11360	4	52
Y124160-39140	9	13
Y124240-01871	2	15
Y124395-49840	10	17
	16	15
Y124450-44550	10	51
Y124450-44560	10	48
Y124460-11340	16	4
	4	17
Y124465-44950	10	32
	16	17
Y124550-77030	14	33
Y124722-59050	10	36
	10	39
	12	53
	12	56
Y124766-59050	13	5
	13	8
Y126501-79240	15	5
Y129001-01250	1	11
Y129001-02930	1	25
Y129001-32330	2	11
Y129001-91841	2	22
Y129004-01190	1	33
Y129004-03010	4	39
Y129004-11100	4	10
Y129004-11650	4	31
Y129004-11900	4	21
Y129004-34802	9	1
Y129004-42001	10	1
Y129004-42040	10	15
Y129004-49610	10	33
Y129004-49620	10	37
Y129004-49711	10	34
Y129004-49721	10	38
Y129004-55611	13	1
Y129005-22080	8	17
Y129005-22500	8	19
Y129005-22900	8	33
Y129005-22950	8	35
Y129005-59830	9	15
Y129006-35100	9	8
Y129006-44480	9	23
Y129052-79270	15	16
Y129100-01580	3	15
	3	1
	8	2
Y129100-01640	3	16
Y129100-11110	4	11
Y129100-23910	8	29
Y129100-42051	10	3
Y129100-42121	10	4
Y129100-55690	13	12
Y129100-77500	5	8
Y129100-77510	16	27
	5	9
Y129103-49301	9	33
Y129107-44590	10	64
Y129136-77011	14	1
Y129136-77310	14	2
Y129136-77520	14	14
Y129150-01200	1	31
Y129150-02020	1	7
Y129150-02450	7	4
Y129150-02870	1	34
Y129150-02930	1	28
Y129150-02940	1	37
Y129150-03070	4	40
Y129150-11230	4	32
Y129150-11280	4	28
Y129150-11370	4	18
Y129150-11750	4	34
Y129150-11810	4	7
Y129150-14101	7	7
Y129150-14200	7	1
Y129150-14400	7	2
Y129150-23600	8	31
Y129150-23610	8	39
Y129150-25301	7	16
Y129150-35041	16	11
	9	3

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


シリンダブロック　CYLINDER BLOCK

REF NO.	PARTS NO.	Description	Q'ty	I	R	Remarks
1	**Y729602-01560**	BLOCK ASSY, CYLINDER	1			
5	**Y124160-01910**	・ PLUG PT1/4	2			
6	**Y171051-01921**	・ PLUG	1			
7	**Y129150-02020**	・ BOLT, METAL CAP	10			
10	**Y124060-01050**	・ PLUG PT1/8	1			
11	**Y129001-01250**	・ PLUG 50	1			
12	**Y27241-120000**	・ PLUG 12	2			
13	**Y27241-300000**	・ PLUG 30	8			
14	**Y129795-02411**	・ BUSH, CAMSHAFT	1			
15	**Y124160-01910**	・ PLUG PT1/4	1			
25	**Y129001-02930**	・ MAIN BEARING SET	5		(3)	REPAIR PART.
28	**Y129150-02930**	・ METAL, THRUST	2			
31	**Y129150-01200**	STUD, CYL. HEAD	18			
32	**Y129407-01340**	GASKET,CYL.HEAD	1			
33	**Y129004-01190**	SPACER	1			
34	**Y129150-02870**	MAIN METAL US=0.25	5		(1)	UNDER-SIZED(U.S=0.25)PART.
37	**Y129150-02940**	METAL,THRUST.25(2PIE	1		(2)	OVER-SIZED(O.S=0.25)PART.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER BLOCK




PREVIEW - YOUFIXTHIS.COM

Y00D8100	1. シリンダブロック				
4TNV88-QTB, QTB1		1:2004 01			PLUS

Download full manual at youfixthis.com


FUEL INJECTION PUMP



Y00D8100	11. FOフンシャポンプ				
4TNV88-QTB. QTB1		1:2004 01			PLUS

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

STARTING MOTOR




PREVIEW ONLY YOUFIXTHIS.COM

Y00D8100	14. スターティングモータ				
4TNV88-QTB. QTB1		1:2004 01			PI IIS

Download full manual at youfixthis.com

COOLING WATER SYSTEM



Y00D8100	10. CWシステム				
4TNV88-QTB. QTB1		1:2004 01			PI IIS

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 8 of 44 pages

The full manual includes:

- All 44 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar TB145 4TNV88-QTB(cab), QTB1(canopy), P-TB145EBB, TB145, 4TNV88-QTB(cab) Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual