NUMERICAL INDEX

Part number	Page	Item
101304-59020	15	6
101720-55750	15	55
102103-55520	15	50
103854-59191	15	15
104200-55321	15	46
104200-55330	15	47
104200-55341	15	48
104200-55750	15	56
105010-39140	11	25
110250-55610	15	51
114250-39450	11	1
114250-53080	14	8
114250-53120	14	12
114250-53130	14	13
114250-53140	14	14
114250-53210	14	15
114250-53400	14	16
119000-11280	4	28
119000-11810	4	9
119000-53100	14	9
119000-55601	15	1
119005-35150	10	10
119117-12560	5	19
119117-12570	5	20
119131-77550	17	15
119140-12680	5	22
119160-12540	5	18
119171-11370	4	19
119173-22300	9	22
119174-01200	1	22
119259-44570	12	39
119260-34810	10	7
119266-49350	12	31
119560-59040	15	10
119560-59051	15	7
119560-59110	15	9
119560-59120	15	12
119593-11300	4	41
119620-01750	3	4
119625-11870	4	20
	19	6
119625-11880	4	21
	19	7
119625-11900	4	22
119640-01640	3	8
119642-49050	12	35
119642-49090	12	37
119810-77340	18	6
120147-44810	12	48
121023-26070	2	27
121137-59080	15	61
121250-44901	12	32
121250-49110	15	21
121250-59550	15	31
121252-39150	11	4
121254-77590	17	10
121257-55720	15	52
121257-55731	15	53
121522-59080	15	62
121522-59090	15	64
121550-49111	10	19
121750-59890	15	14
121850-11150	4	17
	19	5
121850-11180	4	18
121850-21130	9	10
121850-21290	9	4
121850-21680	9	9
121850-21920	9	5
121850-44800	12	40
121850-44830	12	42
121850-44840	12	43
121850-44850	12	44
121850-44860	12	45
121850-44870	12	46
121850-44880	12	47
121851-11970	1	15
121855-59880	15	19
	15	20
	15	34
123472-59120	14	28
123500-49550	12	22
	19	19
123550-49530	12	21
123672-01782	3	6
123900-01340	1	23
	19	2
123900-01620	3	2
123900-01710	3	7
123900-01740	2	4
123900-01780	2	3
123900-01830	2	5
123900-02020	1	5
123900-02340	1	24
123900-02410	1	8
123900-02800	1	16
123900-02930	1	19
123900-02940	1	27
123900-03202	4	47
123900-03210	4	48
	19	8
123900-03220	4	49
123900-07900	4	2
123900-11080	4	7
123900-11090	4	8
123900-11100	4	14
123900-11110	4	15
123900-11120	4	16
123900-11200	4	26
123900-11240	4	27
123900-11310	4	51
	19	9
123900-11510	4	29
123900-11520	4	30
123900-11650	4	31
123900-11660	4	35
123900-12100	5	1
123900-12110	5	2
	19	10
123900-13111	6	3
	19	13
123900-13610	6	1
123900-13650	6	10
123900-14200	7	1
123900-14400	7	2
123900-21050	9	1
123900-21650	9	8
123900-22050	9	16
123900-22950	9	35
123900-23000	9	24
123900-23200	9	28
123900-23600	9	29
123900-23610	9	31
123900-23910	9	27
123900-25060	7	9
123900-25130	7	10
123900-32001	2	7
123900-33060	10	3
	19	16
123900-35000	10	11
123900-39650	11	22
123900-42000	12	2
123900-42050	12	10
	19	17
123900-42470	12	13
123900-44761	12	16
123900-49800	12	18
123900-49820	12	26
	19	31
123900-53050	14	5
123900-66820	16	4
123900-77010	17	1
123900-77020	5	7
	19	11
123900-77030	5	8
	19	12
123900-77210	18	12
123900-77330	18	5
123900-77340	18	1
123900-77400	17	2
123900-77440	17	5
123900-77450	17	6
	17	9
123900-77460	17	7
123900-77480	17	8
123900-77500	5	9
123900-77510	17	11
123900-77520	17	12
123900-77540	17	14
123900-77610	17	20
123900-77640	17	22
123900-77650	17	23
123900-77710	17	24
123901-01950	14	1
123901-03090	4	1
123901-03240	4	58
123901-03250	4	59
123901-03260	4	60
123901-03270	4	57
123901-03280	4	62
123901-13200	6	2
123901-14590	7	3
123901-18080	6	12
	19	14
123901-18090	8	1
	19	15
123901-22080	9	14
123901-22900	9	33
123901-39820	11	11
123901-59811	14	30
123901-59821	14	31
123901-59830	14	32
123901-59840	14	33
123901-66820	16	1
123901-66840	16	2
123910-42480	12	14
123912-03270	4	65
123912-03300	4	63
123912-07900	4	55
123912-11330	4	45

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ｼﾘﾝﾀﾞﾌﾞﾛｯｸ　CYLINDER BLOCK

見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	723900-01560	ｼﾘﾝﾀﾞﾌﾞﾛｯｸ ASY	BLOCK ASSY, CYLINDER	1			
4	171051-01921	・ﾌﾟﾗｸﾞ NPTF1	・PLUG	1			
5	123900-02020	・ﾒﾀﾙｷｬｯﾌﾟﾎﾞﾙﾄ	・BOLT,CAP,MAIN-BEARIN	10			
8	123900-02410	・ﾌﾞｼｭ	・BUSH	1			
9	22351-060012	・ｽﾌﾟﾘﾝｸﾞﾋﾟﾝ 6.0AX 12	・SPRING PIN 6X12	2			
10	23875-030000	・ﾈｼﾞﾌﾟﾗｸﾞPT3/8(ﾅﾝｺｳ)	・PLUG PT3/8,STEEL	4			
11	27231-700000	・ｻﾗｶﾞﾀﾌﾟﾗｸﾞ 70	・PLUG 70	1			
12	27241-300000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 30	・PLUG 30	8			
13	23875-030000	・ﾈｼﾞﾌﾟﾗｸﾞPT3/8(ﾅﾝｺｳ)	・PLUG PT3/8,STEEL	1			
14	27225-120160	・ｳﾁｺﾐﾌﾟﾗｸﾞ 12X16	・PLUG 12*16	1			
15	121851-11970	・ﾊﾟｲﾌﾟｼﾞｮｲﾝﾄ	・JOINT, PIPE	1			
16	123900-02800	・ﾒｲﾝﾒﾀﾙ CMP	・BEARING ASSY, MAIN	5			
19	123900-02930	・ｽﾗｽﾄﾒﾀﾙ CMP	・BEARING ASSY, THRUST	2			
22	119174-01200	ﾍｯﾄﾞﾎﾞﾙﾄ	BOLT, CYLINDER HEAD	18			
23	123900-01340	ﾍｯﾄﾞｶﾞｽｹｯﾄ	GASKET, HEAD	1			
24	123900-02340	ﾒｲﾝﾍﾞｱﾘﾝｸﾞ U.S=0.25	MAIN BEARING US=0.25	5		(1)	ｱﾝﾀﾞｰｻｲｽﾞ(U.S=0.25)ﾌﾞﾋﾝﾃﾞｽ
27	123900-02940	ｽﾗｽﾄﾒﾀﾙ 0.S=0.25	BEARING,THRUST .250S	2		(2)	ｵｰﾊﾞｰｻｲｽﾞ(0.S=0.25)ﾌﾞﾋﾝﾃﾞｽ


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER BLOCK

Y00D7140
4TNE106T-TBL

1 シリンダブロック
CYLINDER BLOCK



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ｼﾘﾝﾀﾞﾍｯﾄﾞ & ﾎﾞﾝﾈｯﾄ　CYLINDER HEAD & BONNET


見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	123901-03090	ｺﾞﾑﾎｰｽ(ﾌﾞﾘｰｻﾞOUT	HOSE, RUBBER	1			
2	123900-07900	ﾂﾘｱｹﾞｶﾅｸﾞ	LIFTER	1			
3	26106-100202	ﾂﾊﾞﾎﾞﾙﾄ 10X 20	BOLT M10X 20 PLATED	2			
4	723900-11100	ｼﾘﾝﾀﾞﾍｯﾄﾞ ASSY	HEAD ASSY, CYLINDER	1			
7	123900-11080	・ﾊﾞﾙﾌﾞｼｰﾄ(INT	・ SEAT, INTAKE	4			
8	123900-11090	・ﾊﾞﾙﾌﾞｼｰﾄ(EXH	・ SEAT, EXHAUST	4			
9	119000-11810	・ﾊﾞﾙﾌﾞｶﾞｲﾄﾞ (ﾊｲｷ)	・ GUIDE, VALVE(EXHAUST	8		(1)	
11	23876-005000	・ﾈｼﾞﾌﾟﾗｸﾞ PT 1/16	・ PLUG PT 1/16,SCREW	1			
12	27241-400000	・ﾜﾝｶﾞﾀﾌﾟﾗｸﾞ 40	・ PLUG 40	1			
13	23876-030000	・ﾈｼﾞﾌﾟﾗｸﾞPT 3/8	・ PLUG PT3/8,SCREW	1			
14	123900-11100	・ﾊﾞﾙﾌﾞ(INT	・ VALVE INTAKE	4			
15	123900-11110	・ﾊﾞﾙﾌﾞ(EXH	・ VALVE EXHAUST	4			
16	123900-11120	・ﾍﾞﾝﾊﾞﾈ	・ SPRING, VALVE	8			
17	121850-11150	・ｽﾃﾑｼｰﾙ	・ SEAL, VALVE STEM	8			
18	121850-11180	・ﾍﾞﾝﾊﾞﾈｻｻｴ	・ RETAINER, SPRING	8			
19	119171-11370	・ｷｬｯﾌﾟ(ﾍﾞﾝ	・ CAP, VALVE	8			
20	119625-11870	・ﾌﾟﾛﾃｸﾀ(ﾉｽﾞﾙ	・ PROTECTOR, NOZZLE	4			
21	119625-11880	・ﾉｽﾞﾙｼｰﾄ	・ SEAT, NOZZLE	4			
22	119625-11900	・ｵｻｴ	・ RETAINER	4			
23	26216-060252	・ｳｴｺﾐﾎﾞﾙﾄ 6X 25	・ STUD M 6X 25 PLATED	8			
24	26366-060002	・ﾂﾊﾞﾂｷﾅｯﾄ 6	・ NUT M 6	8			
25	27310-090000	・ｺｯﾀ(ｽﾃﾑ 9	・ COTTER 9	16			
26	123900-11200	ﾍﾞﾝﾜﾝｻﾎﾟｰﾄCMP	SUPPORT COMP,ROCKKER	1			
27	123900-11240	・ﾍﾞﾝﾜﾝｼﾞｸ	・ SHAFT ROCKER ARM	1			
28	119000-11280	・ｽﾌﾟﾘﾝｸﾞ	・ SPRING	3			
29	123900-11510	・ﾍﾞﾝﾜﾝｻﾎﾟｰﾄ(A	・ SUPPORT ROCKER ARM A	3			
30	123900-11520	・ﾍﾞﾝﾜﾝｻﾎﾟｰﾄ(B	・ SUPPORT ROCKER ARM B	1			
31	123900-11650	・ｷｭｳｷﾍﾞﾝﾜﾝ KIT	・ ARM ASSY, SUC. ROCKE	4			
32	129150-11230	・・ ｱｼﾞﾔｽﾀ (ﾍﾞﾝｽｷﾏ	・・ SCREW, VALVE	4			
34	129150-11750	・・ ﾅｯﾄ M8XP1.0	・・ NUT M8XP1.0	4			
35	123900-11660	・ﾊｲｷﾍﾞﾝﾜﾝ KIT	・ ARM ASSY, EXH. ROCKE	4			
36	129150-11230	・・ ｱｼﾞﾔｽﾀ (ﾍﾞﾝｽｷﾏ	・・ SCREW, VALVE	4			
38	129150-11750	・・ ﾅｯﾄ M8XP1.0	・・ NUT M8XP1.0	4			
39	22242-000180	・ﾄﾒﾜC(ｼﾞｸ 18	・ CIRCLIP 18	2			
40	26577-040162	・ｻﾗｺﾈｼﾞ(+ｱﾅ 4X16	・ SCREW M 4X 16	1			
41	119593-11300	ｳｴｺﾐﾎﾞﾙﾄ 8X80	BOLT 8X80	4			
42	26106-080702	ﾂﾊﾞﾎﾞﾙﾄ 8X 70	BOLT M 8X 70 PLATED	4			
43	26366-080002	ﾂﾊﾞﾂｷﾅｯﾄ 8	NUT M 8	4			
44	124160-01751	ﾌﾀ(ﾈﾕｺｳ)	CAP, LUB.OIL SUPPLY	1			
45	123912-11330	ﾎﾞﾝﾈｯﾄ CMP	BONNET ASSY	1			
46	129150-03070	・ﾊﾞﾂﾌﾙ (ﾌﾞﾘｰｻﾞ	・ BAFFLE,BREATHER	2			
47	123900-03202	・ｼﾞﾔﾏｲﾀ(ﾌﾞﾘｰｻﾞ	・ PLATE	1			
48	123900-03210	・PK(ﾌﾞﾘｰｻﾞ	・ PACKING(BREATHER	1			
49	123900-03220	・ｼﾞﾖｲﾝﾄ	・ JOINT	1			
51	123900-11310	・PK(ﾍﾞﾝﾜﾝｼﾂ	・ PACKING	1			
52	26022-050122	・ﾅﾍﾞｺﾈｼﾞ(ﾊﾞﾈ5X12	・ SCREW M5X12	3			
53	124160-11360	ﾄﾂﾃ	KNOB	4			
54	24311-000120	Oﾘﾝｸﾞ 1A P 12.0	O-RING 1A P12.0	4			
55	123912-07900	ﾂﾘｱｹﾞｶﾅｸﾞ	LIFTING	1			
56	26106-100252	ﾂﾊﾞﾎﾞﾙﾄ 10X 25	BOLT M10X25 PLATED	2			
57	123901-03270	ﾌﾞﾘｰｻﾞ CMP	BREATHER ASSY	1			
58	123901-03240	・ﾛﾓｳ	・ WOOL,STEAL	3			
59	123901-03250	・ｶﾊﾞｰ(ﾌﾞﾘｰｻﾞ	・ COVER	1			
60	123901-03260	・ﾌﾞﾘｰｻﾞ	・ BREATHER	1			
61	26116-050102	・ﾎﾞﾙﾄ 5X 10	・ BOLT M 5X 10 PLATED	4			
62	123901-03280	ｴﾙﾎﾞ PT3/8-10	ELBOW	1			
63	123912-03300	ｺﾞﾑﾎｰｽCMP(ﾌﾞﾘｰｻﾞﾓﾄﾞｼ	HOSE CMP,BREAZER OUT	1			
65	123912-03270	・ｺﾙｹﾞｰﾄﾁｭｰﾌﾞ19	・ PROTECTOR,FUEL PIPE	1			
66	123951-03090	ﾌﾞﾘｰｻﾞﾎｰｽ(B	HOSE B, BREATHER	1			
67	23000-016000	ﾎｰｽｸﾘｯﾌﾟ 16	CLAMP 16	2			
68	23000-041000	ﾎｰｽｸﾘｯﾌﾟ 41	CLAMP 41	2			
69	23000-041000	ﾎｰｽｸﾘｯﾌﾟ 41	CLAMP 41	1			
70	24311-000320	Oﾘﾝｸﾞ 1A P 32.0	O-RING 1A P-32.0	1			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7140
4TNE106T-TBL

8 タービン
TURBIN




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Y00D7140
4TNE106T-TBL

12 CWシステム
COOLING WATER SYSTEM



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FOﾊﾟｲﾌﾟ　FUEL LINE

見出 REF NO.	部品番号 PARTS NO.	部品名	Description	数量 Q'ty	互換性 I	R	備考
1	119000-55601	FOﾌｨﾙﾀｰ(ｶｰﾄﾘｯｼﾞ)	FILTER, FUEL	1			
2	129470-55610	FOｺｼｷﾎﾝﾀｲ	BODY, FUEL FILTER	1			
3	123912-55900	FOﾌｨﾙﾀﾌﾞﾗｹｯﾄ	BRACKET	1			
4	26106-100252	ﾂﾊﾞﾎﾞﾙﾄ 10X 25	BOLT M10X 25 PLATED	2			
5	26106-100182	ﾂﾊﾞﾎﾞﾙﾄ 10X 18	BOLT M10X 18 PLATED	2			
6	101304-59020	ｶﾝﾂｷﾞﾃ(ｶﾀｸﾁ 12	JOINT 12, PIPE	2			
7	119560-59051	FO-T CMP	PIPE ASSY, FUEL OIL	1			
9	119560-59110	･ ｺﾙｹﾞﾝﾄﾁｭｰﾌﾞ 15	･ PROTECTOR, FUEL PIPE	1			
10	119560-59040	FO-T D13/7.5 * L700	PIPE,13/7.5X700,FUEL	1			
12	119560-59120	･ ｺﾙｹﾞ-ﾄﾁｭｰﾌﾞ 15	･ TUBE	1			
13	124766-59050	ﾎｰｽｸﾘｯﾌﾟ(ﾏﾙ 12	CLAMP 12	4			
14	121750-59890	ﾅｲﾛﾝﾊﾞﾝﾄﾞ 140	CLAMP 140	1			
15	103854-59191	ｶﾝﾂｷﾞﾃﾎﾞﾙﾄ 12 CMP	BOLT W/PLUG & SEAL	1			
17	124060-59380	･ 6ｶｸﾌﾟﾗｸﾞ 6(ｴｱｰﾇｷ	･ PLUG	1			
18	22190-060002	･ ｼｰﾙﾜｯｼｬ(ｺﾏﾙ.ﾆﾄﾘﾙ) 6	･ SEAL WASHER 6S	1			
19	121855-59880	ｼﾞｮｲﾝﾄ(FOﾊﾟｲﾌﾟ	JOINT	1			
20	121855-59880	ｼﾞｮｲﾝﾄ(FOﾊﾟｲﾌﾟ	JOINT	1			
21	121250-49110	CWﾊﾟｲﾌﾟﾂｷﾞﾃ	JOINT, PIPE	1			
22	22190-120002	ｼｰﾙﾜｯｼｬ(ｺﾏﾙ 12	SEAL WASHER 12	4			
23	23857-060000	ｶﾝﾂｷﾞﾃﾎﾞﾙﾄ 6	JOINT BOLT 6	1			
24	129950-59211	FOﾊﾟｲﾌﾟ	PIPE, FUEL	1			
25	124766-59050	･ ﾎｰｽｸﾘｯﾌﾟ(ﾏﾙ 12	･ CLAMP 12	2			
26	129950-59221	･ ｺﾙｹﾞ-ﾄﾁｭｰﾌﾞ15	･ TUBE	1			
28	124066-59100	ﾎｰｽｸﾘｯﾌﾟ(ﾏﾙ 8	CLAMP 8	9			
29	129495-59300	ｶﾝﾂｷﾞﾃﾎﾞﾙﾄ	BOLT, PIPE JOINT	1			
30	129980-59530	ｼﾞｮｲﾝﾄ(FO-Tﾓﾄﾞｼ	JOINT,FUEL RETN.PIPE	1			
31	121250-59550	FO-T(D8XL120	PIPE, FUEL	3			
32	124732-59562	FO-T(D8XL230	PIPE, FUEL OIL	1			
33	129150-59580	ｷｬｯﾌﾟ(FO-Tﾓﾄﾞｼ	CAP	1			
34	121855-59880	ｼﾞｮｲﾝﾄ(FOﾊﾟｲﾌﾟ	JOINT	1			
35	128300-59910	ｵｰﾊﾞﾌﾛｰﾊﾞﾙﾌﾞ CMP	VALVE ASSY,OVER-FLOW	1			
41	22190-140002	ｼｰﾙﾜｯｼｬ(ｺﾏﾙ.ﾆﾄﾘﾙ)14	SEAL WASHER 14S	2			
42	22190-140002	ｼｰﾙﾜｯｼｬ(ｺﾏﾙ.ﾆﾄﾘﾙ)14	SEAL WASHER 14S	2			
43	22190-080002	ｼｰﾙﾜｯｼｬ(ｺﾏﾙ.ﾆﾄﾘﾙ) 8	SEAL WASHER 8S	1			
44	26106-080102	ﾂﾊﾞﾎﾞﾙﾄ 8X 10	BOLT M 8X 10 PLATED	1			
45	129335-55700	ｳｵｰﾀｾﾊﾟﾚｰﾀ CMP	SEPARATOR, WATER	1			
46	104200-55321	･ ﾃｰﾊﾟﾊﾞﾙﾌﾞ	･ VALVE, TAPER	1			
47	104200-55330	･ ｽﾌﾟﾘﾝｸﾞ(ﾃｰﾊﾟﾊﾞﾙﾌﾞ	･ SPRING, TAPER VALVE	1			
48	104200-55341	･ ﾊﾝﾄﾞﾙ(FOｺｯｸ	･ HANDLE, COCK	1			
49	124064-55510	･ ｵｵｲ(FOｺｼｷ	･ BOWL, FUEL STRAINER	1			
50	102103-55520	･ Oﾘﾝｸﾞ(ｵｵｲ	･ O-RING	1			
51	110250-55610	･ ﾘﾃｰﾆﾝｸﾞﾘﾝｸﾞ	･ RING, RETAINING	1			
52	121257-55720	･ ｽﾌﾟﾘﾝｸﾞ(ｽｸﾘｰﾝ	･ SPRING, SCREEN	1			
53	121257-55731	･ ﾌﾛｰﾄ	･ FLOAT	1			
55	101720-55750	･ 6ｶｸﾌﾟﾗｸﾞ 6(ｴｱｰﾇｷ	･ PLUG	2			
56	104200-55750	･ ﾅﾍﾞｺﾈｼﾞ 4(FOｺｯｸﾊﾝﾄﾞﾙ	･ SCREW M 4	1			
57	171081-55910	･ ｽｸﾘｰﾝ (100ﾒｯｼｭ	･ SCREEN	1			
58	23418-060000	･ ﾊﾟｯｷﾝ(ﾏﾙ 6	･ GASKET 6, NYLON	2			
59	24311-240100	･ Oﾘﾝｸﾞ 1A P 10A	･ O-RING 1A P-10A	1			
60	124722-59050	ﾎｰｽｸﾘｯﾌﾟ(ﾏﾙ 9	CLAMP 9	6			
61	121137-59080	FO-T(D12XL1150	PIPE, FUEL	1			
62	121522-59080	FO-T(D12XL1350	PIPE, FUEL OIL	1			
63	124520-59080	FOT 7/12X580L	PIPE, FUEL OIL	1			
64	121522-59090	FO-T(D12XL900	PIPE (L=900), FUEL	1			

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 7 of 44 pages

The full manual includes:

- All 44 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar TL150, 4TNE106T-TBL Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual