YANMAR

PARTS CATALOG

0CS10-M52701EN

Last update Oct., 2017

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Contents

Fig. No. Fig. Name

LABEL & ACCESSORY

1. LABEL(CABIN)
2. LABEL(CANOPY)
3. SAFETY LABEL(CABIN)
4. SAFETY LABEL(CANOPY)
5. REPAIR PARTS

ENGINE RELATED

6. MUFFLER & AIR CLEANER
7. ACCELERATOR
8. ENGINE MOUNT
9. RADIATOR SHURAUD
10. RADIATOR & SUB-TANK
11. DUCT
12. FUEL TANK
13. FUEL LINE

ELECTRICAL PARTS

14. BATTERY
15. ELECTRIC PART(AROUND ENGINE)
16. ELECTRIC PART(AROUND FRAME)
17. ELECTRIC PART(STARTING SWITCH)
18. ELECTRIC PART(AROUND SEAT)
19. ELECTRIC PART(TRAVEL ALARM)
20. ELECTRIC PART(WORK LAMP)

Fig. No. Fig. Name

21. ELECTRIC PART(QUICK COPLER : SWITCH BOX)

AIR CONDITIONER & HEATER

22. HEATER(TO M53438)
119. (22A)HEATER(FROM M53439)
23. AIR CONDITIONER(ELECTRIC PART)
24. AIR CONDITIONER(ENGINE RELATED)
25. AIR CONDITIONER(CONDENSER RELATED)
26. AIR CONDITIONER(CABIN RELATED)(TO M53438)
120. (26A)AIR CONDITIONER(CABIN RERATED)(FROM M53439)
27. AIR CONDITIONER(PIPING)

TRAVELING

29. SPROCKET & ROLLER
123. (29A)TRACK ROLLER(K SPEC.)
30. IDLER & ADJUST
31. CRAWLER


CONTROL EQUIPMENT

32. CONTROL EQUIPMENT(LOCK LEVER & STAND : RIGHT)
33. CONTROL EQUIPMENT(LOCK LEVER & STAND : LEFT)
34. CONTROL EQUIPMENT(TRAVEL LEVER)
35. CONTROL EQUIPMENT(BLADE LEVER)
36. CONTROL EQUIPMENT(SWING PEDAL)
37. CONTROL EQUIPMENT(LOW-HIGH PEDAL)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.6. MUFFLER & AIR CLEANER



(A)=VIO27-5B(US)
(B)=VIO27-5B(AS)
(C)=VIO27-5B(NZ)
(D)=VIO27-5B(SG)
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172A45-11301	TUBE ASSY, EXHAUST	1	1	1	1				
3	2	172A46-11390	TAPE, INSURATOR	3	3	3	3				
4	1	172A46-11302	MUFFLER ASSY	1	1	1	1				
4-1	1	172A77-11300	SILENCER ASSY	1	1	1	1			N	
	(A=M53534)	(B=M53534)	(C=M53534) (D=M53534)								
5	1	172A46-11500	CLEANER ASSY, AIR	1	1	1	1				1
6	2	129004-12520	ELEMENT	1	1	1	1				
6-1	2	119808-12520	ELEMENT	1	1	1	1			R	
	(A=M53831)	(B=M53831)	(C=M53831) (D=M53831)								
7	2	119866-12530	COVER ASSY	1	1	1	1				
8	2	119808-12540	VALVE, UNLOADER	1	1	1	1				
9	1	172A46-11510	HOSE, AIR CLEANER	1	1	1	1				
10	1	172A46-11520	HOSE, AIR CLEANER	1	1	1	1				
11	1	172A46-11550	BRACKET ASSY	1	1	1	1				
12	1	124701-11911	GASKET, SILENCER	1	1	1	1				
13	1	129400-13201	GASKET, SILENCER	1	1	1	1				
14	1	23000-070000	CLAMP, 70	3	3	3	3				
15	1	26013-080202	BOLT, M8X 20	2	2	2	2				
16	1	26013-080252	BOLT, M8X 25	4	4	4	4				
17	1	26014-100252	BOLT, M10X 25	2	2	2	2				
18	1	26051-080002	NUT, M8	8	8	8	8				
19A	1	172125-03951	LABEL, AIR CLEANER	1	1	1	1				2

Remarks
(1)Please use this part with following label at the same time.
Ref.No.19A.
(2)Label is not illustrated.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.15. ELECTRIC PART(AROUND ENGINE)



(A)=VIO27-5B(US) (D)=VIO27-5B(SG)
(B)=VIO27-5B(AS) (E)=
(C)=VIO27-5B(NZ) (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172A85-16500	HARNESS ASSY,A	1	1	1	1				
1-1	1	172A85-16501	HARNESS ASSY,A	1	1	1	1			S	1
	(A=M/#53276)	(B=M/#53276)	(C=M/#53276) (D=M/#53276)								
1A	2	1A7130-51130	DIODE, 1.5A	2	2	2	2			W	
	(A=M53494)	(B=M53494)	(C=M53494) (D=M53494)								
3	2	172458-16550	FUSE, SLOWBLOW	1	1	1	1				
5	1	172A45-16610	SUPPORT, HARNESS	1	1	1	1				
6	1	172A45-16740	SUPPORT ASSY	1	1	1	1				
7	1	172A45-16760	SUPPORT ASSY	1	1	1	1				
8	1	194680-51670	BAND, CLIP	9	9	9	9				
8-1	1	194680-51670	BAND, CLIP	10	10	10	10			K	
	(A=M53168)	(B=M53168)	(C=M53168) (D=M53168)								
9	1	129612-52100	PUMP ASSY, FUEL FEED	1	1	1	1				
10	1	22137-060000	WASHER, 6	2	2	2	2				
11	1	22137-100000	WASHER, 10	2	2	2	2				
12	1	22217-060000	WASHER, SPRING 6	1	1	1	1				
13	1	26013-060162	BOLT, M6X 16	2	2	2	2				
14	1	26013-100162	BOLT, M10X 16	3	3	3	3				
14-1	1	26013-100162	BOLT, M10X 16	1	1	1	1			K	
	(A=M53425)	(B=M53425)	(C=M53425) (D=M53425)								
15	1	26013-100202	BOLT, M10X 20	2	2	2	2				
16	1	26716-060002	NUT, M6	1	1	1	1				
17	1	933171-15801	CORD, ENGINE EARTH	1	1	1	1				
18	1	124970-77920	TIMER	1	1	1	1				
19	1	22217-060000	WASHER, SPRING 6	1	1	1	1				
20	1	26013-060162	BOLT, M6X 16	1	1	1	1				
21	1	172455-61720	BOLT	2	2	2	2			W	
	(A=M53425)	(B=M53425)	(C=M53425) (D=M53425)								
22	1	22217-100000	WASHER, SPRING 10	2	2	2	2			W	
	(A=M53425)	(B=M53425)	(C=M53425) (D=M53425)								
23	1	194202-56460	BAND, 200	1	1	1	1			W	
	(A=M53307)	(B=M53307)	(C=M53307) (D=M53307)								

Remarks
(1)A=Ref.No.1:normal type, No.1-1:waterproof type.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.43. TRACK FRAME & TURNING BEARING



(A)=VIO27-5B(US)
(B)=VIO27-5B(AS)
(C)=VIO27-5B(NZ)
(D)=VIO27-5B(SG)
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172A44-50101	FRAME ASSY, LOWER	1	1	1	1				
2	1	172458-50480-2	COVER, FRAME	2	2	2	2				
3	1	26106-100122	BOLT, M10X 12 PLATED	4	4	4	4				
4	1	172730-05250	WASHER	12	12	12	12				1
5	1	172458-50800-2	PLATE, GUARD	2	2	2	2				1
6	1	172458-50810-2	PLATE, GUARD	2	2	2	2				1
7	1	26013-120252	BOLT, M12X 25	12	12	12	12				1
8	1	172458-57600-2	BEARING, TURNING	1	1	1	1				
9	2	172142-57610	SEAL SET	1	1	1	1				
10	3	172122-57630	SEAL, SWING	1	1	1	1				
11	3	172122-57640	SEAL, SWING	1	1	1	1				
12	1	172A46-57610	BOLT	32	32	32	32				
13	1	172122-57620	PIN, PARALLEL	4	4	4	4				

Remarks
(1)Iron crawler spec.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.53. CABIN(BODY)

(A)=VIO27-5B(US) (D)=VIO27-5B(SG)
(B)=VIO27-5B(AS) (E)=
(C)=VIO27-5B(NZ) (F)=



No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172312-17250	ASHTRAY	1	1	1	1				
2	1	172458-63580	SPACER	1	1	1	1				
3	1	172164-65710	RUBBER, SEAL	1	1	1	1				
4	1	172A47-67801	CABIN ASSY	1	1	1	1				1
5	2	172458-03310	LABEL, CABIN FRONT	1	1	1	1				
6	2	1E5100-51430	KNOB, CLUTCH	1	1	1	1				
7	2	172519-63240	BOLT	6	6	6	6				
8	2	172455-67310	RUN, GLASS	2	2	2	2				
9	2	172455-67320	CAP, CHANNEL	2	2	2	2				
10	2	172455-67330	PLATE ASSY, GLASS	2	2	2	2				
11	2	172455-67340	HOLDER, GLASS	2	2	2	2				
12	2	172455-67350	SCREW	4	4	4	4				
13	2	172455-67360	SCREW	2	2	2	2				
14	2	172455-67440	CLIP, TREE	4	4	4	4				
15	2	172458-67840	RUN, GLASS	1	1	1	1				
16	2	172458-67960	SEAL	1	1	1	1				
17	2	172458-67970	SEAL	1	1	1	1				
18	2	172458-67981	SEAL	1	1	1	1				
19	2	172A47-68001	FRAME ASSY, CABIN	1	1	1	1				
20	3	172458-68070	HINGE ASSY, DOOR	2	2	2	2				
21	2	172162-69050	LOCK ASSY	1	1	1	1				
22	2	172165-69190	RUBBER, STOPPER	1	1	1	1				
23	2	172458-69790	COVER ASSY	1	1	1	1				
23-1	2	172M04-69790	COVER ASSY	1	1	1	1				R
		(A=M53831)	(B=M53831) (C=M53831) (D=M53831)								
24	2	172458-69830	LEVER, RESET	1	1	1	1				
25	2	172458-69930	SEAL, DOOR	1	1	1	1				
26	2	22117-100000	WASHER, 10	1	1	1	1				
27	2	22117-120000	WASHER, 12	2	2	2	2				
28	2	22272-000100	RING, E-10	1	1	1	1				
29	2	24550-012200	BUSH, 12X20	1	1	1	1				
30	2	26366-080002	NUT, M8	4	4	4	4				
31	2	26716-100002	NUT, M10	1	1	1	1				
32	1	22867-400100	SCREW, 4X10	3	3	3	3				
33A	1	172437-03441	LABEL, ROPS	1	1	1	1				2
33B	1	172437-03451	LABEL, SEAT BELT	1	1	1	1				2
33C	1	172A47-03250	LABEL, PTO FOOT	1	1	1	1				2
34	1	172444-68650	CLIP, TREE	2	2	2	2			W	
		(A=M53001)	(B=M53001) (C=M53001) (D=M53001)								


Remarks
(1)Please use this part with following label at the same time.
Ref.No.33A,33B,33C.
(2)Label is not illustrated.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.63. HYD.OIL PUMP & JOINT(QUICK COUPLER SPEC.)



(A)=VIO27-5B(US)
(B)=VIO27-5B(AS)
(C)=VIO27-5B(NZ)
(D)=VIO27-5B(SG)
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172168-71101-4	COVER, FLYWHEEL	1	1	1	1				
2	1	172165-71200	COUPLING	1	1	1	1				
3	1	172422-76100	FLANGE	1	1	1	1				
4	1	22117-100000	WASHER, 10	4	4	4	4				
5	1	24321-000400	O-RING, 1AG40.0	1	1	1	1				
6	1	26013-100302	BOLT, M10X 30	4	4	4	4				
7	1	26013-100302	BOLT, M10X 30	8	8	8	8				
8	1	26013-120352	BOLT, M12X 35	2	2	2	2				
9	1	26450-120402	BOLT, M12X 40	3	3	3	3				
10	1	172958-73501	PUMP ASSY	1	1	1	1				
11	2	172458-73510	BARREL KIT, CYLINDER	1	1	1	1				
12	3	172422-73130	HOLDER, BARREL	1	1	1	1				
13	3	172422-73250	RETAINER	2	2	2	2				
14	3	172458-73530	NEEDLE	3	3	3	3				
15	3	172458-73540	SPRING	1	1	1	1				
16	3	172458-73670	HOLDER, SHOE	1	1	1	1				
17	3	22252-000350	RING, 35	1	1	1	1				
18	3	172458-73520	PISTON ASSY, PUMP	1	1	1	1				
19	2	172422-73140	PLATE, SWASH	1	1	1	1				
20	2	172422-73160	PIN	2	2	2	2				
21	2	172422-73220	PIN	1	1	1	1				
22	2	172422-73280	PIN	1	1	1	1				
23	2	172422-73290	BEARING, BALL	1	1	1	1				
24	2	172422-73500	BEARING, NEEDLE	1	1	1	1				
25	2	172958-73510	BLOCK ASSY, VALVE	1	1	1	1				
25-1	2	172958-73511	BLOCK ASSY, VALVE (A=*2014.10.) (B=*2014.10.) (C=*2014.10.) (D=*2014.10.)	1	1	1	1			N	
26	3	172422-73550	PLUG	8	8	8	8				
27	3	172422-73620	SPRING	1	1	1	1				
28	3	172422-73630	FILTER	1	1	1	1				
29	3	172458-73630	PLUG	1	1	1	1				
30	3	172422-73640	ADJUSTER KIT	1	1	1	1				
31	3	172458-73640	PLUG	1	1	1	1				
32	3	172422-73650	PLUG	2	2	2	2				
33	3	172422-73660	BOLT	1	1	1	1				
34	3	172422-73670	CLAMP	1	1	1	1				
35	3	24311-000100	O-RING, 1AP10.0	1	1	1	1				
36	3	24315-000080	O-RING, 1BP8.0	1	1	1	1				
37	3	24315-000140	O-RING, 1BP14.0	1	1	1	1				
38	3	26450-050452	BOLT, M5X 45	4	4	4	4				
39	3	172458-73680	VALVE ASSY	1	1	1	1				1
40	3	172458-73690	VALVE ASSY	1	1	1	1				2
41	3	172458-73790	VALVE,SOLENOID	1	1	1	1				3
42	2	172422-73520	SPRING	4	4	4	4				
43	2	172422-73530	PLUG	1	1	1	1				
44	2	172422-73530	PLUG	1	1	1	1				
45	2	172422-73540	BOLT	5	5	5	5				
46	2	172422-73550	PLUG	5	5	5	5				
47	2	172458-73550	SPRING	1	1	1	1				
48	2	172422-73560	SCREW	1	1	1	1				
49	2	172458-73560	HOLDER, SPRING	1	1	1	1				

Remarks
(1)For second gear traveling.
(2)For safety lock.
(3)For quick coupler.

N:Old ⇔(Yes/No) New, Q:Old ⇔(No/Yes) New, R:Old ⇔(Yes/Yes) New, S:Old ⇔(No/No) New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change


++ CONTINUE ++

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Fig.106. BOOM



(A)=VIO27-5B(US) (D)=VIO27-5B(SG)
(B)=VIO27-5B(AS) (E)=
(C)=VIO27-5B(NZ) (F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172A84-81100	BOOM ASSY	1	1	1	1				1
1-1	1	172A84-81101	BOOM ASSY,EX (2J)	1	1	1	1			S	1
	(A=M/#53131)	(B=M/#53137)	(C=M/#53136) (D=M/#53092)								
1-2	1	172A84-81101-Y	BOOM ASSY,EX	1	1	1	1			S	1
	(A=M54001)	(B=M54001)	(C=M54001) (D=M54001)								
2	2	172020-10620	SEAL, DUST	4	4	4	4				
4	2	172458-81400	BUSH	2	2	2	2				
5	1	172164-81670	SPACER	1	1	1	1				
6	1	172175-81700	SHIM	2	2	2	2				
7	1	172175-81710	SHIM	2	2	2	2				
8	1	172458-81800	PIN ASSY	2	2	2	2				
9	1	172A44-81910	PIN ASSY(40X168	1	1	1	1				
10	1	172A46-81930	PIN ASSY	1	1	1	1				
11	1	172165-82520	SHIM	1	1	1	1				
12	1	172165-82530	SHIM	1	1	1	1				
13	1	172165-82580	SHIM	1	1	1	1				
14	1	172165-82590	SHIM	1	1	1	1				
15	1	172146-82910	SPACER	1	1	1	1				
16	1	22157-120000	WASHER, 12	1	1	1	1				
17	1	22157-120000	WASHER, 12	3	3	3	3				
18	1	24761-050000	NIPPLE, GREASE C	2	2	2	2				
19	1	26013-120202	BOLT, M12X 20	1	1	1	1				
20	1	26013-120252	BOLT, M12X 25	2	2	2	2				
21	1	26013-120302	BOLT, M12X 30	2	2	2	2				
22	1	172126-16540	CLAMP	1	1	1	1				
23	1	26013-100202	BOLT, M10X 20	1	1	1	1				
24	1	172A46-61150-2	COVER, HOSE	1	1	1	1				
24-1	1	172A46-61150-Y	COVER, HOSE	1	1	1	1			S	
	(A=M54001)	(B=M54001)	(C=M54001) (D=M54001)								
25	1	172137-62970	GROMMET	3	3	3	3				
26	1	172A46-79300-2	GUIDE, HOSE	1	1	1	1				
26-1	1	172A46-79300-Y	GUIDE, HOSE	1	1	1	1			S	
	(A=M54001)	(B=M54001)	(C=M54001) (D=M54001)								
27	1	172A46-81800-2	COVER, BOOM	1	1	1	1				2
27-1	1	172A46-81800-Y	COVER, BOOM	1	1	1	1			S	2
	(A=M54001)	(B=M54001)	(C=M54001) (D=M54001)								
28	1	172A44-81950-2	COVER ASSY, BOOM	1	1	1	1				
28-1	1	172A44-81950-Y	COVER ASSY, BOOM	1	1	1	1			S	
	(A=M54001)	(B=M54001)	(C=M54001) (D=M54001)								
29	1	22137-100000	WASHER, 10	1	1	1	1				
30	1	22157-080000	WASHER, 8	3	3	3	3				
31	1	26013-080162	BOLT, M8X 16	3	3	3	3				
32	1	26013-080162	BOLT, M8X 16	2	2	2	2				
33	1	26013-100202	BOLT, M10X 20	1	1	1	1				
34	1	26013-100302	BOLT, M10X 30	1	1	1	1				
35	1	26013-100452	BOLT, M10X 45	2	2	2	2				
36	1	26013-100202	BOLT, M10X 20	2	2	2	2				
37	1	172A46-72680-2	COVER, HOSE	1	1	1	1				
37-1	1	172A46-72680-N	COVER, HOSE	1	1	1	1			S	
	(A=M54001)	(B=M54001)	(C=M54001) (D=M54001)								
38	1	172A47-72770-2	PIPE ASSY, BOOM	1	1	1	1				

Remarks
(1)Please use this part with following label at the same time.
Ref.No.42A,42B,42C.
L=Ref.No.1:480mm, No.1-1:380mm.
(2)Please use this part with following label at the same time.
Ref.No.43A,43B,43C.
(3)Label is not illustrated.

N:Old ⇔ New, Q:Old ⇔ New, R:Old ⇔ New, S:Old ⇔ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

++ CONTINUE ++

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com


Parts No. Index

Parts No.	Fig. No.	Ref. No.
114110-07760	1	65
	2	62
	3	32
	4	31
	52	27 E
114110-07761	1	65 -1
	2	62 -1
	3	32 -1
	4	31 -1
	52	27 E-1
119247-77100	18	12
	23	8
119650-77910	18	14
119650-77911	18	14 -1
119802-55710	13	12
119802-77200	18	13
119808-12520	6	6 -1
119808-12540	6	8
119866-12530	6	7
120147-44810	28	15
121250-49121	10	6
121450-44531	10	12
121468-44510	10	10
121468-44520	10	10 -1
121468-44540	10	13
121470-44581	10	15
124450-44560	10	14
124465-44950	22	23
	27	43
	119	24
124701-11911	6	12
124766-59050	10	18
	13	15
124970-77920	15	18
129004-12520	6	6
129100-55690	13	11
129211-77920	18	15
129400-13201	6	13
129612-52100	15	9
129942-07760	117	46
129942-07761	117	46 -1
172020-10620	106	2
172110-76170	102	6 -1
172110-76170-3	102	6
172112-77361	91	11
	114	23
172112-87860	111	2
172113-12522	7	8
172116-75850-B	90	15
172116-76381	93	21
172117-83970-7	67	35
172122-17190	50	13 -1
		15 -1
172122-37844	30	15
		36
172122-46590	34	13
	36	13
172122-57620	43	13
172122-57630	43	10
172122-57640	43	11
172122-70350	70	53
172122-70630	71	39
172122-73430	70	62
172122-73470	70	10
	71	40
172122-73480	70	11
172122-79890	104	25
172122-79930	90	18
	96	14
		15
	102	17
	104	26
	116	12
172122-82290	108	8
172123-76121	19	9
	91	3
	93	4
	97	5
	99	10
		10 -1
	100	30
	102	3
	104	1
	114	18
	115	1
172124-13230-3	8	9
172124-13411	10	8
172124-17640	22	12
	27	19
	119	13
172124-46200	33	5
	34	12
	36	11
	110	1
172124-65450	51	13
172124-65480	51	14
172124-70380	71	35
172124-70390	71	2
		36
172124-76160	93	7
172124-94310-5	111	9
172125-03951	1	40
	2	36
	3	11
	4	10
	6	19 A
172126-11510	14	7 A
	18	1
	22	1
	27	2
		3
	119	1
172126-16540	19	23
	56	25
	106	22
172137-12270	7	7
172137-14610	13	9
172137-16560	20	6
	27	7
172137-17631	22	10
	27	17
	119	11
172137-46042	8	11
	64	1
	65	1
	66	1
172137-46210	21	18
172137-62970	106	25
172137-66230	45	3
172137-69850	47	14
172137-73860	72	5
172137-76580	102	9
172141-13490	22	2
	27	4
	119	2
172141-37320	29	6
	123	3
172141-41340	7	9
	34	1
172141-41360	36	5
	37	3
	49	4
172141-41370	33	3
	34	3
		6
	40	3
172141-50762-3	45	21
172141-50763-1	45	21 -1
172141-70110	70	48
172141-70150	70	50
172141-70160	70	51
172141-70370	70	3
172141-70440	70	42
172141-70450	70	4
172141-70460	70	5
172141-70470	70	6
172141-72190	65	8
	68	3
172141-72250	66	8
	67	2
172141-72420	66	9
172141-72690	68	5
172141-73090	66	32
172141-73770	90	6
172141-76181	19	10
	67	27
	92	9
	93	9
	95	1
	96	1
	97	8
	99	11
		11 -1
	100	9
	102	7
	113	21
172141-76220	96	5
	100	12
	115	2
172141-76900	113	19
172141-76920	103	6
172141-84601	110	18
172142-45870	36	10
172142-57610	43	9
172142-72260	64	33
172142-73800	72	7
172142-74670	99	7
172142-76181	64	38
	65	32
	66	35
	93	11
	95	3
	96	3
172142-76240	100	13
172142-76940-2	101	10
172142-76940-Y	101	10 -1
172142-81620	107	7
172142-82310	105	4
172142-94241-W	111	8
172146-45691	34	9

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

VEHICLE PAINTED COLOR(2)(FROM M54001)




Color Code	Desc-ription	Painted Color	Paint Part No.		
			16L Can	4L Can	SPRAY
49		YANMAR Navy Gray	-------	TOR-91390000	TOR-94800490
2R		YANMAR Turmeric Yellow	-------	977620-41001	977620-41002
73		YANMAR Warm Gray	-------	-------	TOR-94800730
83		YANMAR Grayish Green	981101-09615	977620-40830	977620-30N41
12		YANMAR Black	-------	TOR-91220001	TOR-94800120

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.41. TURNING FRAME

(A)=VIO27-5B(US)
(B)=VIO27-5B(AS)
(C)=VIO27-5B(NZ)
(D)=VIO27-5B(SG)
(E)=
(F)=



No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	172A44-53310	WEIGHT, COUNTER	1	1	1	1				
2	1	172A47-53320	SEAL, WEIGHT	1	1	1	1				
3	1	172187-53321	WASHER	2	2	2	2				
4	1	172455-53331	BOLT	2	2	2	2				
5	1	172458-14380	PLATE, RUBBER	1	1	1	1				
6	1	172A44-54090	FRAME ASSY, TURNING	1	1	1	1				1
8	2	172168-54750	BUSH 60X70	2	2	2	2				
9	2	172168-54760	SEAL, DUST	2	2	2	2				
10	1	172A46-54530	BOSS ASSY	1	1	1	1				
11	1	172A47-65911	HINGE ASSY	1	1	1	1				
12	1	22157-100000	WASHER, 10	2	2	2	2				
12-1	1	22137-100000	WASHER, 10	2	2	2	2			N	
	(A=M53001)	(B=M53001)	(C=M53001) (D=M53001)								
13	1	22217-160000	WASHER, SPRING 16	2	2	2	2				
14	1	24761-050000	NIPPLE, GREASE C	1	1	1	1				
15	1	26013-100402	BOLT, M10X 40	2	2	2	2				
16	1	26116-160402	BOLT, M16X 40 PLATED	2	2	2	2				
17	1	172458-54750	SEAL	1	1	1	1				
18A	1	172156-03740	LABEL, GREASE	1	1	1	1				2

Remarks
(1)Please use this part with following label at the same time.
Ref.No.18A.
(2)Label is not illustrated.


N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

Download full manual at youfixthis.com

PREVIEW YOUFIXTHIS.COM

Fig.82. CONTROL VALVE(US,AS,NZ:3/7)



(A)=VIO27-5B(US)
(B)=VIO27-5B(AS)
(C)=VIO27-5B(NZ)
(D)=VIO27-5B(SG)
(E)=
(F)=

No.	Lev.	Parts No.	Description	Q'ty (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	2	172A46-74410	VALVE	1	1	1					
2	3	172499-70180	VALVE ASSY, REVERSE	1	1	1					
3	3	172458-74230	O-RING	2	2	2					
4	3	172A46-74260	INLET SECTION SUB	1	1	1					
4A	4	172A46-74250	SPOOL ASSY, INLET	1	1	1					
6	3	172458-74260	BOLT	4	4	4					
7	3	172173-74280	SPRING	1	1	1					
8	3	172A47-74360	FILTER	1	1	1					
9	3	172A47-74370	PISTON	1	1	1					
10	3	172A47-74380	COVER, PILOT	1	1	1					
11	3	172458-74530	SEAT, SPRING	1	1	1					
12	3	172458-74540	SPRING, RETURN	1	1	1					
13	3	172458-74550	COVER, PILOT	1	1	1					
14	3	172458-74670	PLUG	1	1	1					
15	3	172A47-74980	CIRCLIP	1	1	1					
16	3	24315-000080	O-RING, 1BP8.0	1	1	1					
17	2	172458-74680	VALVE, RELIEF	2	2	2					
17-1	2	172A85-74680	RELIEF 210/30	2	2	2					N
	(A=M53516)	(B=M53516)	(C=M53516)								
18	2	172A44-74160	SECTION, TRAVEL	1	1	1					
18-1	2	172A44-74161	SECTION, TRAVEL	1	1	1					N
	(A=M53516)	(B=M53516)	(C=M53516)								
19	3	172458-74130	WIPER, DUST	1	1	1					
20	3	172458-74140	RETAINER, SEAL	1	1	1					
21	3	172A44-74260	SECTION ASSY, TRAVEL	1	1	1					
21A	4	172A44-74150	SPOOL ASSY, TRAVEL	1	1	1					
22	3	172458-74170	CAP, SPRING	1	1	1					
22-1	3	172A78-74170	CAP, SPRING	1	1	1					N
	(A=M53516)	(B=M53516)	(C=M53516)								
24	3	172458-74290	VALVE, REVERSE	1	1	1					
25	3	172458-74360	SPRING, VALVE	1	1	1					
26	3	172458-74640	STAY, VALVE	1	1	1					
27	3	24311-000120	O-RING, 1AP12.0	1	1	1					
28	3	24315-000110	O-RING, 1BP11.0	1	1	1					
28-1	3	41851-000110	O-RING	1	1	1					N
	(A=M53092)	(B=M53092)	(C=M53092)								
29	3	26450-050102	BOLT, M5X 10	2	2	2					
30	3	26450-050182	BOLT, M5X 18	2	2	2					

Remarks
* Control valve assy is shown in Fig.80.

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

Copyright (C) 2013 YANMAR CO., LTD. All RightsReserved.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 172 pages

The full manual includes:

- All 172 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar Vio27-5B Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual