
0-05 Engine Gasket Kit
0-05 Jeu de joints du moteur
0-05 Kit de Juntas do Motor
0-05 Kit de empaquetaduras de motor

005A0151400 A.1




PREVIEW ONLY YOUFIXTHIS.COM

Download full manual at youfixthis.com

Track Frame, Without Blade
Bâti de chenille, sans lame
Estrutura da Esteira, sem Lâmina
Bastidor de oruga, sin hoja niveladora

TX1115592 B.1




TX1115592

PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

Hydraulic Pump
Pompe hydraulique
Bomba Hidráulica
Bomba hidráulica

TX1116895 A.1




TX1116895

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Cab
Cabine
Cabine
Cabina

TX1116247 A.1




TX1116247

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Blade (Standard) 2490 mm (98 in.)
Lame (standard) 2490 mm (98 in.)
Lâmina (Padrão) 2490 mm (98 in.)
Cuchilla (estándar) 2490 mm (98 in.)

TX1117865 A.1



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Table of Contents

01 Wheels & Tires & Tracks
0130 Track Systems 48
02 Axles, Differentials & Suspension Systems
0260 Axles, Diff. & Susp. Sys. Hyd. (Incl. Fwd) 68
04 Engine - Miscellaneous Engine / Complete Engine
0404 Cylinder Block 82
05 Engine Auxiliary System
0510 Engine Cooling Systems 182
0520 Intake System 190
0530 External Exhaust Systems 194
0540 Engine Mounting 196
0560 External Fuel Supply Systems 198
13 Miscellaneous Vehicle
1322 Labels & Trademarks 210
16 Vehicle Electrical Systems
1671 Batteries, Support & Cables 216
1673 Vehicle Lighting System 218
1674 Wiring Harness & Switches (If Not Included Elsewhere) 232
17 Frame Chassis Or Supporting Structure
1740 Frame Installation 260
18 Operator's Station
1810 Operator Enclosure 266
1821 Seat And Seat Belts 314
1830 Heating & Air Conditioning 330
19 Sheet Metal and Styling
1910 Hood Or Engine Enclosure 348
20 Safety, Convenience and Miscellaneous
2001 Radio 376
2002 Mirror 378
2004 Warning Devices Including Horn & Reverse Alarm 382
2010 Miscellaneous 388
21 Vehicle Main Hydraulic System
2161 Hydraulic Pumps & Drives 392
2162 Hyd Selective Control & Load Holding Valves 416
2164 Hydraulic Reservoir, Filter & Cooler 432
26 Global Vehicle Communication
2601 Communication Controller 442
33 Backhoe & Excavator
3301 Blades & Side Cutters 448
3302 Bucket With Teeth 452
3315 Controls Linkage 474
3340 Backhoe & Excavator Frames 502
3362 Control & Load Holding Valves 528
3363 Lines, Hoses & Fittings 534
3365 Hydraulic Cylinders 632
43 Swing, Rotation Or Pivoting System
4353 Swing Bearing & Mounting 668

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Alphabetical Index

Page

0-05 Engine Gasket Kit ... 86, 88
0-10 Cylinder Head Cover ... 90
0-11 Cylinder Head ... 92, 94
0-12 Cylinder Block ... 96, 98
0-13 Oil Pan And Level Gauge ... 100
0-14 Camshaft And Valve ... 102, 104
0-15 Crankshaft, Piston and Flywheel ... 106
0-20 Timing Gear Case ... 108
0-20 Timing Gear Case and Flywheel Housing ... 110
0-22 Engine Mounting ... 112
0-25 Inlet Manifold ... 114
0-27 Exhaust Manifold ... 116
0-28 Ventilation System ... 118
0-30 Water Pump And Corrosion Resistor ... 120
0-31 Thermostat and Housing ... 122
0-32 Water Piping; Engine ... 124, 126
0-33 Fan and Fan Belt ... 130
0-36 Turbocharger System ... 134
0-40 Fuel Injector System ... 136, 138
0-41 Fuel Filter And Bracket ... 140
0-50 Oil Cooler and Oil Filter ... 142, 144
0-51 Oil Pump And Oil Strainer ... 146
0-52 Oil And Vacuum Piping, Engine ... 148, 150, 152, 154
0-57 Emission Piping ... 156, 158
0-60 Engine Electrical Control Parts ... 160, 162
0-66 Generator ... 180
1-10 Radiator ... 164, 166
1-50 Exhaust Pipe And Silencer ... 168, 170
2-Way Rotary Valve ... 528
8-10 Wiring Harness and Fuse ... 172
8-15 Fixing Parts; Wiring Harness ... 174
8-25 Switch And Relay; Instrument Panel ... 176
8-26 Electrical Control And Other Parts ... 178

A

Accelerator, Throttle Kit, 0-25 Inlet Manifold ... 114
Access Panels ... 374
Adapter, For Esco Ultralok™ (Hammerless) Teeth ... 468
Adapter, Heavy Duty Bucket (24 in) (0.47 yd³) ... 452
Adapter, Heavy Duty Bucket (30 in) (0.64 yd³) ... 454
Adapter, Heavy Duty Bucket (36 in) (0.81 yd³) ... 456
Adapter, Heavy Duty Bucket (42 in) (0.99 yd³) ... 458
Adapter, TK Bucket Tooth System (Hammerless, Horizontal Pin Retention) ... 466
Adapter, TK300 Series Tooth System ... 466
Additional Fuse Box Wiring Harness ... 254
Adjuster, Track Chain ... 58
Air Cleaner ... 190
Air Cleaner Plumbing ... 192
Air Conditioner ... 330
Air Conditioner (A/C) Condenser Components ... 340
Air Conditioner and Heater Duct ... 334
Air Conditioner Bracket ... 330
Air Conditioner Compressor and Condenser Hoses ... 338
Air Conditioner Compressor Components ... 336
AIR CONDITIONER COMPRESSOR HOSE ... 338
Air Conditioner Condenser ... 342, 344
AIR CONDITIONER CONDENSER HOSE ... 338
Air Conditioner Controller ... 330
Air Conditioner Filter ... 330
Air Conditioner Sensor ... 332
Air Conditioner/Heater Filter ... 334
Air Conditioning Compressor ... 342, 344
Air Conditioning Compressor, Condenser, and Sensor ... 344
Air Conditioning Unit Components ... 332
Air Conditioning, Condenser and Compressor ... 342
Air conditioning, Wiring Harness ... 332
Air Duct Solar Sensor ... 334
Air Duct, Air Conditioner/Heater ... 334
Air Filter Restriction Sensor ... 190
AIR FILTER, AIR CONDITIONING UNIT ... 332
Air Flow Tube, Intercooler ... 186
Air Pressure Sender Sensor ... 232
Air Suspension Heated Seat Components ... 316
Air Suspension Seat (Heated) ... 314
Air Temperature Sensor-0-60 ... 160
Alarm, Travel ... 244, 386
Alarm, Travel Switch ... 384
Alternator, 0-60 Engine Electrical Control Parts ... 160, 162
Alternator-0-60 ... 160
Anchor, Tool Box Cover ... 350
Antenna ... 444

Page

Antenna, Antenna, Cab Interior Light, and Secondary Exit ... 282
Antenna, Cab Interior Light, and Secondary Exit ... 282
Antenna, JDLink™ Modular Telematics Gateway and Satellite Module Controller ... 444
Antenna, JDLink™ Modular Telematics Gateway Assembly ... 446
Antenna, JDLink™ Modular Telematics Gateway, 4G LTE ... 442
Antenna, JDLink™ MTG (Cellular) ... 446
Anti-Drift Kit, Boom ... 628
Anti-Drift Valve (Boom) ... 628
Anti-Drift Valve, Control Valve Spools, 5 Spool Side, 1 ... 418
Anti-Drift Valve, Control Valve Spools, 5 Spool Side, 2 ... 420
Arm Auxiliary Lines (High Flow) (3.0 m) ... 608
Arm Auxiliary Lines(High Flow)(2.51 m) ... 606
Arm Cylinder ... 648
Arm Cylinder Components (- 401260) ... 650
Arm Cylinder Components (401261 -) ... 652
ARM CYLINDER OIL LINE (- 401260) ... 650
ARM CYLINDER OIL LINE (401261 -) ... 652
ARM CYLINDER SEAL KIT (- 401260) ... 650
ARM CYLINDER SEAL KIT (401261 -) ... 652
Arm High Flow Auxiliary Lines (2.51m) ... 606
Arm High Flow Auxiliary Lines (3.0 m) ... 608
Arm Lines, 2.51 m ... 602
Arm Lines, 3.01 m ... 604
Arm Link ... 514
Arm Pins And Bushings, 2.51 m ... 504
Arm, 2.51m ... 502
Arm, 3.01m ... 506
Arm, Arm, 2.51m ... 502
Arm, Arm, 3.01m ... 506
ARM, LOCKING; HYDRAULIC COUPLER ... 470
Arm, Rocker Arm Shaft, 0-14 Camshaft And Valve ... 102, 104
Arm, Rocker Arm, 0-14 Camshaft And Valve ... 102, 104
Arm, Windshield Wiper ... 288
Arm, Wiper Arm, Cab Front Window ... 288
Armrest Covers ... 302
Armrest Covers (With Blade) ... 300
Armrest, Cab Console and Armrest ... 290
Armrests ... 290
Ashtray ... 302
Ashtray (With Blade) ... 300
Ashtray, Armrest Covers ... 302
Ashtray, Armrest Covers (With Blade) ... 300
Attaching Pins, Bucket Thumb, Without Coupler (Kits Built 28 June 2010 -) ... 518
Attenuator Lines ... 558
Attenuator Lines, Hydraulic Pump ... 558
Auto Idle Switch ... 240
Auxiliary Audio Interface Wiring Harness ... 388
Auxiliary Audio Wiring Harness ... 388
AUXILIARY CONTROL PILOT CONTROLLER GRIP ... 478
AUXILIARY CONTROL SWITCH ... 258
Auxiliary Foot Control Solenoid Valve Kit (1 Way) ... 624
Auxiliary Function Lever (401188 -) ... 530
Auxiliary Function Lever Wiring Harness And Switches (401188 -) ... 496
Auxiliary Function Levers (401188 -) ... 498
Auxiliary Functional Solenoid Valve Components ... 532
Auxiliary Fuse Box Wiring Harness ... 256
Auxiliary High Flow Control Valve Relief Valves ... 416
Auxiliary Hydraulic Lines on Boom to Cylinders ... 612
Auxiliary Lines On Boom Cylinders ... 612
Auxiliary Lines, Arm (High Flow) (3.0 m) ... 608
Auxiliary Lines, Arm(High Flow)(2.51 m) ... 606
Auxiliary Pilot Control Valve ... 492
Auxiliary Pressure Relief Valves ... 626
Auxiliary Switch Wiring Harness ... 258
Axle, Lower Track Chain Roller ... 64

B


Ball, Swing Bearing ... 686
Bar, Open Center 3 Bar Shoe, Track Chain Assembly ... 60
Bar, Single Bar Shoe, Track Chain Assembly ... 60
Base, Seat ... 326
Battery and Battery Cables ... 216
Battery Cover ... 216
Battery Tester ... 216
Battery, Dry Charged Battery, Battery and Battery Cables ... 216
Beacon ... 228
Beacon Jumper Wiring Harness ... 228
Beacon Switch ... 228
Beacon Wiring Harness ... 228
Bearing, Swing ... 686


PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

17 Digit Product Identification Number

TX1118406 A.1





TX1118406

Key			
1	World Code	1FF	Deere Hitachi
2	Model Identifier	135G	Machine Model
3	Machine Option Code	X	Linkage Configuration X.....Tracked Excavators R.....Military Excavators
4	Check Letter	_	Factory Use Only
5	Year Manufactured Code	C	Code C.....2012 D.....2013
6	Engine Emissions Code	E	Emissions Level E.....iT4 F.....FT4
7	Machine Serial Number	012345	

Engine Emission Level Identification

Engine Model Number	Emissions Level
ISUZU 4JJ1XZSA-03	Interim Tier 4 / Stage III B

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Alphabetical Index - Continued

Page


Shaft, Swing Motor Components ... 680
Shaft, Swing Motor Gearbox Components ... 682
Shaft, Travel Motor Components ... 70
Shaft, Travel Motor Gear Case Components ... 72
Shim Kit, Pilot Pressure Regulating Valve ... 568
Shim, Auxiliary Pilot Control Valve ... 492
Shoe, Flat Shoe, Track Chain Assembly ... 60
Shoe, One Bar Track ... 60
Shoe, Open Center 3 Bar Shoe, Track Chain Assembly ... 60
Shoe, Rubber Track ... 60
Shoe, Single Bar Shoe, Track Chain Assembly ... 60
Shoe, Steel Track ... 60
Shoe, Three Bar Track ... 60
Shoe, Track Chain Assembly ... 60
Shroud, 1-10 Radiator ... 164, 166
Shroud, Cooling Package Hoses ... 184
Shroud, Engine ... 356
Shroud, Fan ... 182
Shroud, Fan, Cooling Package ... 184
Shroud, General Purpose Bucket ... 460
Shroud, Heavy Duty Bucket ... 462
Shroud, Heavy-Duty Bucket, 106.7 cm (42 in), 0.76 m³ (0.99 yd³) ... 458
Shroud, Heavy-Duty Bucket, 60.9 cm (24 in), 0.35 m³ (0.47 yd³) ... 452
Shroud, Heavy-Duty Bucket, 76.2 cm (30 in), 0.49 m³ (0.64 yd³) ... 454
Shroud, Heavy-Duty Bucket, 91.44 cm (36 in), 0.62 m³ (0.81 yd³) ... 456
SHUTOFF LEVER, PILOT ... 474
SHUTOFF VALVE, PILOT, TO PROPEL PILOT VALVE PILOT HYDRAULIC LINES ... 582
Shuttle Valve Pilot Lines (For Use With Blade) ... 596
Shuttle Valve, Blade Signal ... 596
Side Cutter, Heavy Duty Bucket (24 in) (0.47 yd³) ... 452
Side Cutter, Heavy Duty Bucket (30 in) (0.64 yd³) ... 454
Side Cutter, Heavy Duty Bucket (36 in) (0.81 yd³) ... 456
Side Cutter, Heavy Duty Bucket (42 in) (0.99 yd³) ... 458
Side Window Guard Bars ... 278
Sleeve, Control Valve Spools, 5-Spool Side, 1 ... 418
Sleeve, Control Valve Spools, 5-Spool Side, 2 ... 420
Sleeve, Hydraulic Pump Regulator (1) Components, For Use With Blade ... 402
Sleeve, Hydraulic Pump Regulator (2) Components, For Use With Blade ... 406
Sleeve, Hydraulic Pump Regulator 1 Components, For Use Without Blade ... 400
Sleeve, Hydraulic Pump Regulator 2 Components, For Use Without Blade ... 404
Sleeve, Pilot Valve (Front, Swing) ... 476
Sleeve, Solenoid Valve Components, Auxiliary Function ... 532
Sleeve, Solenoid Valve Manifold, Four Spool ... 564
Sleeve, Solenoid Valve Manifold, Two Spool ... 566
Sleeve, Swing Motor Gearbox Components ... 682
Sleeve, Travel Motor Crossover Relief Valve Components ... 74
SMARTLOC™ COUPLER COMPONENTS ... 470
Solar Sensor ... 334
Solenoid Valve ... 500
Solenoid Valve Components, Auxiliary Function ... 532
Solenoid Valve Lines to Hydraulic Pump ... 568
Solenoid Valve Lines to Oil Tank ... 568
Solenoid Valve Manifold, Four Spool ... 564
Solenoid Valve Manifold, Two Spool ... 566
Solenoid Valve Pilot Line To Pilot Shutoff Valve ... 586
SOLENOID VALVE, ELECTRIC, KIT (2 WAY) FOR AUXILIARY FUNCTIONS ... 622
Solenoid Valve, Hydraulic Pump Regulator (1), For Use With Blade ... 402
Solenoid Valve, Hydraulic Pump Regulator (2), For Use With Blade ... 406
Solenoid Valve, Kit (1 Way) ... 624
SOLENOID VALVE, PUMP REGULATOR 1 ... 400
Solenoid, Hydraulic Pump ... 410
Solenoid, Solenoid Valve Components, Auxiliary Function ... 532
Solenoid, Solenoid Valve Manifold, Four Spool ... 564
Solenoid, Solenoid Valve, Auxiliary Function Lever (401188 -) ... 530
Solenoid, Solenoid Valve, Electric Solenoid Valve Kit (2 Way) ... 622
Solenoid, Solenoid Valve, Hydraulic Coupler Kit ... 472
Solenoid, Solenoid Valve, Hydraulic Pump Regulator (1) Components, For Use With Blade ... 402
Solenoid, Solenoid Valve, Hydraulic Pump Regulator 1 Components, For Use Without Blade ... 400
Solenoid, Solenoid Valve, Hydraulic Solenoid Valve Kit ... 410
Solenoid, Solenoid Valve, Solenoid Valve ... 500
Solenoid, Solenoid Valve, Solenoid Valve Components, Auxiliary Function ... 532
Solenoid, Solenoid Valve, Solenoid Valve Manifold, Four Spool ... 564
Solenoid, Solenoid Valve, Solenoid Valve Manifold, Two Spool ... 566
Speaker Wiring Harness ... 284
Speaker, Cab Rear Tray, Air Duct, And Speakers ... 284
Speakers, Radio ... 284
Spindle, Rotary Manifold Components ... 672
Spool Valve, Pilot Signal Manifold ... 696
Spool, Auxiliary Pilot Control Valve ... 492
Spool, Control Valve Bottom ... 424
Spool, Control Valve Spools, 4-Spool Side ... 422
Spool, Control Valve Spools, 5-Spool Side, 1 ... 418
Spool, Control Valve Spools, 5-Spool Side, 2 ... 420
Spool, Control Valve, End Caps, Left ... 428
Spool, End Caps, Control Valve, Left ... 428
Spool, Hydraulic Pump Regulator (1) Components, For Use With Blade ... 402
Spool, Hydraulic Pump Regulator (2) Components, For Use With Blade ... 406
Spool, Hydraulic Pump Regulator 1 Components, For Use Without Blade ... 400
Spool, Hydraulic Pump Regulator 2 Components, For Use Without Blade ... 404
Spool, Pilot Signal Manifold Valves ... 696
Spool, Pilot Valve (Front, Swing) ... 476
Spool, Solenoid Valve Components, Auxiliary Function ... 532
Spool, Solenoid Valve Manifold, Four Spool ... 564
Spool, Solenoid Valve Manifold, Two Spool ... 566
Spool, Spool Valve, Pilot Signal Manifold Valves ... 696
Spool, Travel Motor Brake Valve Components ... 76
Spool, Travel Pilot Control Valve Components ... 486
Spool, Valve Spool, Control Valve End Caps, Left ... 428
Spool, Valve Spool, Control Valve End Caps, Right ... 426
Spool, Valve Spool, Hydraulic Pump Regulator (1) Components, For Use With Blade ... 402
Spool, Valve Spool, Hydraulic Pump Regulator (2) Components, For Use With Blade ... 406
Spool, Valve Spool, Hydraulic Pump Regulator 1 Components, For Use Without Blade ... 400
Spool, Valve Spool, Hydraulic Pump Regulator 2 Components, For Use Without Blade ... 404
Spools, Control Valve (4-Spool Side) ... 422
Spools, Control Valve Bottom ... 424
Spools, Control Valve End Caps, Right ... 426
Spools, Control Valve, 5 Spool Side, 2 ... 420
Spools, Control Valve, 5-Spool Side, 1 ... 418
Spring, Auxiliary Pilot Control Valve ... 492
Springs, Pilot Signal Manifold ... 696
Sprocket, Chain Sprocket, 0-14 Camshaft And Valve ... 102, 104
Sprocket, Chain Sprocket, Travel Motor Gear Case Components ... 72
Sprocket, Idler Sprocket, 0-14 Camshaft And Valve ... 102, 104
Stabilizer, Stabilizer Foot, 0-22 Engine Mounting ... 112
Standard Blade 2490 mm (98 in.) ... 448
Standard Blade 2490 mm (98 in.) Bushings ... 448
Standard Esco Ultralok™ (Hammerless Teeth) ... 468
Starter Switch ... 240
Starter Switch Wiring Harness ... 240
Starter, Starter Motor, 0-60 Engine Electrical Control Parts ... 160, 162
Starter-0-60 ... 160
Starting Motor-0-60 ... 160
Stator, 0-66 Generator ... 180
Steel Track Shoe ... 60
Step, Engine Covers ... 352
Step, Main Frame ... 264
Step, Standard Track Frame ... 50, 264
Step, Standard Undercarriage ... 50, 264
Step, Tool Box ... 350, 364
Step, Track ... 48
Step, Track Frame Secondary Steps ... 52
Step, Track Frame, With Blade ... 50
Step, Track Frame, Without Blade ... 48
Steps, Track Frame, Bolt On ... 52
Stop Switch, Engine ... 248
Stop, Air Suspension Heated Seat Components ... 316
Stop, Arm, 2.51m ... 502
Stop, Arm, 3.01m ... 506
Stop, Boom ... 510
Stop, Boom Pins and Bushings ... 512
Stop, Cab Components (Handrail, Guard Bars) ... 278
Stop, Cab Door Components ... 272
Stop, Cab Window Hardware ... 280
Stop, Cooling and Hydraulic Compartment Doors ... 358
Stop, Direct Hydraulic Thumb Kit, Without Coupler (Kits Built 28 June 2010 -) ... 518
Stop, Engine And Storage Compartment Panels ... 356
Stop, Engine Covers ... 352
Stop, Heavy Duty Bucket ... 516

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Engine Oil Filter and Lines
Filtre à huile moteur et conduites
Filtro de Óleo do Motor e Linhas
Filtro y tuberías de aceite motor

TX1115977 A.1




TX1115977

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

0-32 Water Piping; Engine
0-32 Tuyauterie d'eau; moteur
0-32 Tubulação de Água; Motor
0-32 Tuberías de agua; motor

032A0151400 A.1



032A0151400

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Key	Part No.	Part Name	Qty.	Serial No.	Remarks
47	0911802080	Nut	1		M8 FLANGE
62	0280510250	Bolt	6		M10X25 FLANGE
74	0916147100	Washer	6		ID=10.5 OD=26
93	0280508500	Bolt	3		M8X50 FLANGE
97	8982266410	Spacer	3		SUB FOR 1225590260
104A	8980196451	Bracket	1		
104B	8981710300	Bracket	1		
117	1093370170	Isolator	6		
379	0911802080	Nut	3		M8 FLANGE
406A	8980120093	Shield	1		
522	0286510200	Bolt	2		M10X20 FLANGE
535A	0280510500	Bolt	3		M10X50 FLANGE
535B	0280508450	Bolt	4		M8X45 FLANGE
536A	8973711061	Shroud	1		SUB FOR 8973711060
561A	8973759110	Bracket	3		
562A	8980196461	Bracket	1		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fuel Filter and Filter Lines
Filtre à carburant et conduites de filtre
Filtro de Combustível e Linhas do Filtro
Filtros de combustible y líneas

TX1117298 A.1



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Key	Part No.	Part Name	Qty.	Serial No.	Remarks
0	FYA00001076	Monitor	1		
1	4297188	Travel Warning Alarm	1		
2	4716663	Wiring Harness	1		Monitor
3	7057403	Bracket	1		
5	.....	Screw With Washer	2		J260816 NLA
	19M7162	Cap Screw	2		M8 X 16
	24M7055	Washer	2		8.400 X 16 X 1.600 mm
7	4692542	Clip	2		
8	.....	Screw With Washer	4		J680616 NLA
	21M7577	Socket Head Screw	4		M6 X 16
	12M7006	Lock Washer	4		6 mm
	24M7054	Washer	4		6.400 X 12 X 1.600 mm

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Key	Part No.	Part Name	Qty.	Serial No.	Remarks
0	7059407	Cover	1		
0A	.....	Cover	1		2059238 NLA
0B	7059339	Cover	1		
0C	7059338	Cover	1		
0D	2053523	Cover	1		
1	FYA00003014	Louver	2		
3	7059403	Air Duct	1		
4	7059401	Air Duct	1		
5	4444700	Screw	4		
7	4653906	Mechanical Lighter	1		
8	4447072	Bushing	1		
10	4361302	Speaker	2		
12	4716639	Wiring Harness	1		Speakers
13	4361800	Screw	8		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Seat Stand
Base de siège
Suporte do Assento
Soporte de asiento

TX1115965 C.1




TX1115965

PREVIEW- YOUFIXTHIS.COM

Download full manual at youfixthis.com

Rear View Mirror Components
Composants de rétroviseur
Componentes do Retrovisor
Componentes del espejo retrovisor

TX1174815 A.1




TX1174815

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Hydraulic Pump Regulator (2) Components, For Use With Blade
Régulateur de pompe hydraulique (2), à utiliser avec la lame
Componentes do Regulador da Bomba Hidráulica (2), para Uso com Lâmina
Componentes del regulador de la bomba hidráulica (2), para usar con hoja

TX1205958 A.1



TX1205958

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Key	Part No.	Part Name	Qty.	Serial No.	Remarks
1	.....	Screw With Washer	4		J260830 NLA
	19M7288	Cap Screw	4		M8 X 30, SUB FOR J900830
	24M7055	Washer	4		8.400 X 16 X 1.600 mm, SUB FOR A590108
2	FYA40013754	Bracket	1		ALSO ORDER 4651835, SUB FOR FYA60017543
3	.....	Screw With Washer	1		J271020
	19M7938	Cap Screw	1		M10 X 20, SUB FOR J901020
	24M7346	Washer	1		11 X 20 X 2 mm, SUB FOR J222010
4	AT448479	Wiring Harness	1		Does Not Include Antenna, Order Separately, JDLink™ Harness
5	FYA00021746	Wiring Harness	1		JDLink™ Ultimate (MTG)
6	.....	Screw With Washer	2		J260616 NLA
	19M7560	Cap Screw	2		M6 X 16, J260616 NLA, SUB FOR J900616
	24M7054	Washer	2		6.400 X 12 X 1.600 mm, SUB FOR A590106
7	FF108515	Antenna	1		8.5 ft
8	H77698	Tie Band	2		SUB FOR 4055312
9	H77698	Tie Band	10		SUB FOR 4055312

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Key	Part No.	Part Name	Qty.	Serial No.	Remarks
0	8118208	Valve Cover	1		
0A	.....	Valve Cover	1		NSEP
0B	.....	Spool	4		NSEP
1	4319299	Spacer	4		
2	4662206	Shim	2		0.1 mm (0.003 in), SUB FOR 4203411
3	4368629	Compression Spring	4		
4	4364970	Guide	4		
5	4368630	Compression Spring	4		
6	9226367	Push Nut	4		
6A	3099628	Bushing	1		
6B	4447050	Seal	1		
6C	4201993	O-Ring	1		
6D	4602154	Push Nut	1		
8	.....	Base	1		9184275 NLA
8A	.....	Holder	1		2044332 NSEP
8B	4437433	Bushing	4		
10	19M7576	Screw	2		M10 X 30, SUB FOR J781030
11	12M7066	Lock Washer	2		10 mm, SUB FOR A590910
14	4437432	Gasket	2		
15	4428902	Torsional Damper	2		
16	12M7006	Lock Washer	4		6 mm, SUB FOR A590906
17	J780612	Bolt	4		
21	3098245	Cam	2		
24	4185600	O-Ring	2		
25	4447067	O-Ring	2		
26	9207567	Pin Fastener	1		
26A	4425305	Pin Fastener	1		
26B	3087987	Bracket	1		
26C	4051262	Spring Pin	1		
26D	34M7124	Spring Pin	1		8 X 30 mm, SUB FOR 4205318
26E	4205317	Spring Pin	1		
27	9207568	Pin Fastener	1		
27A	4425305	Pin Fastener	1		
27B	3087987	Bracket	1		
27C	4051262	Spring Pin	1		
27D	34M7124	Spring Pin	1		8 X 30 mm, SUB FOR 4205318
27E	4205317	Spring Pin	1		
28	34M6402	Spring Pin	2		8 X 28 mm, SUB FOR 4027427
29	4213419	Spring Pin	2		
32	8077903	Cover	1		
33	.....	Screw With Washer	2		J260614 NLA
	19M7560	Cap Screw	2		M6 X 16
	24M7054	Washer	2		6.400 X 12 X 1.600 mm
40	4208977	Drain Plug	2		
41	CH11561	Packing	2		SUB FOR Z964255
42	9134109	Drain Plug	2		SUB FOR 4217651
43	CH19111	O-Ring	2		SUB FOR 4113154
48	9773023	Drain Plug	1		
50	FYB60000033	Hyd Actuated Control Valve	1		SUB FOR FYB60000029, Travel Pilot

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Key	Part No.	Part Name	Qty.	Serial No.	Remarks
0	**AT379643**	**Field Installation Kit**	**1**		**Whole Goods**
1	AT386431	Pin	1		
2	.....	Clamp	1		AT386422 NLA
3	AT383236	Hydraulic Cylinder	1		Components On Separate Page, Bolt -On Rod Guide
	AT383237	Seal Kit	1		
4	.....	Bracket	1		AT386511 NLA
5	T229481	Pin	1		
6	AT386510	Link	1		
7	T277102	Pin	2		
8	AT386506	Link	1		
9	AT386507	Link	1		
10	AT339884	Pin	1		
11	T279901	Pin	1		
12	T229499	Thrust Washer	1		
13	T229515	Shim	34		
14	T276673	Spacer	2		
15	.....	Spacer	1		T279932 NLA
16	.....	Stop	1		T279933 NLA
17	JD7759	Lubrication Fitting	4		
18	19H3586	Cap Screw	1		1/2" X 4-1/4"
19	U16721	Lock Nut	1		
20	19H3105	Cap Screw	2		3/4" X 5"
21	14H1058	Nut	3		3/4"
22	19H2826	Cap Screw	3		3/4" X 4-1/2"
23	T229420	Cap	1		
24	T279935	Stop	2		
25	AT386556	Pin	1		
26	T276470	Spring Locking Pin	1		
27	19H2633	Cap Screw	3		3/8" X 1-1/2"
28	12H304	Lock Washer	3		3/8"
29	AT342741	Hydraulic Hose	1		
40	T229333	Bushing	2		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com


Key	Part No.	Part Name	Qty.	Serial No.	Remarks
0	9316550	Solenoid Valve	1		
1	.....	Valve	1		
2	.....	Sleeve	1		
2A	.....	Sleeve	1		
2B	4163873	O-Ring	1		SUB FOR 4484116
2C	R99052	O-Ring	1		SUB FOR 4484118
2D	4185600	O-Ring	1		
3	.....	Spool	1		
4	.....	Washer	1		
5	.....	Plate	1		
6	.....	O-Ring	1		
7	19M7600	Screw	2		M5 X 12, SUB FOR J780512
15A	.....	Housing	1		
15B	9314145	Solenoid Valve	2		
15C	.....	Filter	1		
15D	CH11560	Packing	1		SUB FOR 939356
15E	.....	Ball	1		
15F	.....	Housing	1		
15G	4453196	O-Ring	1		
15H	9761179	Plug	2		

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Arm High Flow Auxiliary Lines (3.0 m)
Conduites auxiliaires à débit élevé de bras (3.0 m)
Linhas Auxiliares de Alta Vazão do Braço (3,0 m)
Tuberías auxiliares de alto caudal del brazo (3,0 m)

TX1117872 B.1




TX1117872

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Arm Cylinder
Cylindre de bras
Cilindro do Braço
Cilindro de brazo

TX1116824 A.1




TX1116824

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Swing Bearing Seal and Mounting Hardware
Joint de roulement de pivotement et boulonnerie de montage
Vedação do Rolamento de Giro e Peças de Montagem
Cojinete de giro, sello y tornillería de montaje

TX1117855 D.2



TX1117855

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 25 of 732 pages

The full manual includes:

- All 732 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

John Deere 135G Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual