INTRODUCTION AND CUSTOMER INFORMATION

T189849A -UN-23APR03



LEFT SIDE VIEW OF JOHN DEERE 350D AND 400D DUMP TRUCK
(MANUFACTURED 2001-)

TO THE CUSTOMER

THE PART NUMBERS IN THIS PARTS CATALOG WERE CORRECT AT THE TIME YOUR CATALOG WAS PUBLISHED. IT IS OUR POLICY TO CONSTANTLY IMPROVE OUR MACHINES AND THEREFORE, PART NUMBERS MAY CHANGE. WHEN ORDERING PARTS, VERIFY PART NUMBERS THROUGH YOUR DEALER.

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.)

PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com
COPYRIGHT © 2004 DEERE & COMPANY Moline, Illinois All rights reserved

ALPHABETICAL INDEX


GRID		PAGE
	A	
2F21	A/C COMPRESSOR	1832 - 2
2F21	A/C COMPRESSOR PULLEY KIT	1832 - 2
2F21	A/C COMPRESSOR SUPPORTS	1832 - 2
2B21	A/C CONTROL SWITCH	1600 - 8
2B19	A/C SWITCH	1600 - 6
2J1	ACCUMULATOR LINES AND HOSES, FRONT CHASSIS	2163 - 2
2I19	ACCUMULATOR,HYDRAULIC OIL MANIFOLD BLOCK	2162 - 2
1K17	ACCUMULATOR,WET DISC BRAKE COMPONENTS	1063 - 2
1K19	ACCUMULATOR,WET DISC BRAKE COMPONENTS	1063 - 4
2E21	ACESS DOOR,HVAC SYSTEM	1813 - 4
2A23	ACTUATOR,PARK BRAKE	1111 - 4
2F23	ADAPTER (AIR CONDITIONER ASSY/HOSES) (SERIAL NO. -XXXXXX)	1832 - 4
2G1	ADAPTER (AIR CONDITIONER ASSY/HOSES) (SN XXXXXX-)	1832 - 6
1H13	ADAPTER (AIR INTAKE SYSTEM)	0521 - 2
1D1	ADAPTER AND WEAR PLATE, TRANSMISSION	0342 - 2
1E9	ADAPTER,TRANSMISSION TO ENGINE	0364 - 10
1B4	ADJUSTER (FRONT AND REAR AXLE DIFFERENTIAL)	0210 - 2
1H15	AIR CLEANER	0521 - 4
2J23	AIR COMPRESSOR	2261 - 2
2J23	AIR COMPRESSOR CONNECTING ROD	2261 - 2
2J23	AIR COMPRESSOR CRANKSHAFT	2261 - 2
2K15	AIR COMPRESSOR HOSE AND LINES	2264 - 2
2K1	AIR COMPRESSOR MOUNTING BRACKET	2261 - 4
2J23	AIR COMPRESSOR REPAIR KIT	2261 - 2
2F23	AIR CONDITIONER ASSEMBLY AND HOSES (SERIAL NO. -XXXXXX)	1832 - 4
2G1	AIR CONDITIONER ASSEMBLY AND HOSES (SN XXXXXX-)	1832 - 6
2G3	AIR CONDITIONER CASING, VALVES AND COILS	1832 - 8
2G5	AIR CONDITIONER HOSES	1832 - 10
2G7	AIR CONDITIONER HOSES AND CONDENSER	1833 - 2
2K17	AIR DRYER	2264 - 4
2K9	AIR DRYER AND RESERVOIR LINES (SN XXXXXX-)	2263 - 4
2F23	AIR DUCTS (AIR CONDITIONER ASSY/HOSES) (SERIAL NO. -XXXXXX)	1832 - 4
2G1	AIR DUCTS (AIR CONDITIONER ASSY/HOSES) (SN XXXXXX-)	1832 - 6
2K13	AIR HORN	2263 - 8
2K11	AIR HOSE, REAR CHASSIS	2263 - 6
1H13	AIR INTAKE SYSTEM	0521 - 2
1H13	AIR RESTRICTION INDICATOR (AIR INTAKE SYSTEM)	0521 - 2
2C5	ALARM, BACK-UP	1673 - 2
2B15	ALARM,BACK UP	1600 - 2
1G15	ALTERNATOR	0423 - 2
1G15	ALTERNATOR BRUSH SET	0423 - 2
1G15	ALTERNATOR FAN	0423 - 2
1G15	ALTERNATOR FAN PULLEY	0423 - 2
1G17	ALTERNATOR SUPPORT AND HARDWARE	0423 - 4
1G15	ALTERNATOR VOLTAGE REGULATOR	0423 - 2
2H7	AM/FM RADIO (SERIAL NO.-200524)	2001 - 2
2H9	AM/FM RADIO (SERIAL NO.200525-)	2001 - 4
2B23	ANGLE, BATTERY HOLD-DOWN	1671 - 2
2C3	ANGLE, EXTRA BATTERY CONPONENT KIT	1671 - 6
2H9	ANTENNA,RADIO (SERIAL NO.200525-)	2001 - 4
1I9	ANTI SKID PAD (FUEL TANK)	0564 - 2
2J17	ANTI-SKID PADS, HYDRAULIC TANK	2164 - 2
1C11	ARM, REAR SUSPENSION	0242 - 16
2E11	ARM, TAILGATE	1741 - 22
2F13	ARM, WINDOW WIPER	1814 - 2
1C13	ARM,FRONT SUSPENSION	0265 - 2
2F17	ARMREST KIT, OPERATOR SEAT	1821 - 4
2F15	ARMREST, PNEUMATIC SEAT	1821 - 2
1C9	ARMS (AXLE TO CHASSIS) (REAR SUSPENSION LINKS)	0242 - 14
2D15	ARTICULATION BUMP STOP PAD (FRONT MAIN FRAME/GUARDS)	1741 - 2
2E5	ARTICULATION JOINT ASSEMBLY	1741 - 16
2G22	ASHTRAY	2000 - 2
1C9	AXLE TO CHASSIS ARMS (REAR SUSPENSION LINKS)	0242 - 14
1C1	AXLE,REAR	0242 - 6
	B	
2B15	BACK UP ALARM	1600 - 2
2C5	BACK-UP ALARM	1673 - 2
2B23	BATTERY	1671 - 2
2J17	BATTERY BOX HARDWARE	2164 - 2
2B23	BATTERY CABLE	1671 - 2
2B23	BATTERY DISCONNECT	1671 - 2
2B23	BATTERY HOLD-DOWN	1671 - 2
2B17	BATTERY MICROPROCESSOR	1600 - 4
2C1	BATTERY, EXTRA	1671 - 4
2I3	BEACON, FLASHING	2004 - 4
1C11	BEAM, WALKING (REAR SUSPENSION)	0242 - 16
1B4	BEARING CAP/CONE/CUP (FRONT AND REAR AXLE DIFFERENTIAL)	0210 - 2
1C5	BEARING CONE AND CUP (350D) (CALIPER, AXLE FINAL DRIVE KIT)	0242 - 10
1B10	BEARING CUP (MID AXLE DIFFERENTIAL (CONTINUED))	0210 - 8
1B8	BEARING CUP/CONE (MID AXLE DIFFERENTIAL)	0210 - 6
1C3	BEARING CUP/CONE (400D) (WDB AXLE FINAL DRIVE KIT)	0242 - 8
1J1	BEARING, GEARS AND TRANSFER CASE OUTPUT SHAFT (REAR)	0851 - 8
1I24	BEARING, GEARS/TRANSFER CASE OUTPUT SHAFT (FRONT)	0851 - 6
1B6	BEARING, ROLLER (FRONT AND REAR AXLE DIFFERETIAL (CONTINUED))	0210 - 4
1G13	BEARING, START MOTOR	0422 - 2
1D3	BEARING, THRUST (TRANSMISSION SHAFT)	0351 - 2
1C13	BEARING,FRONT SUSPENSION	0265 - 2
2E11	BEARING,PIVOT (TAILGATE KIT)	1741 - 22
1F3	BEARINGS (CAMSHAFT), GASKET SET AND CYLINDER BLOCK (CONTINUED)	0404 - 4
1J6	BEARINGS (EMERGENCY STEERING PUMP)	0930 - 2
1E18	BEARINGS (ROD), CRANKSHAFT AND GEAR	0401 - 2
1I20	BEARINGS (TRANSFER CASE INPUT SHAFT)	0851 - 2
1D11	BEARINGS AND GASKETS (TRANS PINION CARRIER P3 W/RETARDER)	0351 - 10
1E18	BEARINGS(MAIN), CRANKSHAFT AND GEAR	0401 - 2
1D5	BEARINGS, THRUST (TRANSMISSION TORQUE CONVERTER)	0351 - 4
1D5	BEARINGS, THRUST (TRANSMISSION TORQUE CONVERTER)	0351 - 4
1D9	BEARINGS, THRUST AND ROLLER (TRANS. PLANET PINION CARRIER P2)	0351 - 8
1D7	BEARINGS, THRUST/ROLLER (TRANSMISSION PLANET PINION CARRIER P1	0351 - 6
1G19	BELT AND TIGHTENER	0429 - 2

PREVIEW. YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER BLOCK, CAMSHAFT BEARINGS AND GASKET SET

T188522 -UN-31MAR03




T188522

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FRONT AND REAR AXLE DIFFERENTIAL

T196345 -UN-14NOV03




T196345

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

HYDRAULIC OIL MANIFOLD BLOCK AND ACCUMULATOR

T197836 -UN-12FEB04




T197836

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CAB DOOR AND HVAC SYSTEM

T196080 -UN-12NOV03




T196080

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FRONT MAIN FRAME AND GUARDS

T144631 -UN-14SEP01



T144631

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

WHEEL RIM AND VALVE STEM

KEY	PART NO.	PART NAME	QTY	SERIAL NO.	350D	400D	REMARKS
1	.....	RIM	1		X	X	
2	U43961	WHEEL RING	1		X	X	(SUB FOR AT253702)
3	R29479	WHEEL RING	1		X	X	
	TT226117	RING	1		X	X	
4	AT255200	FLANGE	2			X	
5	.....	GUARD	1		X	X	
6	T168523	KEY	1		X	X	(SUB FOR T55250, THIS APPLICATION)
7	.....	TIRE	1		X	X	
8	AT252510	CAP	1		X	X	
9	AT252509	TIRE VALVE STEM	1		X	X	
10	AT256194	RIM	1		X		
	AT253547	RIM	1			X	

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

ALPHABETICAL INDEX - CONTINUED

GRID		PAGE
2F15	BELT, SEAT	1821 - 2
1G13	BENDIX DRIVE	0422 - 2
1B4	BEVEL GEAR (FRONT AND REAR AXLE DIFFERENTIAL)	0210 - 2
1B8	BEVEL GEAR (MID AXLE DIFFERENTIAL)	0210 - 6
1H23	BIN BODY EXHAUST PIPE HEAT SHIELD	0531 - 8
1H23	BIN BODY HEATER EXHAUST PIPE	0531 - 8
2C5	BIN COUNTER ROTARY SENSOR	1673 - 2
2C5	BIN DOWN SWITCH	1673 - 2
2E9	BIN DUMP BODY	1741 - 20
1H23	BIN DUMP BODY HEATER KIT	0531 - 8
2E9	BIN DUMP BODY PLATES	1741 - 20
2E9	BIN DUMP BODY REAR LIGHT GUARD	1741 - 20
2E9	BIN DUMP BODY SHIMS	1741 - 20
2E13	BIN PIVOT	1743 - 2
2K3	BIN TIP CONTROL LEVER	2262 - 2
2L2	BIN TIP CYLINDER	3565 - 2
2L2	BIN TIP CYLINDER REPAIR KIT	3565 - 2
2F1	BIN TIP KNOB	1813 - 8
2K3	BIN TIP LEVER DETENT VALVE	2262 - 2
2K3	BIN TIP LEVER DETENT VALVE REPAIR KIT	2262 - 2
2K3	BIN TIP LEVER REPAIR KIT	2262 - 2
2F13	BLADE, WINDOW WIPER	1814 - 2
1I9	BLEED VALVE (FUEL TANK)	0564 - 2
1F1	BLOCK (CYLINDER), CAMSHAFT BEARINGS AND GASKET SET	0404 - 2
1F3	BLOCK (CYLINDER), CAMSHAFT BEARINGS AND GASKET SET (CONTINUED)	0404 - 4
2J15	BLOCK CLAMP, HOSES, REAR CHASSIS HYDRAULIC	2163 - 14
2I23	BLOCK COMPONENTS, HYDRAULIC	2162 - 6
2I19	BLOCK,HYDRAULIC OIL MANIFOLD	2162 - 2
2G3	BLOWER, AIR CONDITIONER	1832 - 8
2E9	BODY,BIN DUMP	1741 - 20
2B23	BOLT, BATTERY HOLD-DOWN	1671 - 2
1G21	BOLT, RING GEAR AND FLYWHEEL	0433 - 1
2C13	BOOT (ELECTRICAL EQUIPMENT AND COLD START)	1674 - 2
2C3	BOOT (RED OR BLACK) EXTRA BATTERY CONPONENT KIT	1671 - 6
1J4	BOOT/GUARD (STEERING COLUMN AND WHEEL)	0911 - 2
1F21	BOWL, SEAL AND FITTING (FUEL PUMP)	0413 - 2
1E3	BOX, TRANSMISSION OIL COOLER	0364 - 4
2C13	BRACKET (ELECTRICAL EQUIPMENT AND COLD START)	1674 - 2
1I1	BRACKET (COLD START HARNESS SUPPORT)	0540 - 2
1J4	BRACKET (STEERING COLUMN AND WHEEL)	0911 - 2
1E11	BRACKET (TRANS. SPEED SENSOR WIRING HARNESS)	0374 - 2
2K1	BRACKET, AIR COMPRESSOR MOUNTING	2261 - 4
2K9	BRACKET, AIR DRYER/RESERVOIR LINES (SN XXXXXX-)	2263 - 4
1H7	BRACKET, FAN GUARD MOUNTING	0511 - 2
2G22	BRACKET, FIRE EXTINGUISHER	2000 - 2
2G14	BRACKET, HOOD	1911 - 6
2G16	BRACKET, HYDRAULIC MANIFOLD PLATES AND HARDWARE	1913 - 2
2E15	BRACKET, REAR VERTICAL (UNDER PLATE)	1746 - 2
2G5	BRACKET, RECEIVER-DRIER AIR CONDITIONER	1832 - 10
2I7	BRACKET, STEERING VALVE	2160 - 2
1F19	BRACKET,EXHAUST VALVE BRAKE MANIFOLD (SER.NO.200665-)	0410 - 6
2H23	BRACKET,FIRE EXTINGUSHER	2003 - 2
2G12	BRACKET,HOOD LATCH	1911 - 4
1D24	BRACKET,TRANSMISSION OIL COOLER FAN (SER.NO.-200714)	0364 - 2
1E1	BRACKET,TRANSMISSION OIL COOLER FAN (SER.NO.200715-)	0364 - 3A
1H17	BRACKETS (ENGINE EXHAUST ASSEMBLY)	0531 - 2
1D13	BRACKETS (TRANS. PLANET PINION CARRIER (P3) W/RETARDER) (CONTINUED)	0351 - 12
2E7	BRACKETS AND COVER (REAR FRAME ASSY)	1741 - 18
1I1	BRACKETS AND GUARD (ENGINE AND MOUNTING PARTS)	0540 - 2
2D15	BRACKETS AND SUPPORTS (FRONT MAIN FRAME/GUARDS)	1741 - 2
1H7	BRACKETS, PLATES AND GUARDS (RADIATOR, FAN SHROUD AND HOSES)	0511 - 2
2D19	BRACKETS, REAR FRAME	1741 - 6
1H19	BRACKETS,EXHAUST SHIELD (SER.NO.-200714)	0531 - 4
1H21	BRACKETS,EXHAUST SHIELD (SER.NO.200715-)	0531 - 6
2H21	BRACKETS,REAR VIEW MIRRORS (SERIAL NO.200705-)	2002 - 12
2A21	BRAKE (PARK BRAKE MOUNTING)	1111 - 2
1K1	BRAKE ASSEMBLIES,FRONT AXLE WET DISC	1011 - 14
1K3	BRAKE ASSEMBLY,MID AXLE WET DISC	1011 - 16
2A23	BRAKE ASSEMBLY,PARK	1111 - 4
1K7	BRAKE DISC,SERVICE BRAKE CALIPER(350D) (WITH DRY DISC BRAKE)(SER.NO.-200465)	1011 - 20
2A21	BRAKE DISK (PARK BRAKE MOUNTING)	1111 - 2
2I9	BRAKE HOSES	2160 - 4
1K21	BRAKE HOSES,WET DISC	1063 - 6
2D19	BRAKE LINE GUARD BRACKETS AND PLATE (REAR FRAME CLAMPS AND HARDWARE)	1741 - 6
1K1	BRAKE LINE GUARDS,FRONT AXLE WET DISC	1011 - 14
1K1	BRAKE LINES,FRONT AXLE WET DISC BRAKE	1011 - 14
1K3	BRAKE LINES,MID AXLE WET DISC BRAKE	1011 - 16
1K21	BRAKE LINES,WER DISC	1063 - 6
1C7	BRAKE PIPES (REAR) (350D)	0242 - 12
2I9	BRAKE VALVE	2160 - 4
2I9	BRAKE VALVE PEDAL	2160 - 4
2I9	BRAKE VALVE SEAL KIT	2160 - 4
2B15	BREAKER,CIRCUIT	1600 - 2
1E7	BREATHER CAP,TRANSMISSION (WITH RETARDER)	0364 - 8
1C7	BREATHER, RESERVOIR (350D)	0242 - 12
1I16	BREATHER,TRANSFER DRIVE GEAR CASE	0841 - 2
1G13	BRUSH SET, STARTER AND SOLENOID SWITCH	0422 - 2
1G15	BRUSH SET,ALTERNATOR	0423 - 2
2B19	BULB,INSTRUMENT PANEL SWITCH	1600 - 6
1D17	BUSHINGS, RING AND SEAL (TRANSMISSION FRONT SUPPORT HOUSING)	0361 - 2
1F17	BUTTERFLY (EXHAUST)	0410 - 4

C


2B21	CAB AIR RECIRCULATION SWITCH	1600 - 8
2F11	CAB BOTTOM SEALS	1813 - 18
2D21	CAB CLAMPS AND HARDWARE	1741 - 8
2E23	CAB DOOR	1813 - 6
2E23	CAB DOOR CYLINDER	1813 - 6
2E23	CAB DOOR HINGE	1813 - 6
2E23	CAB DOOR INTERIOR PANEL	1813 - 6
2F1	CAB DOOR LATCH	1813 - 8
2E23	CAB DOOR WINDOW PANE	1813 - 6
2E23	CAB DOOR WINDOW RETAINER	1813 - 6

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

MACHINE DRIVE SHAFTS

T144495 -UN-29AUG01



KEY	PART NO.	PART NAME	QTY	AXLE SERIAL NO.	340 500 DD	REMARKS
23	TT207352	COUPLING	1		X X	HYDRAULIC PUMP DRIVE SHAFT
24	TT207364	COUPLING	1		X X	HYDRAULIC PUMP DRIVE SHAFT
25	TT290396	SHAFT	1		X X	HYDRAULIC PUMP DRIVE, (SUB FOR TT290142)
26	TT290396	SHAFT	1		X X	FRONT (TRANSMISSION TO TRANSFER DRIVE) (SUB FOR TT290142 AND TT290143)
27	TT290261	SHAFT	2		X X	(FRONT AND REAR WHEEL DRIVE)
29	TT290262	SHAFT	1		X X	(MID REAR)
30	TT290263	SHAFT	1		X X	(REAR)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FRONT AXLE SUSPENSION STRUT CYLINDER
(SERIAL NO.200760-)


KEY	PART NO.	PART NAME	QTY	AXLE SERIAL NO.	345 00 DD	REMARKS
1	19M8017	CAP SCREW	2		X X	M12 X 20
2	AT253501	GUARD	1		X X	
3	AT258675	CAP	1		X X	
4	AT46202	HYD ACTUATED CONTROL VALVE	1		X X	
5	R394R	O-RING	1		X X	
6	TT186335	BRACKET	1		X X	
7	TT207676	PIPE PLUG	1		X X	
8	H170536	NUT	1		X X	
9	AT253363	HYDR. CYLINDER ROD GUIDE	1		X X	
10	T20779	RING	1		X X	FURNISH AT253315
11	.....	SEAL	1		X X	(FURNISH AT253315
12	CE14618	O-RING	1		X X	(FURNISH AT253315)
13	.....	GUIDE	1		X X	(FURNISH AT253315)
14	TT161939	PISTON	1		X X	
15	24M7429	WASHER	6		X X	13 X 24 X 2.500 MM
16	19M8341	SCREW	8		X X	M12 X 45
17	AT253522	BARREL	1		X X	
18	AT258668	FITTING PLUG	1		X X	
19	AT253731	BUSHING	2		X X	
20	AT253774	LABEL	1		X X	
21	.....	SEAL	1		X X	(FURNISH AT253315)
22	.....	SEAL	1		X X	(FURNISH AT253315)
23	.....	SEAL	1		X X	(FURNISH AT253315)
24	AT253567	CLAMP	1		X X	
25	AT253680	BOOT	1		X X	
26	AT253566	CLAMP	1		X X	
27	TT221630	BALL	1		X X	
28	TT182574	ROD	1		X X	
29	AT253315	SEAL KIT	1		X X	
30	TT230242	ABSORBER	1		X X	STRUT R.H.
	TT230244	ABSORBER	1		X X	STRUT L.H.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

TRANSMISSION OIL COOLER FAN AND FAN BRACKET
(SERIAL NO.200715-)

T201628 -UN-12JUL04




T201628

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CYLINDER HEAD AND VALVES

T144553 -UN-09OCT01



T144553

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

STARTER, SOLENOID SWITCH AND BRUSH SET

KEY	PART NO.	PART NAME	QTY	STARTER SERIAL NO.	345 00 DD	REMARKS
5	TTDC221712	STARTER MOTOR	1		X X	
11	TTDC221713	STARTER MOTOR DRIVE	1		X X	
17	TTDC150166	NEEDLE BEARING	1		X X	
26	TTDC150167	NEEDLE BEARING	1		X X	
35	AT255765	BUSHING	1		X X	
38	TTDC260094	BRUSH SET	1		X X	BRUSH
41	TTDC221714	SPRING	4		X X	
56	TTDC221715	SWITCH	1		X X	
59	TTDC221716	SOLENOID	1		X X	
77	TTDC100660	NUT	3		X X	

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

BIN DUMP BODY HEATER KIT


KEY	PART NO.	PART NAME	QTY	SERIAL NO.	350D	400D	REMARKS
1	A31869	LOCK NUT	5		X	X	
2	24M7054	WASHER	4		X	X	6.400 X 12 X 1.600 MM
3	24M7132	WASHER	3		X	X	8.400 X 18 X 1.500 MM
4	24M7433	WASHER	12		X	X	10.500 X 20 X 2 MM
5	TT207826	PIPE	1		X	X	
6	19M7662	CAP SCREW	4		X	X	M10 X 30
7	24M7429	WASHER	4		X	X	13 X 24 X 2.500 MM
8	19M8043	CAP SCREW	5		X	X	M16 X 140
9	19M8166	CAP SCREW	9		X	X	M10 X 110
10	TT100655	NUT	4		X	X	
11	TT207386	SHIELD	1		X	X	HEAT
12	19M7387	CAP SCREW	4		X	X	M12 X 40
13	14M7274	NUT	9		X	X	M10
14	A51212	LOCK NUT	30		X	X	
15	AN273958	CLAMP	1		X	X	
16	19M8425	CAP SCREW	4		X	X	M6 X 16
17	19M7407	CAP SCREW	3		X	X	M8 X 25
18	19M8118	CAP SCREW	2		X	X	M10 X 35
19	TT140622	SEAL	6		X	X	
20	AT256159	SPRING WASHER	18		X	X	
21	AT252430	FLANGE	3	-200597	X	X	
	TT208099	FLANGE	3	200598-	X	X	
22	TT176142	SUPPORT	1		X	X	TOP
23	TT176143	SUPPORT	1		X	X	
24	TT176144	SUPPORT	1	-200597	X	X	
	TT176785	PLATE	1	200598-	X	X	
25	TT176179	CLAMP	2		X	X	RH
26	TT176180	CLAMP	2		X	X	LH
27	TT176346	SHIM	4		X	X	
28	TT176352	GUARD	1		X	X	
29	TT183410	SUPPORT	1		X	X	
30	TT183413	SUPPORT	1		X	X	
31	AT147401	CLAMP	3		X	X	
32	AT252560	SPRING	9		X	X	
33	TT218449	CLAMP	5		X	X	(SUB FOR AT252689, THIS APPLICATION)
34	TT207198	PIPE	1		X	X	
35	TT207214	ISOLATOR	2		X	X	
36	TT207215	EXHAUST PIPE	1		X	X	
37	TT207226	BRACKET	1	-200597	X	X	
	TT208095	BRACKET	1	200598-	X	X	
38	TT207228	PIPE	1	-200597	X	X	
	TT208097	PIPE	1	200598-	X	X	
39	TT207229	ADAPTER	3		X	X	
40	TT207233	PIPE	1	-200597	X	X	
	TT208096	PIPE	1	200598-	X	X	
41	TT207296	SPRING	5		X	X	
42	TT207386	SHIELD	1		X	X	HEAT
43	TT208097	PIPE	1		X	X	
44	**AT308945**	**KIT**	**1**		**X**	**X**	**WHOLE GOODS (BIN HEATER KIT) (SUB FOR AT195304 AND TT260772)**
45	19M7638	CAP SCREW	6		X	X	M10 X 130

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

EMERGENCY STEERING PUMP

T144598 -UN-06SEP01




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

R.H FRONT AND L.H MID AXLE WET DISC BRAKE HOUSING AND COVER(400D)
OPTIONAL R.H.FRONT AND L.H.MID AXLE WET DISC BRAKE HOUSING AND COVER(350D)

T144602 -UN-30AUG01



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

DECALS AND LABELS (350D) (CONTINUED)

KEY	PART NO.	PART NAME	QTY	SERIAL NO.	350D	400D	REMARKS
23	TT207191	LABEL	1		X		OVERHEAD POWERLINE
24	TT207192	SAFETY SIGN	1		X		SEATBELT WARNING
25	TT207277	LABEL	1		X		PARK BRAKE APPLICATION
27	TT207335	LABEL	1		X		SPEED DOWN SLOPE
28	TT207339	LABEL	1		X		SEAT INSTRUCTIONS
29	TT207381	LABEL	1		X		REFRIGERANT
30	TT207385	LABEL	1		X		SHIFT INHIBITING
31	TT207394	LABEL	1	-200535	X		FUSE & RELAY LAYOUT
	TT208939	LABEL	1	200536-	X		FUSE AND RELAY LAYOUT
32	TT207409	LABEL	1		X		BIN TIP
33	TT207411	LABEL	1		X		EMERGENCY EXIT
34	TT207412	LABEL	1		X		PARK BRAKE
35	TT207415	LABEL	1		X		ROPS/FOPS
37	TT207334	LABEL	1		X		TIRE PRESSURE
38	TT207336	LABEL	2		X		ARTICULATION CRUSH
39	TT207434	LABEL	1		X		INSTRUMENT CLUSTER
41	JD5920	REFLECTOR	2		X		RED, (SUB FOR JD5924)
42	TT207304	LABEL	2		X		TIE-DOWN POINT
43	TT207310	LABEL	2		X		LIFTING EYE
45	TT207337	LABEL	3		X		VISIBILITY WARNING
46	TT207338	SAFETY SIGN	1		X		PARK BRAKE WARNING
47	TT207350	LABEL	1		X		SPRING PRESSURE
48	TT207351	LABEL	2		X		BIN SUPPORT
49	TT207668	LABEL	5		X		HOOD (NON ILLUSTRATED)
50	TT207669	LABEL	5		X		DEERE LOGO (LEAPING) (NON ILLUSTRATED)
51	TT207669	LABEL	1		X		LEAPING DEERE

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CAB TRANSMISSION WIRING HARNESS


KEY	PART NO.	PART NAME	QTY	SERIAL NO.	350D	400D	REMARKS
2	AT260816	ELECTRONIC CONTROL UNIT	1		X	X	GEAR SELECTOR, (SUB FOR AT256796)
10	TT208233	MODULE	1		X	X	TCU, 6 SPEED, (SUB FOR TT207168)
12	.....	WASHER	1		X	X	
13	TT207053	MULTI-FUNCTIONAL CONTROLLER	1		X	X	RETARDER
17	TT207025	WIRING HARNESS	1	-200947	X	X	TRANSMISSION
	TT218734	CAB WIRING HARNESS	1	200948-	X		TRANSMISSION
	TT207025	WIRING HARNESS	1	-200957		X	TRANSMISSION
	TT218734	CAB WIRING HARNESS	1	200958-		X	TRANSMISSION
23	TT206783	RESISTOR	1		X	X	(1K OHM, 0.5WATT)
43	TT176093	FRAME	1		X	X	TRANSMISSION CONTROL SUPPORT
51	19M7160	CAP SCREW	3		X	X	M6 X 30
59	14M7528	LOCK NUT	17		X	X	M6
65	19M8425	CAP SCREW	11		X	X	M6 X 16
68	24M7054	WASHER	31		X	X	6.400 X 12 X 1.600 MM

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

OSCILLATION FRAME

T144637 -UN-06SEP01




T144637

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CAB BOTTOM SEALS

T145876 -UN-09OCT01



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

HYDRAULIC MANIFOLD PLATES AND HARDWARE

KEY	PART NO.	PART NAME	QTY	SERIAL NO.	345 00 DD	REMARKS
1	24M7338	WASHER	8		X X	17 X 30 X 3 MM
2	TT176429	PLATE	1		X X	REAR (RH) (SUB FOR TT207789)
3	TT207790	PLATE	1		X X	REAR (LH)
4	24M7433	WASHER	6		X X	10.500 X 20 X 2 MM
9	19M7662	CAP SCREW	1		X X	M10 X 30
10	19M7759	CAP SCREW	8		X X	M16 X 60
18	14M7327	LOCK NUT	14		X X	M8
19	14M7328	LOCK NUT	12		X X	M16
29	19M7407	CAP SCREW	15		X X	M8 X 25
34	AT258477	WASHER	16		X X	
90	TT174774	BRACKET	1		X X	
96	TT176086	COVER	1		X X	

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

FIRE EXTINGUISHER


KEY	PART NO.	PART NAME	QTY	SERIAL NO.	350D 400D	REMARKS
1	AT189487	FIRE EXTINGUISHER	1		X X	
2	19M7502	CAP SCREW	2		X X	M5 X 25
3	AT189390	BRACKET	1		X X	
4	14M7297	NUT	2		X X	M5

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

CASE DRAIN AND RETURN HYDRAULIC LINES AND HOSES

T197838 -UN-17FEB04




T197838

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

AIR COMPRESSOR HOSE AND LINES

T144716 -UN-26SEP01



PREVIEW IT YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 25 of 509 pages

The full manual includes:

- All 509 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

John Deere 350D, 400D Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual