
Boom Wiring Harness
Faisceau de câbles de flèche
Grupo de cables de aguilón

TX1127191 B.1




TX1127191

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Engine Block
Bloc de moteur
Bloque de motor

TX1128211 F.1




TX1128211

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Hydraulic Pump
Pompe hydraulique
Bomba hidráulica

TX1127861 A.1




TX1127861

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Cab
Cabine
Cabina

TX1126212 C.1




TX1126212

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Track Frame Covers
Protections de bâti de chenille
Cubiertas de bastidor de cadena

TX1127612 A.1




TX1127612

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Standard Arm, 1.38 m
Bras standard, 1,38 m
Brazo estándar de 1,38 m

TX1127548 A.1




PREVIEW - YOUFIXTHIS.COM

TX1127548

Download full manual at youfixthis.com

Machine Wiring Harness
Faisceau de câblage de machine
Grupo de cables de la máquina

TX1127226 B.1




PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Timing Gear Cover
Carter de distribution
Cubierta de engranajes de distribución

TX1128216 A.1




TX1128216

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Hydraulic Pump Components
Composants de pompe hydraulique
Componentes de bomba hidráulica

TX1127200 B.1




TX1127200

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Cab Components, Right Side Window
Composants de cabine, vitre droite
Componentes de la cabina, ventana derecha

TX1128448 C.1



1 — 2,3,4,5,6,7,8


TX1128448

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Front Idler
Oisif de avant
Engranaje delantero

TX1127634 A.1




TX1127634

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Boom 2.85 m
Flèche 2,85 m
Aguilón de 2,85 m

TX1127588 B.1




TX1127588

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Cab Wiring Harness
Faisceau de cabine
Grupo de cables de cabina

TX1127239 A.1




PREVIEW YOUFIXTHIS.COM

Download full manual at youfixthis.com

Flywheel Housing and Oil Pan
Logement du volant moteur et carter d'huile
Alojamiento de volante y cárter de aceite

TX1128218 A.1




TX1128218

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Oil Cooler Lines and Fittings
Refroidisseur d'huile et conduites
Refrigerador de aceite y tuberías

TX1127920 C.1




TX1127920

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Cab Components, Cab Lights, Antenna, and Hardware
Composants de cabine, éclairage de cabine, antenne et boulonnerie
Componentes de cabina, luces de cabina, antena y tornillería

TX1150187 E.1




TX1150187

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Track Frame Lower Roller
Galet inférieur de bâti de chenille
Rodillo inferior de bastidor de cadena

TX1127607 B.1




TX1127607

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Boom Pins and Bushings
Axes et bagues de flèche
Bujes y pasadores de aguilón

TX1127535 A.1



TX1127535

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Table of Contents

01 Wheels & Tires & Tracks
0110 Powered Wheels, Tires, and Fastenings 40
0130 Track Systems 50
02 Axles, Differentials & Suspension Systems
0260 Axles, Diff. & Susp. Sys. Hyd. (Incl. Fwd) 66
04 Engine
0400 ENGINE 80
05 Engine Auxiliary System
0505 Cold Weather Starting Aids 120
0510 Engine Cooling Systems 122
0520 Intake System 124
0530 External Exhaust Systems 130
0540 Engine Mounting 138
0560 External Fuel Supply Systems 144
13 Miscellaneous Vehicle
1322 Labels & Trademarks 152
16 Vehicle Electrical Systems
1674 Wiring Harness & Switches 158
17 Frame Chassis Or Supporting Structure
1740 Frame Installation 172
18 Operator's Station
1810 Operator Enclosure 182
1811 ROPS, FOPS, OPS, Or Body Frame 232
1821 Seat And Seat Belts 244
1830 Heating & Air Conditioning 252
19 Sheet Metal & Styling
1910 Hood Or Engine Enclosure 274
20 Safety, Convenience & Miscellaneous 11192
2001 Radio 11192 306
21 Vehicle Main Hydraulic System
2121 Hyd Pumps & Drives 308
2163 Hyd Lines & Hoses 312
2164 Hyd Reservoir, Filter & Cooler 314
33 Backhoe & Excavator
3301 Blades & Side Cutters 320
3302 Bucket With Teeth 330
3315 Controls Linkage 374
3340 Backhoe & Excavator Frames 408
3344 Boom 416
3345 Bucket Linkage 420
3362 Control & Load Holding Valves 426
3363 Lines, Hoses & Fittings 472
3365 Hydraulic Cylinders 522
43 Swing, Rotation Or Pivoting System
4360 Hydraulics 550

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Alphabetical Index

Page

A

Accelerator, Throttle Kit, Intake Manifold 90
Accumulator 406
Accumulator, Hydraulic Accumulator, Accumulator 406
ACCUMULATOR, STEERING 406
Adapter Kit, Hammer 368
Adapter, Control Valve Lines 520
Adapter, Excavator Breaker Mount (Series Ii) 334
Adapter, Interface (Pa15 And Pa30 Auger) 332
Adapter, TF Tooth, Heavy Duty Bucket (12", 2.1 Cu Ft) 340
Adapter, TF Tooth, Heavy Duty Bucket (18", 3.6 Cu Ft) 348
Adapter, TF Tooth, Heavy Duty Bucket (24", 5.2 Cu Ft) 352
Adapter, TF Tooth, Heavy Duty Bucket (30", 6.8 Cu Ft) 356
Adapter, TK Tooth, Heavy Duty Bucket (12", 2.1 Cu Ft) 344
Adapter, TK Tooth, Heavy Duty Bucket (18", 3.6 Cu Ft) 350
Adapter, TK Tooth, Heavy Duty Bucket (24", 5.2 Cu Ft) 354
Adapter, TK Tooth, Heavy Duty Bucket (30", 6.8 Cu Ft) 358
Adapter, TK Tooth, Heavy Duty Bucket (36", 8.3 Cu Ft) 360
Additional Canopy Light 236
Additional Counterweight 180
Adjuster, Track, Rubber 56
Adjuster, Track, Steel 58
Air Cleaner 124
Air Cleaner Bracket 128
Air Cleaner Hose 126, 128
Air Cleaner Piping 126
Air Cleaner Support 128
Air Cleaner, Support 128
Air Conditioner 252
Air Conditioner Components 258
Air Conditioner Compressor Wiring Harness 258
Air Conditioner Condenser (- 280686) 254
Air Conditioner Condenser and Compressor (280687 -) 256
Air Conditioner Condenser Wiring Harness (- 280686) 254
Air Conditioner Condenser Wiring Harness (280687 -) 256
Air Conditioner Controller 252
Air Conditioner Cooler (- 280686) 254
Air Conditioner Cooler (280687 -) 256
AIR CONDITIONER DUCT 262
AIR CONDITIONER DUCT INTERIOR COVER 262
AIR CONDITIONER LINES AND SOLENOID 260
Air Conditioner Relays 252
Air Conditioner Solenoid and Lines 260
Air Conditioner System 252
Air Conditioner, Wiring Harness 252
Air Filter, Heater 266
Air Restriction Indicator 124
Alarm, Hydraulic Coupler Kit 364
Alarm, Travel 302
ALARM, TRAVEL WARNING 158
Alternator 114
Alternator Fan Belt 102
Alternator Mounting 114
Alternator, Alternator 114
Alternator, Diesel Engine 80
ANGLE BLADE 322
Angle Blade Frame 324
Angle Kit, Rotary Manifold, Power Angle Blade 562
Antenna Wiring Harness 206
Antenna, Cab 206
Antenna, Cab Components, Cab Lights, Antenna, and Hardware 206
Arm Cylinder 522
Arm Cylinder Components 524
Arm Rest 398
Arm Section 444
Arm Section, Control Valve, Power Angle Blade 468
Arm Section, Main Control Valve 428
Arm, Long (1.69m) 412
Arm, Long Arm, 1.69 m 412
Arm, Long Assembly (1.69m) 414
Arm, Rocker 88
Arm, Rocker Arm Shaft, Cylinder Head, Rocker Arms, and Valves 88
Arm, Rocker Arm, Cylinder Head, Rocker Arms, and Valves 88
Arm, Standard (1.38m) 408
Arm, Standard Arm, 1.38 m 408
Arm, Standard Assembly (1.38 m) 410
Arm, Wiper Arm, Cab Components, Windshield 216
Armature, Starter 112
Armrest, Arm Rest 398
Armrest, Right Console 394
Attachment Pedal Hose And Fittings 380
Auto Idle 170
Auto Idle Switch 252
Auto-Shutdown 170
Auxiliary Boom Lines 482
Auxiliary Function Control Levers 390
Auxiliary Function Lever Label 390
Auxiliary Lines, Boom 476
Auxiliary Pilot Control Valve Components 378
Auxiliary Section 448
Auxiliary Section 2, Control Valve (Power Angle Blade) 470
Auxiliary Section, Control Valve, Power Angle Blade 468
Auxiliary Section, Main Control Valve 428

B

Bar, Quick Coupler 420
Bar, Triple Bar Shoe, Track Chain Assembly, Rubber Pad Shoe 64
BARREL, BUCKET CLAMP CYLINDER 546
Barrel, Track Adjuster, Rubber 56
Barrel, Track Adjuster, Steel 58
Base Isolator 296
Battery 166
Battery and Cable 166
Battery Compartment 302
Battery, Dry Charged Battery, Battery and Cable 166
Bearing Kit, Cylinder Block 82
Bearing, Camshaft 96
Bearing, Swing 564
Bearings, Main 82
Belt, Air Conditioner (- 280686) 254
Belt, Air Conditioner (280687 -) 256
Belt, Engine Fan 102
Belt, Retractable Seat 250
Belt, Rubber Track Belt, Rubber Crawler Pad 46
Belt, Seat Belt, Retractable Seat Belt 250
Bezel, Additional Canopy Light 236
Bezel, Boom Wiring Harness 158
Bezel, Cab Components, Cab Lights, Antenna, and Hardware 206
Bezel, Cab Light 218
Bezel, Canopy Light 234
BLADE ANGLE AUXILIARY SPOOL SECTION, MAIN CONTROL VALVE 470
BLADE ANGLE CYLINDER COMPONENTS (- 281169) 542
Blade Angle Cylinder Components (281170 -) 544
BLADE ANGLE CYLINDER GUARD 322
Blade Angle Cylinder Seal Kit (281170 -) 544
Blade Angle Hydraulic Cylinder Components (- 281169) 542
Blade Control Lever And Hoses 404
Blade Control Lever and Lines 404
Blade Cutting Edge 326
Blade Cylinder Cover 328
Blade Cylinder Hoses 328
Blade Grease Fitting 320
Blade Lever (Power Angle Blade) 382
Blade Lift Cylinder 526
Blade Lift Cylinder Components 528
Blade Mounting 328
Blade Pilot Control Valve Components 378
Blade Section 436
Blade Section, Control Valve, Power Angle Blade 468
Blade Section, Main Control Valve 428
Blade, Blade Lift Cylinder Components 528
BLADE, POWER ANGLE 322
Blade, Power Angle Blade 322
Blade, Power Angle, Control Valve 464
Blade, Power Angle; Frame 324
Blade, Standard 320
Blade, Standard Blade 320
Blade, Window Wiper 216
Blade, Wiper Blade, Cab Components, Windshield 216
Block Heater, Engine 120
Block, Cylinder, Kit, Swing Motor 554
Block, Engine Cylinder 82
Blower Motor 264
Blower Motor Port Changer 258, 264
Blower, Air Conditioner 258
Blower, Air Conditioner Components 258
Blower, Fan, Water Pump 102
Blower, Heater 258, 264
Blower, Heater Components 264
Body, Valve, Rotary Valve 460, 462

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

To The Customer

The part numbers in this Parts Catalog were correct at the time of publication. Per John Deere policy, we continuously improve our products. Therefore, when ordering parts verify the part numbers with your dealer.

SI Units of Measure

Metric dimensions are provided as applicable throughout this parts catalog.

Bolt and Cap Screw Strength Identification

Bolts and cap screws required to have high-strength qualities equivalent to metric property class 10.9 (SAE grade 8) or higher are identified throughout this catalog by the description 10.9, 12.9 or 14.9. All standard bolts and cap screws are metric property class 8.8 (SAE grade 5) or lower.

Serial Number Listing Information

Serial number information is listed to show on which machines each part can be used; for example:

	–		**The part can be used on all products.**
000000	–		**The part can be used on products beginning with the serial number listed.**
	–	**000000**	**The part can be used on products up to and including the serial number listed.**
000000	–	**000000**	**The part can be used on products between and including the serial number listed.**

When XXXXXX's are listed in place of a serial number, a serial number change was made, but the exact serial number was not available at the time of publication.

Direction Arrow

Arrows are used with illustrations to indicate the front of the unit. “Right-Hand” and “Left-Hand” sides are determined by facing in direction of machine forward travel.

Box-Enclosed Illustrations

Box-enclosed keyed parts in the illustration are available as a service assembly or an attachment. These parts may also include parts not available for service. The illustrations may not show all individual parts of an attachment. A box not keyed includes non-current parts.

Complete Goods Listings

Complete Goods are listed in bold face type. Order separately. Do not include on replacement part order.

Orientation of Engine

Right Hand (RH) and Left Hand (LH) sides are determined by standing at flywheel and facing the engine.

John Deere Remanufactured Components


The REMAN parts listed in this catalog are intended for the repair or replacement of failed or worn original equipment components. John Deere Reman components are manufactured to stringent John Deere standards and produced to original John Deere specifications that incorporates the latest design and performance improvement updates.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

17 Digit Product Identification Number

TX1129385 A.1



TX1129385

Key			
1	World Code	1FF	John Deere
2	Model Identifier	50G	Machine Model
3	Machine Option Code	X	Linkage Configuration X.....Tracked Excavators R.....Military Excavators
4	Check Letter	A	Factory Use Only
5	Year Manufactured Code	A	Code C.....2012 D.....2013
6	Engine Emissions Code	H	Emissions Level G.....iT4/Stage III A (19–56 kW) H.....FT4 / Stage III A (19–37 kW)
7	Machine Serial Number	012345	

Engine Emission Level Identification


Engine Model Number	Emissions Level
4TNV88C	FT4 / Stage III A (19–37 kW)

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Start Switch
Contacteur de démarrage
Interruptor de arranque

TX1126154 A.1



PREVIEW - YOUFIXTHIS.COM

TX1126154

Download full manual at youfixthis.com

Key	Part No.	Part Name	Qty.	Serial No.	Remarks
0	4689750	Solenoid Valve	1		Auxiliary Control Function, Components On Separate Page
1	A852122	Adapter Fitting	2		INCLUDES 957366
	957366	O-Ring	1		
2	4653765	Filter	1		
3	A852423	Tee Fitting	1		INCLUDES 957366
	957366	O-Ring	1		
4	4667624	Structural Tube	1		
5	4431605	Hose Guard	1		SUB FOR 4402004
8	4478170	Hose	1		
10	FYD40001586	Bracket	1		
13	.....	Screw With Washer	2		J260820 NLA
	19M7881	Screw	2		M8 X 20, SUB FOR J900820
	24M7055	Washer	2		8.400 X 16 X 1.600 mm, SUB FOR A590108
15	4714147	Grip	1		Right
16	4690013	Grip	1		Left
17	4728520	Shaft	2	-287888	
	FYD00010844	Shaft	2	287889-	
18	4034733	Spring Pin	2		
19	14M7275	Nut	2		M12, SUB FOR J950012
20	2060151	Boot	2		
22	FYD00001784	Wiring Harness	1		Control Lever
23	R44302	Tie Band	5		SUB FOR 4326365
24	H77698	Tie Band	2		SUB FOR 4371049 AND 4441695
25	4721547	Clip	1		
27	A852222	Union Fitting	1		INCLUDES 957366
	957366	O-Ring	1		
31	H77698	Tie Band	2		SUB FOR 4055312
34	.....	Screw With Washer	2		J260814 NLA
	19M7162	Cap Screw	2		M8 X 16, SUB FOR J900814
	24M7055	Washer	2		8.400 X 16 X 1.600 mm, SUB FOR A590108
36	FYD00003202	Seal	1		
37	FYD00003114	Insulator	1		
39	FYD00004598	Hose	1		
40	FYD00004599	Hose	1		
41	FYD00004655	Hose	1		
43	4705752	Label	1		Auxiliary Function Lever

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 24 of 588 pages

The full manual includes:

- All 588 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

John Deere 50G Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual