YANMAR

PARTS CATALOG

PREVIEW - YOUFIXTHIS.COM

Published 2009/7 (Jul.)

0CNP4-G43700

Download full manual at youfixthis.com

CONTENTS

MODEL : EF227E-233E(
PC NO : 0CNP4-G43700

Fig.No. GROUP NAME

ENGINE CONTROL SECTION

1. ENGINE ACCESSORIES
2. ACCEL LEVER & FOOT ACCELERATOR
3. EXHAUST
4. FUEL TANK
5. FUEL PIPE
6. AIR CLEANER

FRONT AXLE SECTION

7. FRONT BLACKET
8. FRONT SUPPORT
9. FRONT HITCH
10. TIE ROD
11. RING GEAR
12. DIFFERENTIAL GEAR
13. PROPELLER SHAFT
14. FRONT SHAFT
15. FRONT AXLE CASE
16. FRONT GEAR CASE
17. FRONT SPINDLE
18. FRONT WHEEL TIRE
19. STEERING
20. P.S.T. CYLINDER
21. P.S.T. VALVE
22. P.S.T. HOSE

TRANSMISSION SECTION

23. CLUTCH HOUSING
24. CLUTCH & CLUTCH SHAFT
25. CLUTCH RELEASE

Fig.No. GROUP NAME

26. TRANSMISSION CASE
27. CENTER PLATE
28. REVERSE HOUSING
29. MAIN DRIVE SHAFT
30. MAIN SHAFT
31. REVERSE SHAFT
32. REDUCTION SHAFT
33. COUNTER SHAFT
34. REVERSE IDLE SHAFT
35. P.T.O. DRIVE SHAFT
36. P.T.O. SHAFT
37. MAIN CHANGE SHIFT
38. MAIN CHANGE LEVER
39. REVERSE SHIFT
40. REVERSE LEVER
41. SUB CHANGE SHIFT
42. SHIFT LINK
43. P.T.O. SHIFT
44. SUB CHANGE & P.T.O. LEVER
45. KNOB
46. FRONT DRIVE
47. FRONT SHIFT
48. 4WD LEVER

REAR AXLE SECTION


49. RING GEAR & DIFFERENTIAL GEAR
50. REAR HOUSING
51. DIFFERENTIAL LOCK
52. FINAL PINION & FINAL GEAR
53. REAR AXLE SHAFT

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Directions for the Parts Catalog.

1.The parts stipulated in this Parts Catalog are not necessarily standard equipped parts.
2.Parts may change without prior notice.
3.The following is an example of the Parts Catalog format.



①Ref. No.

The Ref. No. listed may not be in accordance with the illustration Ref. No.

(Ex.) Illustration No. List Ref No.

1 1 (Before change) → 1- 1 (After change)

For interchangeable symbols N, R and K, illustrations for new parts may be abbreviated.

②Lev. (Level)

Level indication

The numbers below indicate the level of relativity towards the main part.

1 ----- Main parts (Assembly parts)

2 ----- Sub component included in " 1 ".

3 ----- Sub component included in " 2 ".

Note) Parts that are not for sale are partially illustrated but not listed.

③Interchangeability Mark

When a part change takes place, one of the following interchangeability symbols is indicated beside the part.

Symbol	Interchangeability	Contents note
N	Old ← Yes / No → New	New Part is interchangeable for Old Part but Old Part is not interchangeable for New Part.
Q	Old ← No / Yes → New	New Part is not interchangeable for Old Part but Old Part is interchangeable for New Part.
R	Old ← Yes / Yes → New	New/ Old Parts are both interchangeable.
S	Old ← No / No → New	New/ Old Parts are both not interchangeable.
W		Part discontinued.
Z		Part newly added.
F		Not interchangeable by a single part but interchangeable together with related parts.
K		Changes only for used parts quantities.

④Effective Machine No.

When a part changes, the effective Machine No. will be indicated in the (A)-(F) column.

Product Symbol	Product No.	Product Symbol	Product No.
C	Clutch No. Compressor No.	F	Machine No. (Agricultural Equip.)
D	Drive No.	M	Machine No.
E	Engine No.	Note 1)	Date

Note 1) A date may follow the symbol. (Ex.) 1996.01

Note 2) " XXX " are for parts that could not be predicted or for engine models that could not be identified.

Note 3) (A=E00185) is the E (Engine Serial Number) for the column (A) model (in this case 4JH-DT) after the parts design change.

⑤Remarks Mark


Figures or alphabets (symbols) are entered in the remarks column.

The comments (remarks) on parts that are indicated at the bottom of the illustration are the same symbols as those stated above.

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Fig.1. ENGINE ACCESSORIES



Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

1. ENGINE ACCESSORIES


(A)=EF227E (B)=EF230E (C)=EF233E (D)= (E)= (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	198220-52180	RELAY, STARTER	1	1	1					
2	1	198461-52950	RELAY CA,TYPE C	1	1	1					
3	1	119650-77910	RELAY, GROW	1	1	1					
4	2	129052-77920	BODY, RELAY	1	1	1					
5	2	119650-77930	BRACKET, RELAY	1	1	1					
6	1	119852-77910	CONTROLLER,QHS	1	1	1					
7	1	26106-060162	BOLT M 6X 16 PLATED	3	3	3					
8	1	119852-44500	RADIATOR ASSY	1							
9	1	198200-00610	RUBBER, ABSORBER	2	2	2					
10	1	198200-01410	HOSE, COOLING WATER	1							
11	1	198200-01430	SEAL, WATER HOSE	1							
12	1	198200-01440	SEAL,RADIATOR	2	2	2					
13	1	198208-01451	HOSE, COOLING WATER	1	1	1					
14	1	198280-01470	PIPE,WATER DRAIN	1	1	1					
15	1	198200-01510	SHROUD ASSY, FAN	1							
16	1	198200-11351	STAY ASSY, FILTER	1	1	1					
17	1	129263-44510	TANK ASSY, SUB	1	1	1					
19	2	121450-44531	CAP	1	1	1					
20	2	124450-44560	CLAMP	1	1	1					
21	2	23065-070180	PIPE 7X 180	1	1	1					
22	2	121470-44581	GASKET	1	1	1					
23	1	129150-49101	COCK ASSY, 3-WAY	1	1	1					
24	2	129150-49081	COCK, DRAIN	1	1	1					
26	1	175022-49730	CRIP 31, HOSE	2	2	2					
27	1	124766-59050	CLAMP 12	2	2	2					
28	1	124766-59050	CLAMP 12	4	4	4					
29	1	198200-60710	GUIDE ASSY, SCREEN L	1							
30	1	198200-60760	GUIDE, SCREEN R	1							
31	1	198200-60950	SCREEN, RADIATOR	1							
32	1	198200-61950	WEATHER-STRIP, A	1	1	1					
33	1	198200-61980	SEAL, RADIATOR LH	1	1	1					
34	1	23000-035000	CLAMP 35	2	2	2					
35	1	23980-730250	HOSE 7.3X800 BRAIDED	1	1	1					
36	1	23980-730510	HOSE, 7.3 X 510	1	1	1					
37	1	26106-060122	BOLT M 6X 12 PLATED	4	4	4					
38	1	26106-060122	BOLT M 6X 12 PLATED	4	4	4					
39	1	26106-080162	BOLT M 8X 16 PLATED	1	1	1					
40	1	26106-080162	BOLT M 8X 16 PLATED	2	2	2					
41	1	129055-44501	RADIATOR ASSY		1	1					
42	1	198208-01410	HOSE, COOLING WATER		1	1					
43	1	198208-01480	URETHANE FOAM,RADIAT		2	2					
44	1	198208-01510	SHROUD ASSY, FAN		1	1					
45	1	198206-60710	GUIDE ASSY, SCREEN L		1	1					
46	1	198206-60760	GUIDE, SCREEN R		1	1					
47	1	198206-60950	SCREEN, RADIATOR		1	1					
48	1	198448-61620	CAP,		1	1					
49	1	194180-61980	GROMMET 24		1	1					

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\rightleftarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\rightleftarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

Fig.7. FRONT BLACKET



7. FRONT BLACKET

(A)=EF227E (D)=
(B)=EF230E (E)=
(C)=EF233E (F)=


REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	198280-11100	BRACKET M ASSY, AXLE	1							
2	1	198200-17950	CLAMP	1	1	1					
3	1	26013-120302	BOLT W/WASHER M12X30	12							
4	1	26106-080122	BOLT M 8X 12 PLATED	1	1	1					
5	1	198287-11100	BRACKET M ASSY, AXLE		1	1					
6	1	198208-11210	STAY, L.H.		1	1					
6-1	1	1A8115-11210	STAY, L.H.		1	1				R	
		(B=*2008.11.)	(C=*2008.11.)								
7	1	198208-11220	STAY, R.H.		1	1					
7-1	1	1A8115-11220	STAY, R.H.		1	1				R	
		(B=*2008.11.)	(C=*2008.11.)								
8	1	198208-11310	BOLT, 10 X 25		16	16					
9	1	26106-100452	BOLT M10X 45 PLATED		2	2					
10	1	26106-100552	BOLT M10X 55 PLATED		2	2					
11	1	198287-11210	PLATE L CMP.			1					
12	1	198287-11230	PLATE R CMP.			1					
13	1	26013-120252	BOLT M12X 25			4					
14	1	198093-84810	SEAL,FENDER		1	1					
		(B=*2008.01.)	(C=*2008.01.)								

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.26. TRANSMISSION CASE



PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

26. TRANSMISSION CASE


(A)=EF227E (B)=EF230E (C)=EF233E (D)= (E)= (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	194150-21910	PLUG 11.2	4	4	4					
2	1	198282-24110	HOUSING, XMSN.	1	1	1					
3	1	198200-24120	GASKET, XMSN.	1	1	1					
4	1	198282-24150	COVER ASSY, XMSN.	1	1	1					
5	2	198071-24350	PLATE,OL.INSP.WINDOW	1	1	1					
6	2	1A1040-28470	WINDOW 25,OIL CHECK	1	1	1					
7	1	198200-24170	GASKET, XMSN. COVER	1	1	1					
8	1	198280-24180	COVER, XMSN. SIDE	1	1	1					
9	1	198200-24190	GASKET, HOUSING	1	1	1					
10	1	198255-24460	PLATE, OIL SEAL	1	1	1					
11	1	198282-26710	STAY ASSY, LEVER	1	1	1					
12	1	198280-26901	GUARD M ASSY,PTO	1	1	1					
13	1	198280-73170	SUPPORT, LOWER LINK	1	1	1					
14	1	198280-73250	SUPPORT, LOWER LINK	1	1	1					
15	1	22312-080140	PIN 8X14,STRAIGHT	2	2	2					
16	1	23491-140002	PLUG 14	1	1	1					
17	1	23871-010000	PLUG PT1/8,SCREW	1	1	1					
18	1	23887-180002	PLUG 18	3	3	3					
19	1	24311-000160	O-RING 1A P-16.0	1	1	1					
20	1	24311-000180	O-RING 1A P-18.0	3	3	3					
21	1	26013-120552	BOLT M12X55	2	2	2					
22	1	26106-080162	BOLT M 8X 16 PLATED	2	2	2					
23	1	26106-080162	BOLT M 8X 16 PLATED	4	4	4					
24	1	26106-080162	BOLT M 8X 16 PLATED	2	2	2					
25	1	26106-080202	BOLT M 8X 20 PLATED	2	2	2					
26	1	26106-080202	BOLT M 8X 20 PLATED	6	6	6					
27	1	26106-080252	BOLT M 8X 25 PLATED	8	8	8					
28	1	26106-080452	BOLT M 8X 45 PLATED	1	1	1					
29	1	26106-080802	BOLT M 8X 80 PLATED	1	1	1					
30	1	26106-100252	BOLT M10X 25 PLATED	4	4	4					
31	1	26106-100502	BOLT M10X 50 PLATED	2	2	2					
32	1	27260-170000	PLUG 17,BORE	1	1	1					

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

Fig.60. HYDRAULIC PUMP



60. HYDRAULIC PUMP

(A)=EF227E (D)=
(B)=EF230E (E)=
(C)=EF233E (F)=


REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	198172-41110	PUMP, HYDRAULIC	1	1	1					
2	2	178070-10401	SQUARE RING	1	1	1					
3	2	194521-41570	PIN 11X7	2	2	2					
4	2	22252-000320	CIRCLIP 32	1	1	1					
5	2	24421-153207	SEAL TC15 32 07, OIL	1	1	1					
6	2	26016-080352	BOLT M 8X 35	4	4	4					
7	1	198280-41150	PUMP ASSY,HYD.OIL	1	1	1					
8	2	178070-10401	SQUARE RING	1	1	1					
9	2	194521-41570	PIN 11X7	2	2	2					
10	2	22252-000320	CIRCLIP 32	1	1	1					
11	2	24421-153207	SEAL TC15 32 07, OIL	1	1	1					
12	2	26016-080352	BOLT M 8X 35	4	4	4					
13	1	26013-080802	BOLT M 8X 80	2	2	2					
14	1	26013-080802	BOLT M 8X 80	2	2	2					

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.73. WIRE HARNESS



Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

73. WIRE HARNESS


(A)=EF227E (D)=
(B)=EF230E (E)=
(C)=EF233E (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	198280-51170	WIRING HARNESS, LAMP	1	1	1					
2	1	198461-52950	RELAY CA,TYPE C	1	1	1					
3	1	29622-250001	BAND RF 250	1	1	1					
4	1	198282-51150	WIRING HARNESS, F	1	1	1					
5	2	198535-52110	FUSE	3	3	3					
6	2	198535-52120	FUSE 10A	4	4	4					
7	2	198535-52130	FUSE 15A	3	3	3					
8	2	198535-52140	FUSE 20A	3	3	3					
9	2	198200-52520	COVER, FUSE BOX	1	1	1					
10	1	198280-51200	CABLE, STARTER	1	1	1					
11	1	194170-51210	GROMMET 25	1	1	1					
12	1	194242-51660	CLAMP, WIRE HARNESS	1	1	1					
13	1	26106-060122	BOLT M 6X 12 PLATED	2	2	2					
14	1	194990-22130	NUT W/WASHER 6	1	1	1					
15	1	194990-22140	NUT W/WASHER 8	1	1	1					
16	1	198282-51110	WIRING HARNESS, A	1	1	1					
17	1	198280-51410	CABLE, BATTERY	1	1	1					
18	2	1A7000-52820	SLOW BLOW FUSE60A	3	3	3					
19	1	194250-51420	CABLE, BATTERY EARTH	1	1	1					
20	1	198220-51870	CLAMP 200	3	3	3					
21	1	124550-77030	COVER, TERMINAL	1	1	1					
22	1	124756-77040	COVER, TERMINAL	1	1	1					
23	1	124756-77040	COVER, TERMINAL	1	1	1					
24	1	26106-080122	BOLT M 8X 12 PLATED	1	1	1					
25	1	26106-080162	BOLT M 8X 16 PLATED	1	1	1					
26	1	198280-51540	BATTERY,	1	1	1					
27	1	198200-51510	CORD,WATER TEMP.	1							

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

Fig.89. DRIVER SEAT



89. DRIVER SEAT

(A)=EF227E (D)=
(B)=EF230E (E)=
(C)=EF233E (F)=


REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	198282-62910	COVER ASSY,DUST B	1	1	1					
2	1	198282-63110	SEAT CMP	1	1	1					
3	1	26106-080122	BOLT M 8X 12 PLATED	6	6	6					
4	1	26106-080162	BOLT M 8X 16 PLATED	4	4	4					

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\rightleftarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\rightleftarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\rightleftarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

Fig.92. LABELS (SAFETY)



92. LABELS (SAFETY)

(A)=EF227E (D)=
(B)=EF230E (E)=
(C)=EF233E (F)=

REF.	LEV.	PARTS NO.	DESCRIPTION	Q'TY (A)	(B)	(C)	(D)	(E)	(F)	I	R
1	1	198163-65350	DANGER,ROTAT.SHAFT	1	1	1					
2	1	198280-65610	LABEL,3P	1	1	1					
3	1	198163-65930	CAUTION,MUFFLER	1	1	1					
4	1	198163-65940	CAUTION,SAFETY COVER	2	2	2					
5	1	1A6150-91251	LABEL,RAKE CAUTION	1	1	1					
6	1	1A6150-93151	LABEL,COVER	1	1	1					
7	1	198163-65310	LABEL, SAFETY	1	1	1					
8	1	198282-65300	LABEL,OPERATION G	1	1	1					
9	1	198163-65780	LABEL,BRAKE COUPLING	1	1	1					
10	1	198163-65930	CAUTION,MUFFLER	1	1	1					

N:Old $\overset{\text{Yes}}{\underset{\text{No}}{\leftrightarrows}}$ New, Q:Old $\overset{\text{No}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, R:Old $\overset{\text{Yes}}{\underset{\text{Yes}}{\leftrightarrows}}$ New, S:Old $\overset{\text{No}}{\underset{\text{No}}{\leftrightarrows}}$ New, W:Add, Z:Discontinued, F:Interchangeable by set, K:Q'ty Change

(C)Copy Rights YANMAR CO.,LTD.

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW - YOUFIXTHIS.COM

Download full manual at youfixthis.com

Part Number Index

All parts are stipulated in the order of part numbers.
(Depending on the area in which the part is used.)
This index will display the location of the part according to each part number.

CONTENTS

Fig.No. GROUP NAME

54. REAR WHEEL TIRE
55. REAR WHEEL TIRE
56. BRAKE
57. PEDAL
58. BRAKE LINK
59. PARKING BRAKE

HYDRAULIC CONTROL SECTION

60. HYDRAULIC PUMP
61. HYDRAULIC CYLINDER CASE
62. HYDRAULIC CYLINDER CASE (DRAFT
63. PISTON & LIFT CRANK
64. CONTRPL VALVE
65. RELIEF VALVE
66. SUB VALVE
67. S.C.V. PIPING
68. S.C.V. CONTROL
69. HYDRAULIC CONTROL
70. HYDRAULIC CONTROL (DRAFT
71. DRAFT CONTROL
72. HYDRAULIC PIPING

ELECTRICAL PARTS SECTION

73. WIRE HARNESS
74. WIRE HARNESS
75. SWITCH
76. LAMP
77. LICENCE LAMP
78. METER
79. HORN

Fig.No. GROUP NAME

80. COUPLER

FITTINGS SECTION

81. HOOD
82. SIDE COVER
83. DASHBOARD
84. CURRENT PLATE
85. FENDER
86. LEVER GUIDE
87. FLOOR COVER
88. FLOOR
89. DRIVER SEAT
90. BACK MIRROR
91. LABELS
92. LABELS (SAFETY)

HITCH SECTION

93. TOP LINK
94. LIFT LINK (R
95. LIFT LINK (L
96. LOWER LINK & CHECK CHAIN
97. DRAWBAR HITCH
98. CONTROL BOX
99. SAFETY FRAME (REAR
100. SAFETY FRAME (FRONT

ACCESSORIES SECTION

101. ACCESSORIES

PREVIEW - YOUFIXTHIS.COM
Download full manual at youfixthis.com

PREVIEW ONLY

You're viewing 12 of 124 pages

The full manual includes:

- All 124 pages, complete
- Searchable PDF (find any keyword)
- No watermarks
- Instant download
- Print-ready quality

GET FULL MANUAL NOW

Yanmar EF227E, EF230E, EF233E Parts Catalog

Scan or click anywhere
youfixthis.com

Click anywhere on this page to get the full manual